

ArmorStart ST Motor Controller

Bulletin Numbers 281E and 284E (includes safety versions)



Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment can be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which can lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT Identifies information that is critical for successful application and understanding of the product.

Labels can also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

European Communities (EC) Directive Compliance

If this product has the CE mark it is approved for installation within the European Union and EEA regions. It has been designed and tested to meet the following directives.

Low Voltage and EMC Directives

This product is tested to meet Council Directive 2006/95/EC Low Voltage Directive and Council Directive 2004/108/EC Electromagnetic Compatibility (EMC) by applying the following standard(s):

- Bulletin 281E controller: EN 60947-4-1 — Low-voltage switchgear and controlgear — Part 4-1: Contactors and motor-starters — Electromechanical contactors and motor-starters.
- Bulletin 284E controller: EN/IEC 60947-4-2, EN50178, EN 61800-3 — CE Marked per Low Voltage Directive 2006/95/EC and EMC Directive 2004/108/EC

This product is intended for use in an industrial environment.

Notes:

	Preface	15
	Software Requirements	15
	Summary of Changes	15
	Additional Resources	15
	 Chapter 1	
Product Overview	Description	18
	Catalog Number Explanation	19
	Operation	20
	Mode of Operation.....	21
	Bulletin 281E Controller.....	21
	Full-voltage and Reversing Start.....	21
	Bulletin 284E Controller.....	21
	Sensorless Vector Control.....	21
	Description of Features	22
	Overload Protection	22
	Embedded Switch Technology	22
	Switched, Unswitched, and Safety Power Connections	23
	EtherNet/IP Ports	25
	Embedded Web Server	25
	Email Notification Configuration.....	25
	EtherNet/IP Light-emitting Diode (LED) Status Indication.....	25
	Control Module LED Status and Reset	26
	Electronic Data Sheet (EDS)	26
	Fault Diagnostics.....	27
	Protection Faults	27
	Standard Features	27
	Inputs	27
	Outputs	28
	Gland Plate Entrance	28
	Motor Cable	28
	DeviceLogix.....	28
	Factory-installed Options.....	29
	Source Brake Contactor and Connector (Bulletin 284E Controller Only).....	29
	EMI Filter (Bulletin 284E Controller Only).....	29
	Dynamic Brake Connector (Bulletin 284E Controller Only)..	29
	Safety Output Contactor.....	29
	ArmorStart ST Controller Features.....	30
	ArmorStart ST Controller - Safety Features	31
	 Chapter 2	
Installation, Wiring, and Maintenance	Receiving.....	33
	Unpacking.....	33
	Inspecting	33
	Storing	33

General Precautions 34

Precautions for Bulletin 284E Applications..... 35

Bulletin 281E ArmorStart Controller Connections and Dimensions 36

Bulletin 284E ArmorStart Controller Connections and Dimensions 38

Mount Orientation..... 40

ArmorConnect Power Media 41

 Description 41

Control Power..... 43

 24V DC Control Power..... 43

AC Supply Considerations for Bulletin 284E Units 44

 Ungrounded and High Resistive Distribution Systems 44

Group Motor Installations for USA and Canada Markets 44

Wiring and Workmanship Guidelines 44

 Other System Design Considerations 45

Electromagnetic Compatibility (EMC) 46

 General Notes (Bulletin 284E Controller Only)..... 46

 Wiring 46

Grounding..... 47

 Grounding Safety Grounds..... 47

 Grounding PE or Ground..... 47

Shield and Grounding of Motors and Motor Cables..... 48

 Motor Cable Considerations 48

 Unshielded Cable 48

ArmorConnect Connections..... 49

 Control Power Overview — 4-pin Auxiliary Power..... 49

ArmorConnect Cable Ratings..... 50

 Branch Circuit Protection Requirements for ArmorConnect
 Three-Phase Power Media When Used with ArmorStart
 Controllers 50

Ethernet and I/O Connections..... 51

Power Connections 51

Maintenance..... 53

Chapter 3

Functional Safety

Bulletin 281E Safety Version ArmorStart ST Controller Connections
and Dimensions..... 55

Bulletin 284E Safety Version ArmorStart ST Controller Connections
and Dimensions..... 57

Safety Wiring..... 60

 Safety I/O Module and TÜV Requirements 60

ArmorBlock Guard I/O Modules..... 61

ArmorBlock Guard I/O Recommended Cables and Connectors .. 62

 Micro Cables..... 62

 Safety Function Definition 62

 Limitations of the Safety-related Parts..... 62

Safety Configuration 63

Catalog Number 1732ES-IB12XOBV2 or 1732ES-IB8XOBV4
 Safety I/O Module and PLC Program 63
 ArmorStart ST Controller 63
 Safety PLC Program: 64
 Safety-related Specifications 65
 Component Response Time 65
 Probability of a Dangerous Failure Per Hour and MTTFd for
 Uncontrolled Stop 65
 Maintenance and Internal Part Replacement 65
 Contactor Circuit Verification Procedure 65
 Troubleshooting 66
 1732ES-IB12XOBV2 or 1732ES-IB8XOBV4 Safety Module . 66
 ArmorStart ST - Safety Bulletin 281/284 Distributed Motor
 Controllers Safety Circuit Troubleshooting 66
 ArmorConnect Connections..... 67
 Control Power Overview — 4-pin Auxiliary Power..... 67
 I/O Connections..... 68

Chapter 4

**Introduction to EtherNet/IP and
 Device Level Ring Technology**

Terminology..... 69
 Introduction to EtherNet/IP..... 70
 Linear Network Introduction 73
 Device Level Ring 74
 Introduction 74
 Number of Nodes on a DLR Network 76
 Ethernet Switches 76
 Ethernet Media 76
 EtherNet/IP General Wiring Guideline..... 77
 Requested Packet Interval..... 77

Chapter 5

Product Commissioning

IP Address..... 79
 Gateway Address 80
 Subnet Mask 80
 Configuring EtherNet/IP Address..... 80
 Manually Configure the Network Address Switches 81
 Rockwell Automation
 BootP/DHCP Utility 83
 Save the Relation List 85
 DHCP IP Support 86
 Rockwell Automation Embedded Web Server 87
 Internal Web Server 87
 Network Configuration..... 89
 Parameter Configuration..... 90
 Email Notification Configuration..... 91
 Device Connections..... 92

Ownership 93
 Ethernet Statistics Web Page 94
 Connection Manager Cmd Object Info Web Page 95
 Ring Statistics Web Page..... 96

Chapter 6

**Adding an ArmorStart Selection
to Studio 5000 Software**

Setup..... 97
 Connect and Configure ArmorStart Controller with
 Add-on Profile (AOP)..... 100
 Offline Connection 102
 General Tab..... 102
 Connection Tab..... 103
 Parameters and Configuration Tab..... 104
 Online Connection 105
 Correlation 108
 Module Info Tab 109
 Internet Protocol Tab..... 110
 Port Configuration Tab..... 111
 Network Tab..... 111
 Auto-generated Tags..... 112

Chapter 7

**Bulletin 281E/284E
Programmable Parameters**

Basic Set-up Parameters..... 123
 Parameter Groups 124
 ArmorStart EtherNet/IP Parameters..... 125
 Introduction 125
 How to Program Parameters..... 125
 Bulletin 281E Controller 125
 Basic Status Group 125
 Produced Assembly Config Group 134
 Starter Protection Group..... 135
 User I/O Configuration Group..... 137
 Miscellaneous Configuration Group 141
 Starter Display Group (Bulletin 281E Controller Only) 142
 Starter Set-up Group (Bulletin 281E Controller Only) 144
 Bulletin 284E Controller 145
 Basic Status Group 145
 Produced Assembly Config Group 155
 Starter Protection Group..... 156
 User I/O Configuration Group..... 159
 Miscellaneous Configuration Group 162
 Drive I/O Configuration Group
 (Bulletin 284E controller only) 164
 Drive Display Group (Bulletin 284E controller only) 166
 Drive Setup Group (Bulletin 284E controller only)..... 171
 Drive Advanced Setup Group (Bulletin 284E controller only) 175

Clear a Type 1 Fault and Restart the Drive.....	185
Clear an Overvoltage, Undervoltage, or Heatsink OvrTmp Fault without Restarting the Drive	186
Linear List of Parameters for Bulletins 281E and 284E	197

Chapter 8

How to Configure an Explicit Message

Programming ControlLogix Explicit Message.....	203
Explicit Messaging with ControlLogix.....	203
Configuring the MSG Instruction	203
Formatting an Explicit Message.....	204
Performing Explicit Messages	205

Chapter 9

Diagnostics

Overview	207
Protection Programming.....	207
Fault Display.....	207
Clear Fault	207
Fault Codes.....	208
Fault Definitions	208
Short Circuit.....	208
Overload Trip.....	208
Phase Loss	209
Phase Short	209
Ground Fault	209
Stall	209
Control Power	209
I/O Fault	209
Over Temperature.....	209
Phase Imbalance.....	209
Over Current	210
A3 Power Loss	210
Internal Communication Fault	210
DC Bus Fault	210
Electrically Erasable Programmable Read-only Memory (EEPROM) Fault	210
Hardware Fault	210
Restart Retries.....	210
Miscellaneous Faults.....	211
EtherNet/IP LED Status Indication	211
Control Module LED Status and Reset	213
Control Module Fault LED Indications.....	213
Fault 11 Detail.....	215
Resetting Device to Factory Defaults.....	217

Chapter 10

Troubleshooting

Introduction.....	219
-------------------	-----

Bulletin 281E Troubleshooting..... 220

Bulletin 284E Troubleshooting..... 221

 Fault Definitions 221

IP67 Dynamic Brake Diagnostic (DB1) 222

DB1 Faults 222

 Operation and Troubleshooting of the DB1 - Dynamic Brake 222

 DB1 Resistor Overtemperature Fault..... 223

 DB1 Overcurrent Fault 223

 DB1 Undercurrent Fault..... 224

 DB1 Switch Fault 224

 DB1 Open Fault 225

 DB1 VBus Link Fault..... 225

 DB1 Comm Fault 225

 DB1 Thermal Warning 226

 Reading the Control Supervisor Object..... 226

Hardware Fault - Fan RPM Warning 226

 FAN Fault Handling with Firmware 66.21 of 284..... 226

 Operation 226

 Starter Status, Warning Bit 5: 226

 Warning Status, Parameter 62: 226

 Annunciation with PLC Logic..... 227

Internal Drive Faults 227

Ethernet Statistics 231

Troubleshoot and General Solutions for Linear
or DLR Networks 231

 Specific Issues on Your DLR or Linear Network 232

Troubleshoot Intermittent Ethernet Connectivity 236

 Ethernet Statistics 237

Ethernet Managed Switch Considerations..... 239

 Internet Group Multicast Protocol..... 239

 Virtual Local Area Networks 240

 Port Mirroring 240

Control Module Removal and Installation 241

 Removal of Control Module 241

 Installation of Control Module 241

Fuse Replacement 242

 Source Brake Fuse Faults Reset 243

Chapter 11

**Specifications for ArmorStart
Controllers with EtherNet/IP**

Bulletin 281E Controller 245

 Motor Overload Trip Curves..... 249

 Contactor Life Load Curves 250

Bulletin 284E Controller 253

 Sensorless Vector Control (SVC) 256

 Motor Overload Trip Curves..... 257

Altitude Derating 259

 Altitude Rating for Bulletin 281 259

	Altitude Rating for Bulletin 284	259
	Chapter 12	
Accessories	Industrial Ethernet Media	261
	D Code Connectivity (M12) – 1585D	261
	Sensor Media	262
	Sensor Wiring.....	262
	Motor and Brake Cables	263
	Three-phase Power.....	268
	24V DC Auxiliary Power	268
	Sealing Caps	269
	Handle Accessory	269
	Dynamic Brake Resistors Recommended Dynamic Brake Modules for Option DB1 (IP67 Resistor)	269
	Appendix A	
Applying More Than One ArmorStart Motor Controller in a Single Branch Circuit on Industrial Machinery	Introduction.....	271
	Background.....	271
	Importance of a Motor Controller Being Listed for Group Installation.....	272
	Listing Requirements for a “Factory Assembly” and “Separate Assemblies”	273
	ArmorStart Product Family	274
	Multiple-motor Branch Circuits and Motor Controllers Listed for Group Installation – General.....	275
	Maximum Fuse Ampere Rating according to 7.2.10.4(1) and 7.2.10.4(2).....	277
	Complete Text	277
	Explanatory Example	279
	Input and Output Conductors for Mechanical Controllers (a) ...	285
	Input and Output Conductors for Variable Frequency Drives (b)	285
	Combined Load Conductors (c).....	286
	Appendix B	
Common Industrial Protocol (CIP) Information	High-level Product Description	287
	Product Codes and Name Strings.....	287
	CIP Explicit Connection Behavior.....	287
	EDS Files	288
	CIP Object Requirements.....	288
	Identity Object.....	289
	CLASS CODE 0x0001	289
	Assembly Object	291
	CLASS CODE 0x0004	291
	I/O Assemblies.....	292
	Connection Manager Object.....	296
	CLASS CODE 0x0006	296

Class 1 Connections	297
Exclusive Owner Connection.....	297
Listen Only Connection	298
Class 3 CIP Connections.....	298
Discrete Input Point Object.....	299
CLASS CODE 0x0008	299
Discrete Output Point Object.....	300
CLASS CODE 0x0009	300
Parameter Object	301
CLASS CODE 0x000F	301
Parameter Group Object.....	303
CLASS CODE 0x0010	303
Discrete Input Group Object.....	304
CLASS CODE 0x001D	304
Discrete Output Group Object.....	304
CLASS CODE 0x001E	304
Control Supervisor Object.....	306
CLASS CODE 0x0029	306
Overload Object	308
CLASS CODE 0x002C.....	308
Device Level Ring (DLR) Object	309
CLASS CODE 0x0047	309
Qos Object	310
CLASS CODE 0x0048	310
DPI Fault Object.....	311
CLASS CODE 0x0097	311
DPI Alarm Object.....	315
CLASS CODE 0x0098	315
Interface Object.....	317
CLASS CODE 0x00B4.....	317
TCP/IP Interface Object	318
CLASS CODE 0x00F5	318
Ethernet Link Object.....	319
CLASS CODE 0x00F6	319

Appendix C

DeviceLogix

DeviceLogix Programming.....	322
DeviceLogix Programming Example	323
Import and Export	329

Appendix D

Replacement Parts

Bulletin 281E	
Standard Version Controller	331
Bulletin 284E	
Standard Version Controller	332

	Bulletin 281E Safety Version Controller.....	332
	Bulletin 284E Safety Version Controller.....	333
	Replacement Fuses	334
	Replacement Parts.....	334
	Appendix E	
System Design Considerations When Using a Line Reactor	General Rule.....	335
	Reasons to Use.....	335
	ArmorStart Design.....	336
	Appendix F	
Application Examples	Manual Brake Control.....	337
	Bulletin 284 - VFD Preset Speed Example.....	340
	Operation	345
	DeviceLogix Ladder Editor Example.....	346
	ArmorStart Bulletin 281 Status Bits.....	346
	ArmorStart Bulletin 281 Fault Bits.....	347
	ArmorStart Bulletin 281 Outputs.....	348
	ArmorStart Bulletin 281 Produced Network Bits	348
	ArmorStart Bulletin 284 Status Bits.....	349
	ArmorStart Bulletin 284 Fault Bits.....	349
	ArmorStart Bulletin 284 Outputs.....	350
	ArmorStart Bulletin 284 Produced Network Bits	351
	Report Examples	352
	How to Report the RPM of the Bulletin 284 Internal Fan....	352
	How to Report the Heat Sink Temperature of Bulletin 284..	352
	How to Report the Last Four Faults.....	353
	How to Report an IP Address Conflict Detection.....	353
	Demand Torque Off Considerations	354
	Keypad Disable with DeviceLogix	354
	Motion Disable	354
	Appendix G	
Cable System Quick Reference Diagram	355
	Index	357

Notes:

This manual describes the ArmorStart ST motor controller. It includes information on installation, configuration, programming, and use.

Software Requirements

Network	Software	Version
EtherNet/IP®	RSLinx® Classic	2.56 or later
	RSLogix 5000®	17.01 or later
	Add-on Profile	Download the most current version of the Add-on Profile from: https://rockwellautomationcusthelp.com/
	BOOTP/DHCP	Version 2.3 or later

Summary of Changes

This manual contains new and updated information as indicated in the following table.

Topic	Page
Updated short circuit protection specifications.	245, 253
Updated accessories.	267, 268
Added missing dimension for Dynamic Brake Resistor.	270

Additional Resources



These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
ArmorStart ST Motor Controller Product Information, 280ES-PC001	Provides basic information on how to install, configure, and program, the ArmorStart controllers.
ArmorStart Distributed Motor Controller and ArmorConnect Power Media Selection Guide, 280PWR-SG001	Provides information on product specifications, ratings, certifications, system interface, wiring diagrams, and dimensions, to aid in product selection.
Wiring and Grounding Guidelines for Pulse-width Modulated (PWM) AC Drives, DRIVES-IN001	Provides information to install, protect, wire, and ground pulse-width modulated (PWM) AC drives.
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, http://www.rockwellautomation.com/global/certification/overview.page	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at <http://www.rockwellautomation.com/global/literature-library/overview.page>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Notes:

Product Overview

		
Bulletin	281E	284E
Type	EtherNet/IP	
Horsepower Range:		
0.5...10 Hp (0.37...7.5 kW)	✓	—
1...5 Hp (0.4...3.0 kW)	—	✓
Start Method:		
Full-Voltage and Reverse	✓	—
Sensorless Vector Control	—	✓
Environmental Rating:		
IP67/NEMA Type 4/12 ⁽¹⁾	✓	✓
Control Voltage:		
24V DC	✓	✓
Operational Voltage Ratings:		
200...480V AC	✓	—
380...480V AC	—	✓
Rated for Group Motor Installations	✓	✓
Local logic with DeviceLogix	✓	✓
I/O Capability:	✓	
Four Inputs	✓	✓
Two Outputs	✓	✓
Light-emitting Diode (LED) Status Indication	✓	✓
Gland Plate Entry:		
ArmorConnect Power Media	✓	✓
Quick Disconnects (I/O, Communications, Motor Connection, Three-Phase, and Control Power)	✓	✓
Extended Length Motor and Brake Cables	✓	✓
Factory-Installed Options:		
Source Brake Connector	—	✓
Dynamic Brake Connector	—	✓
Redundant Safety Output Contactor	✓ ⁽²⁾	✓ ⁽¹⁾
EMI Filter	—	✓
Non-shielded/Shielded Motor Cable	—	✓

(1) A sealing cap must be installed on any unused connection to achieve IP67 and Type 4/12 environmental rating.

(2) Only applies to ArmorStart Safety version controller.

Description

The ArmorStart® ST controller is an integrated, pre-engineered, motor-starting solution that implements a safety-related stop function that conforms to Category 0 of IEC 60204-1. The ArmorStart ST controller has different quick connectors versus the ArmorStart controller. The ArmorStart ST controller provides the equivalent of an embedded dual-port EtherNet/IP switch. Model 281E-*-RRG is used in full-voltage and reverse applications. Model 284E-*-RRG-* is used in variable frequency applications where more precise motor control is needed. The ArmorStart ST controller offers IP67/NEMA Type 4/12 enclosure design, which is suitable for water wash down environments, when connectors or a sealing cap in place.

The ArmorStart ST safety version controller is used with an Allen-Bradley® Safety I/O ArmorBlock®, catalog number 1732ES-IB12XOBV2 or 1732ESIB8XOBV4. Over-molded cables (Allen-Bradley® 889N series) connect the ArmorBlock unit to the ArmorStart units. This configuration provides for implementation of a safety-related stop function in machines with the capability of Cat. 4/PL e, according to EN ISO 13849-1 and SIL 3, according to EN 62061/IEC 61508.

Note: For additional information regarding the 1732ES Safety I/O module, see Guard I/O EtherNet/IP Safety Modules User Manual, publication [1791ES-UM001](#).

The ArmorStart ST controller has four configurable (sink/source) DC inputs and two sourcing solid-state outputs. These inputs and outputs are used with sensors and actuators respectively, for monitoring and controlling the application process.

An Add-on Profile (AOP) for ControlLogix® is available. Launch the associated AOP for the device to set up and configure it, by using Studio 5000® software, revision 17.01 or later.

UL Lists the ArmorStart controller and its mating cable assemblies for use ONLY with each other. Both are suitable for installation in motor groups in accordance with 7.2.10.4 of NFPA® 79, *Electrical Standard for Industrial Machinery*®. From the perspective of the ArmorStart product family, being Listed for group installation means one set of fuses or one circuit breaker can protect a branch circuit that has two or more of these motor controllers that are connected to it (see Appendix A).



Variable Frequency Drive (VFD) with Safety



Direct Online Reversing (DOLR) with Safety



Variable Frequency Drive (VFD)



Direct Online Reversing (DOLR)

Catalog Number Explanation

Examples that are given in this section are for reference purposes. This basic explanation cannot be used for product selection because not all combinations produce a valid catalog number.

Figure 1 - Catalog Number Explanation for 281E

281
E - F
12
Z - 10
C - RRG

a
b
c
d
e
f
g
h

a

Bulletin Number	
Code	Description
281	Reversing Starter

b

Code	Description
E	EtherNet/IP

c

Enclosure Type	
Code	Description
F	IP67/NEMA Type 4/12

d

Contactor Size	
12	
23	

e

Control Voltage	
24V DC	
Code	Description
Z	Standard Version
S	Safety Version

f

Short Circuit Protection (Motor Circuit Protection)	
Code	Description
10	10 A Rated Device
25	25 A Rated Device

g

Overload Selection Current Range	
Code	Description
A	0.24...1.2 A
B	0.5...2.5 A
C	1.1...5.5 A
D	3.2...16 A

h

Control and 3-Phase Power Connections/Motor Cable Connection			
Code	Description		
	Control Power	3-Phase Power	Motor Cable
RRG	Round Media (Male Receptacle)	Round Media (Male Receptacle)	No cables supplied

Figure 2 - Catalog Number Explanation for 284E

284 E - F V D2P3 Z - 10 - RRG - SBG - DB1 - EMI
a b c d e f g h i j

<i>a</i>		<i>d</i>		<i>f</i>		<i>i</i>	
Bulletin Number		Torque Performance Mode		Control Voltage		Brake	
Code	Description	Code	Description	Code	Description	Code	Description
284	VFD Starter	V	Sensorless Vector Control and Volts per Hertz	S	24V DC (Safety Version)	DB1	Connectivity to IP67 DB Resistor
				Z	24V DC (Standard Version)	SBG	Source (EM) Brake

<i>b</i>		<i>e</i>		<i>g</i>		<i>j</i>	
Communications		Output Current		Short Circuit Protection (Motor Circuit Protector)		Filter	
Code	Description	Code	Description	Code	Description	Code	Description
E	EtherNet/IP	380...480V		10	10 A Rated Device	EMI	EMI Filter
		D2P3	2.3 A, 0.75 kW, 1.0 Hp	25	25 A Rated Device		
		D4P0	4.0 A, 1.5 kW, 2.0 Hp				
		D6P0	6.0 A, 2.2 kW, 3.0 Hp				
		D7P6	7.6 A, 3.3 kW, 5.0 Hp				

<i>h</i>			
Control and 3-Phase Power Connections / Motor Cable Connection			
Code	Description		
	Control Power	3-Phase Power	Motor Cable
RRG	Round Media (Male Receptacle)	Round Media (Male Receptacle)	No cable

Operation

The ArmorStart ST distributed motor controllers operate three-phase, squirrel-cage induction motors as follows:

Bulletin 281E controller: up to 10 Hp (7.4 kW) at 480V AC

Bulletin 284E controller: up to 5 Hp (3.0 kW) at 480V AC


Mode of Operation

Bulletin 281E Controller

Full-voltage and Reversing Start

This method is used in applications that require across-the-line starting, where full inrush current and locked-rotor torque are realized.

Figure 3 - Full-voltage Start




Bulletin 284E Controller

Sensorless Vector Control

Sensorless vector control provides optimal speed regulation and high levels of torque across the entire speed range of the drive. It features Autotune, which lets the motor controller adapt to individual motor characteristics.

Figure 4 - Sensorless Vector Control



Description of Features

Overload Protection

The ArmorStart ST distributed motor controller has, as standard, electronic motor overload protection. This overload protection is accomplished electronically with an I^2t algorithm. The overload protection of the ArmorStart ST controller is programmable via the communication network (see [Chapter 11](#) for overload trip curves specifications).

Embedded Switch Technology

The ArmorStart ST controller includes embedded switch technology, as standard. Each ArmorStart ST controller consumes one Common Industrial Protocol (CIP™) connection.

Common features are:

- Designed according to the ODVA specification for EtherNet/IP. ODVA specification is at <http://www.odva.org/>
- Embedded switch technology design enables end devices to form linear and ring network topologies
- Supports Device Level Ring (DLR) protocol
- Supports IEEE 1588 transparent clock for CIP Motion™ and CIP Sync™ applications
- Supports the management of network traffic to achieve timely delivery of critical data (QoS and IGMP protocols are supported)

Note: DLR ports cannot be used as two Network Interface Cards (NICs) that are connected to two different subnets.

Switched, Unswitched, and Safety Power Connections


Switched control power (A1/A2) supplies power to outputs, contactor coil, and VFD enable, in the standard controller version, see [Figure 5](#) and [Figure 6](#). When this power is removed or when the disconnect is turned Off, the outputs turn Off and power is removed from the motor output connector. In the safety controller version, the internal safety contactors are controlled from the safety I/O block P/M signals.

Figure 5 - Standard Version Connectors



Switched Control Power: A1/A2
Unswitched Control Power: A3/A2

Figure 6 - Standard Version Control Power Diagram



Switched Control Power: A1/A2
Unswitched Control Power: A3/A2

Unswitched control power (A3/A2) supplies power to inputs, communications, and the electronic control module, see [Figure 5](#) and [Figure 6](#). When this power is removed, the device turns off, with no further control of the motor. There is no communication or I/O activity.

Note: When the local disconnect is turned OFF, it does not inhibit communication or input status.

The safety controller version has additional inputs and outputs that come from the safety contactors. The safety I/O block monitors these inputs and outputs.

The safety I/O block (1732ES safety I/O) interfaces with the ArmorStart ST safety controller version. The P and M safety outputs (SO) control the internal safety contactor. The safety inputs (SI) monitor the safety contactor via SM1 and SM2, see [Figure 7](#) and [Figure 8](#).

Figure 7 - Safety Connectors





Figure 8 - Safety Power Block Input and Output Configuration



EtherNet/IP Ports

The Ethernet switch supports 10/100 Mbps. It uses a sealed D-coded micro (M12) style Ethernet connector. Dynamic Host Configuration Protocol (DHCP) is enabled as the factory default.



ATTENTION: To avoid unintended operation, the adapter must be assigned a fixed IP address. If a DHCP server is used, it must be configured to assign a fixed IP address for your adapter.

Failure to observe this precaution can result in unintended machine motion or loss of process control.

Embedded Web Server

The embedded web server enables the viewing of information and the configuring of the ArmorStart controller via a web browser. The default login is “Administrator”. **There is no password set by default.**

IMPORTANT Set the password to a unique value for authorized personnel. If the Login and password are lost, you have to reset the device to factory defaults. Note: The configuration will be lost.

Email Notification Configuration

The embedded web server supports configuration of the Simple Mail Transfer Protocol (SMTP). Once properly configured, the motor controller emails you with specific fault/trip messages.

EtherNet/IP Light-emitting Diode (LED) Status Indication

Figure 9 - EtherNet/IP LED



EtherNet/IP Light-emitting diode (LED) status and diagnostics consist of four LEDs.

- Link Activity/Status LEDs
 - Ethernet Link1 Activity/Status (Port 1) – LED Color: Bicolor (Green/Yellow)
 - Ethernet Link2 Activity/Status (Port 2) – LED Color: Bicolor (Green/Yellow)
- “MOD” LED – Bicolor Red/Green represents the Ethernet module status
- “NET” LED – Bicolor Red/Green represents the Ethernet network status

Control Module LED Status and Reset

Figure 10 - LED Status Indication and Reset



The Control Module LED status and diagnostics consist of four status LEDs and a Reset button.

- POWER LED**
 The LED is illuminated solid green when switched (+A1/A2) control power is present with the proper polarity.
- RUN LED**
 This LED is illuminated solid green when a start command and control power are present.
- NETWORK LED**
 This bicolor (red/green) LED indicates the status of the internal communication link.
- FAULT LED**
 This LED indicates a Controller Fault (trip) condition.

The “Reset Button” is a local trip reset.

Electronic Data Sheet (EDS)

EtherNet/IP devices have Electronic Data Sheets (EDSs). EDSs are specially formatted text files, as defined by the CIP specifications, which represent the object model of the device. EDS files contain details about the readable and configurable parameters of the EtherNet/IP device. EDS files also provide information about the I/O connections the device supports and the content of the associated data structures. EDS files are used by EtherNet/IP device configuration tools, such as RSNetWorx™ for EtherNet/IP, and data servers such as RSLinx® Classic.

EDS files for all ArmorStart EtherNet/IP devices can also be uploaded directly from the device via the web server interface. Rockwell Automation® product EDS files are also available at: <http://www.ab.com/networks/eds>.

Fault Diagnostics

Fault diagnostic capabilities that are built in the ArmorStart ST distributed motor controller are designed to help you pinpoint a problem for easy troubleshooting and quick restarting.

Protection Faults

Protection faults are generated when potentially dangerous or damaging conditions are detected. Protection faults are also known as “Trips.”

Table 1 - Protection Faults

Bulletin 281E Trip Status	Bulletin 284E Trip Status	PowerFlex® 40 Fault Codes
Short Circuit	Short Circuit	—
Overload	Overload	(Drive Codes 7 and 64)
Phase Loss	Phase Short	(Drive Codes 38...43)
Reserved	Ground Fault	(Drive Code 13)
Reserved	Stall	(Drive Code 6)
Control Pwr Loss	Control Pwr Loss	—
Input Fault	Input Fault	—
Over Temperature	Over Temperature	—
Phase Imbalance	Over Current	(Drive Codes 12 and 63)
A3, Unswitched Power Loss	A3, Unswitched Power Loss	—
Reserved	Internal Comm	(Drive Code 81)
Reserved	DC Bus Fault	(Drive Codes 3, 4 and 5)
EEPROM	EEPROM	(Drive Code 100)
Hdw Flt	Hdw Flt	(Drive Codes 70 and 122)
Reserved	Restart Retries	(Drive Code 33)
Reserved	Misc. Fault ⁽¹⁾	(Drive Codes 2, 8, 29, 48 and 80)

(1) Included is DB1 monitoring or resistor issue.

Parameter Group “Start Protection,” Parameter 24 “PrFault Enable” is used to enable and disable these listed protection faults. See Parameter 61 “LastPR Fault” for additional details of the last protection fault.

Standard Features

Inputs

Four 24V DC inputs are included that are single keyed (two inputs per connector) and sourced from A3/A2 control power. The inputs use two M12 connectors. Each input has an LED status indication. They are configurable as sinking or sourcing.

Outputs

Two self-protected solid-state outputs are included that are single keyed (one per connector) and sourced from A1/A2 control power. Outputs are sourcing type with a maximum current per output of 0.5 A DC. The outputs use one M12 connector per output, each having LED status indication.

Gland Plate Entrance

The ArmorStart ST controller offers connectivity to the ArmorConnect® power media. Factory-installed receptacles are provided for connectivity to three-phase control power media and safety I/O.

The power input gland connectors include: one 35 mm, 4-pin female connector for three-phase power input and one 22 mm (mini size), 4-pin female connector for control power input. The safety version controller adds two 12 mm (micro), 4-pin male connectors for P/M and SM1/SM2 connection.

Motor Cable

Motor cable assemblies are not supplied and have to be ordered separately. To comply with the UL Listing of the controller, use the Rockwell Automation motor cable assembly that is specified by the instructions for the controller. See [Chapter 12](#) for available catalog numbers.

DeviceLogix

DeviceLogix™ is a standalone Boolean program that resides within the ArmorStart distributed motor controller. DeviceLogix is programmed locally by using the AOP and implements Boolean math operations, such as, AND, OR, NOT, Timers, Counters, and Latches. DeviceLogix can run as a standalone application, independent of the network. However, 24V DC via A3 unswitched control power, must be maintained. After a power cycle, all DeviceLogix accumulator data, including timers and counter will be reset. Preset values are maintained over a power cycle.

Factory-installed Options

Source Brake Contactor and Connector (Bulletin 284E Controller Only)

An internal contactor is used to switch the electromechanical motor brake On/Off. The motor brake contactor sources power to the motor brake solenoid from the line side power circuit. The configuration of the R1 relay controls the operation (coil) of the contactor. A customer-accessible 3 A fuse is provided to help protect the brake cable from overcurrent. The cable is ordered separately. Use the Rockwell Automation power media and cable assemblies that are specified by the instructions for the controller, to comply with the UL Listing of the controller. See [Chapter 12](#) for available catalog numbers.

EMI Filter (Bulletin 284E Controller Only)

The EMI filter is required to be CE compliant. The filter must only be used in installations with solidly grounded wye AC supply distribution and must be bonded to the power distribution ground. The shielded motor cable is ordered separately. Use the Rockwell Automation power media and cable assemblies that are specified by the instructions for the controller, to comply with the UL Listing of the controller. See [Chapter 12](#) for available catalog numbers.

Dynamic Brake Connector (Bulletin 284E Controller Only)

The DB1 provides the quick disconnect connector and an internal resistor-monitoring circuit. The IP67 Dynamic Brake Resistor design offers simplicity in wiring and installation. The IP67 Dynamic Brake is separately ordered. See [Chapter 11](#) for available IP67 Dynamic Brake Resistors.

Note: The IP67 Dynamic Brake Resistor is used only with the **-DB1** factory-installed option. Only the specified IP67 Dynamic Brake Resistor can be used based on the VFD horsepower. If non-specified connecting resistors are used, a DB1 fault occurs.

Safety Output Contactor

The safety controller version includes two internal safety contactors in series. The 1732ES Safety I/O module controls and monitors these contactors.

Note: There is no LED indication on the ArmorStart controller for the status of these contactors. The status can be seen from the LEDs on the 1732ES Safety I/O module.

ArmorStart ST Controller Features

Figure 11 - Bulletin 281E ArmorStart ST Direct Online and Reversing (DOLR) Starter





Figure 12 - Bulletin 284E ArmorStart ST DOLR Starter



ArmorStart ST Controller - Safety Features

Figure 13 - Bulletin 281E ArmorStart ST - Safety Starter





Figure 14 - Bulletin 284E ArmorStart ST - Safety Starter



Notes:

Installation, Wiring, and Maintenance

Receiving

You are responsible to thoroughly inspect the equipment before accepting the shipment from the freight company. Check the items that are received against the purchase order. If any items are damaged, it is your responsibility not to accept delivery until the freight agent has noted the damage on the freight bill. If any concealed damage is found during unpacking, it is again your responsibility to notify the freight agent. Leave the shipping container intact and request the freight agent to make a visual inspection of the equipment.

Unpacking

Remove all packing material, wedges, or braces from within and around the ArmorStart distributed motor controller. Remove all packing material from the device or devices. Check the contents of the package. Contact your local Allen-Bradley representative if any items are missing.

IMPORTANT Before the installation and start-up of the drive, a general inspection of mechanical integrity (for example: loose parts, wires, connections, packing materials, and so on) must be made.

Inspecting

After unpacking, check the items nameplate catalog numbers against the purchase order. See [Chapter 1](#) for an explanation of the catalog number system that aids in nameplate interpretation.

Storing

The controller must remain in its shipping container before installation. If the equipment will not be used for some time, it must be stored according to the following instructions to maintain warranty coverage.

- Store in a clean, dry location.
- Store within an ambient temperature range of $-25...+85$ °C ($-13...+185$ °F).
- Store within a relative humidity range of 0...95%, noncondensing.
- Do not store equipment where it can be exposed to a corrosive atmosphere.
- Do not store equipment in a construction area.

General Precautions

In addition to the precautions listed throughout this manual, the following statements, which are general to the system, must be read and understood.



SHOCK HAZARD: Risk of electrical shock. Do not disconnect or connect power cables under load.



ATTENTION: Total circuit impedance must be low enough to confirm that any short circuit or ground fault current is large enough to operate the fuse or circuit breaker. Failure to comply can result in death, personal injury, and/or equipment damage.



ATTENTION: The controller contains ESD (electrostatic discharge) sensitive parts and assemblies. Static control precautions are required for install, test, service, or repair of the assembly. Component damage can result if ESD control procedures are not followed. If you are not familiar with static control procedures, see Guarding Against Electrostatic Discharge, publication [8000-4.5.2](#), or any other applicable ESD protection handbooks.



ATTENTION: An incorrectly applied or installed controller can damage components or reduce product life. Wiring or application errors, such as undersizing the motor, incorrect or inadequate AC supply, or excessive ambient temperatures, can result in malfunction of the system.



ATTENTION: Only personnel familiar with the controller and associated machinery can plan or implement the installation, startup, and subsequent maintenance of the system. Failure to follow this step can result in personal injury and/or equipment damage.



ATTENTION: To avoid electrical shock, open the disconnect switch before you connect and disconnect cables. Risk of shock – environment rating cannot be maintained with open receptacles.

Precautions for Bulletin 284E Applications



WARNING: The drive contains high-voltage capacitors that take time to discharge after removal of mains supply. Before working on a drive, verify isolation of mains supply from line inputs (R, S, T [L1, L2, L3]). Wait 3 minutes for capacitors to discharge to reasonable voltage levels. Failure to do so can result in personal injury or death.

Darkened display LED status indicators are not an indication that capacitors have discharged to reasonable voltage levels. Risk of shock – environment rating cannot be maintained with open receptacles.



ATTENTION: Only qualified personnel familiar with adjustable frequency AC drives and associated machinery can plan or implement the installation, startup, and subsequent maintenance of the system. Failure to follow this step can result in personal injury and/or equipment damage.

Bulletin 281E ArmorStart Controller Connections and Dimensions

Dimensions are shown in millimeters (inches). Dimensions are not intended to be used for manufacturing purposes. All dimensions are subject to change.

Figure 15 - Terminal Designations and Dimensions for Bulletin 281E Controller (RRG Option)










Figure 16 - Bulletin 281E ArmorStart ST Controller Internal Wiring



Bulletin 284E ArmorStart Controller Connections and Dimensions

Dimensions are shown in millimeters (inches). Dimensions are not intended to be used for manufacturing purposes. All dimensions are subject to change.

Figure 17 - Terminal Designations and Dimensions for Bulletin 284E Controller (RRG Option)






Figure 18 - Bulletin 284E ArmorStart ST Controller Internal Wiring



Mount Orientation

The recommended mounting orientation of ArmorStart ST controller is the vertical configuration. This orientation is especially important for the Bulletin 284. It lets proper airflow over the heat sink. Improper mounting or debris buildup reduces airflow and increases internal temperatures. This improper mounting can reduce the overall life of the product. For alternate mounting, contact your local sales representative.



IMPORTANT For proper heat dissipation and product operation, mount in the vertical orientation as shown.

ArmorConnect Power Media **Description**

Details of ArmorConnect power media are described in the ArmorConnect Power and Control Media Selection Guide, publication [280PWR-SG001](#).

The ArmorConnect power media offers both three-phase and control power cable cord set systems including patchcords, receptacles, tees, reducers and accessories to be used with the ArmorStart distributed motor controller. These cable system components let quick connection of ArmorStart controllers, reducing installation time. They provide for repeatable, consistent connection of the three-phase and control power to the ArmorStart controller and motor by providing a plug-and-play environment that also avoids system mis-wiring.

IMPORTANT ArmorConnect connections must be hand tight. See the ArmorConnect instructions for the recommended tightening torque. The use of a tool to help in the tightening of the connector is not recommended.

To specify power media for use with the ArmorStart distributed motor controllers, use only motor and power cables that are listed for use with ArmorStart controllers.

IMPORTANT The UL Listing of the ArmorStart controller requires its mating output motor and input power cable assemblies to be only those assemblies that are specified by the instructions for the controller. By using other cable assemblies, you violate the Listing of the controller, which NFPA 79 prohibits (see 1.5 of NFPA 79 and 110.3(B) of NFPA 70 (NEC)).




SHOCK HAZARD: Risk of electrical shock. Do not disconnect or connect power cables under load.



ATTENTION: ArmorConnect cables are not intended to be connected or disconnected under load. If this task is done, it can result physical injury or equipment damage as a result of high make and break currents and potential fault currents.

The following shows example configurations for power, control, and communication media.

Figure 19 - Cable System Overview



- ❶ CAT5e Bulkhead Connector and Receptacle – Example **Cat.No. 1585A-DD4JD**
- ❷ CAT5e Patchcord, IP67, M12 D-Code, Male Straight, Male Right Angle – Example **Cat.No. 1585D-M4TBDE-***
- ❸ CAT5e, Patch Cable, IP20, RJ45 Male to RJ45 Male – Example **Cat.No. 1585J-M4TB-***
- ❹ Three-phase Power Receptacles - Female receptacles are a panel mount connector with flying leads – Example **Cat. No. 280-M35F-M1**
- ❺ Three-phase Power Trunk- Patchcord cable with integral female or male connector on each end – Example **Cat. No. 280-PWR35A-M***
- ❻ Three-phase Motor Cable - Example **Cat. Nos. 284-PWRM29A-M3 or 280-PWRM29A-M3**
- ❼ Three-phase Power Tee connects to a single M35 drop line to trunk connectors – **Cat. No. 280-T35**
- ❽ Control Power Receptacles - Female receptacles are a panel mount connector with flying leads – **Cat. No. 888N-D4AF1-1F**
- ❾ Control/Auxiliary Power Media Patchcords – Patchcord cable with integral female or male connector on each end – Example **Cat. No. 889N-F4AFNM-***
- ❿ Control/Auxiliary Power Tees - The Tee is used with cordset or patchcord to connect several ArmorStart ST controllers to the same control power source. – Example **Cat. No. 898N-43PB-N4KT**

Control Power

The ArmorStart ST controller uses 24V DC control power for communications and I/O. Switched power supplies the outputs. Unswitched power supplies logic power and sensor inputs.

24V DC Control Power

- A1 = Switched +V
- A2 = Common for both switched and unswitched (-V)
- A3 = Unswitched +V

Input and Output Characteristics

- 5-pin female connectors (M12)
- Four fixed inputs (two per connector) – software selectable sink or source
- Two sourcing outputs DC (solid-state) – (one per connector)

Input and Output Power Connection

- Sensor Power is sourced from +24V supplied from A3(+) and A2(-).
- Output power is sourced from +24V supplied from A1(+) and A2(-).
- Max. current per output point is 0.5 A and is not to exceed 1.0 A total

IMPORTANT There is an instantaneous capacitive inrush for less than 10 ms, which can exceed 20 A. The power supply must be able to support this amount of instant power demand when multiple ArmorStart controllers are turned ON simultaneously. For supplies without this capacity, we recommend applying unswitched power (A3-A2) first and after a 2...4 second delay, apply switched power. If control power falls below 19V DC, there is a higher risk of communications issues or device faults.

AC Supply Considerations for Bulletin 284E Units

Ungrounded and High Resistive Distribution Systems



ATTENTION: The Bulletin 284E controller contains protective Metal Oxide Varistors (MOVs) that are referenced to a ground. These devices must not be disconnected or installed on an ungrounded and high resistive distribution system.

IMPORTANT Do not apply the EMI filter option to grounded or ungrounded delta power source. The EMI option requires a solidly grounded wye (Y) power source (for example, 480/277 or 400/230V AC, 3-phase power source). If applied to a grounded or ungrounded 480V AC delta power source, abnormal ground currents will be detected and cause the EMI filter to be damaged.

Group Motor Installations for USA and Canada Markets

The ArmorStart distributed motor controllers are listed for use in group installations per National Fire Protection Association (NFPA) 79, Electrical Standard for Industrial Machinery. When applied according to the group motor installation requirements, two or more motors, of any rating or controller type, are permitted on a single branch circuit. Group motor installation has been successfully used for many years in the USA and Canada.

Note: For additional information about group motor installations with the ArmorStart distributed motor controller, see [Appendix A](#).

Wiring and Workmanship Guidelines

In addition to conduit and seal-tite raceway, it is acceptable to use cable that is rated Tray Cable Exposed Runs (TC-ER), for power and control wiring on ArmorStart installations. The National Electrical Code (NEC) and NFPA 79 outline the following guidance for installations in the USA and Canada.

In industrial establishments where the conditions of maintenance and supervision verify that only qualified persons service the installation, and where the exposed cable is continuously supported and protected against physical damage, by using mechanical protection, such as struts, angles, or channels, Type TC tray cable that complies with the crush and impact requirements of Type MC (Metal Clad) cable and is identified for such use with the marking Type TC-ER (Exposed Run)⁽¹⁾ shall be permitted between a cable tray and the utilization equipment or device as open wiring. The cable shall be secured at intervals not exceeding 1.8 m (6 ft) and installed in a “good workman-like” manner. Equipment grounding for the utilization equipment shall be provided by an equipment grounding conductor within the cable.

(1) Historically, cable that meets these crush and impact requirements was designated and marked “Open Wiring”. Cable so marked is equivalent to the present Type TC-ER and can be used.

While the ArmorStart controller is intended for installation in factory floor environments of industrial establishments, the following must be considered when locating the ArmorStart controller in the application:

- Cables that include control voltage cables, for example, 24V DC and communications, are not to be exposed to operator or building traffic on a continuous basis.
- Location of the ArmorStart controller to minimize exposure to continual traffic is recommended. If location to minimize traffic flow is unavoidable, other barriers to minimize inadvertent exposure to the cabling must be considered.
- Cables must be routed to minimize inadvertent exposure and/or damage.
- If conduit or other raceways are not used, we recommend that strain relief fittings be used when installing the cables for the control and power wiring through the conduit openings.

The ArmorStart controller or control module is meant to be disconnected and replaced after proper lockout/tagout procedures have been employed.

Other System Design Considerations

3-phase power cabling must be kept at least 150 mm (6 in.) away from the EtherNet/IP network to avoid noise issues. EtherNet/IP is an unpowered network therefore, if device status is important when the power distribution disconnect is in the OFF position, the A3 terminal must have an unswitched power source.

Electromagnetic Compatibility (EMC)

The following guidelines are provided for EMC installation compliance.

General Notes (Bulletin 284E Controller Only)

- The motor cable must be kept as short as possible to avoid electromagnetic emission and also capacitive currents.
- Conformity of the drive with CE EMC requirements does not short circuit that an entire machine installation complies with CE EMC requirements. Many factors can influence total machine/installation compliance.
- By using an EMI filter with any drive rating, you can achieve relatively high ground leakage currents. Therefore, the filter must only be used in installations that are solidly grounded (bonded) to the building power distribution ground. Grounding must not rely on flexible cables and must exclude any form of plug or socket that would permit inadvertent disconnection. Some local codes can require redundant ground connections. The integrity of all connections must be periodically checked.
- When using a shielded motor cable, the drain wire must be bonded to chassis ground at the motor. The recommended motor connection must use a shielded concentric connector. This connection provides 360° shielding.

Wiring

Wire in an industrial control application can be divided into three groups: power, control, and signal. The following recommendations for physical separation between these groups, are provided to reduce the coupling effect:

- Minimum spacing between different wire groups in the same tray must be 16 cm (6 in.).
- Wire runs outside an enclosure must be run in conduit or have shielding/armor with equivalent attenuation.
- Different wire groups must be run in separate conduits.
- Minimum spacing between conduits that contain different wire groups must be 8 cm (3 in.).

Grounding

An effectively grounded product is one that is “intentionally connected to earth through a ground connection or connections of sufficiently low impedance and having sufficient current-carrying capacity to prevent the buildup of voltages that can result in undue hazard to connected equipment or to persons” (as defined by the US National Electric Code NFPA70, Article 100B). Grounding is done for two basic reasons: safety (defined above) and noise containment or reduction. While the safety ground scheme and the noise current return circuit can sometimes share the same path and components, they must be considered different circuits with different requirements.

Grounding Safety Grounds

The object of safety grounding is to verify that all metalwork is at the same ground (or Earth) potential at power frequencies. Impedance between the drive and the building scheme ground, must conform to the requirements of national and local industrial safety regulations or electrical codes. These requirements vary based on country, type of distribution system, and other factors. Periodically check the integrity of all ground connections.

General safety dictates that all metal parts are connected to earth with separate copper wire or wires of the appropriate gauge. Most equipment has specific provisions to connect a safety ground or PE (protective earth) directly to it.

Grounding PE or Ground

The safety ground - PE, must be connected to earth ground. This ground point must be connected to adjacent building steel (girder, joist), a floor ground rod, bus bar, or building ground grid. Grounding points must comply with national and local industrial safety regulations or electrical codes. Some codes can require redundant ground paths and periodic examination of connection integrity.

IMPORTANT To avoid electrolytic corrosion on the external earth terminal, avoid the spraying of moisture directly on the terminal. When used in washdown environments apply a sealant or other corrosion inhibitor on the external ground terminal to minimize any negative effects of galvanic or electrochemical corrosion. Ground connections must be inspected regularly.

Shield and Grounding of Motors and Motor Cables

The motor frame or stator core must be connected directly to the PE connection with a separate ground conductor. We recommend that each motor frame is grounded to building steel at the motor.

Motor Cable Considerations

Most recommendations about motor cable address issues come from the nature of the drive output. A PWM drive creates AC motor current by sending DC voltage pulses to the motor in a specific pattern. These pulses affect the wire insulation and can be a source of electrical noise. The rise time, amplitude, and frequency of these pulses must be considered when choosing a wire/cable type. The choice of cable must consider:

1. The effects of the drive output once the cable is installed
2. The need for the cable to contain drive output noise
3. The amount of cable-charging current available from the drive
4. Possible voltage drop (and subsequent loss of torque) for long wire runs

Keep the motor cable lengths less than 13.7 m (45 ft) unless otherwise noted in the device specifications.

Unshielded Cable


The use of cables without shielding is generally acceptable for installations where drive-created electrical noise does not interfere with the operation of other devices such as: communication cards, photoelectric switches, weigh scales, and others. Be certain the installation does not require shielded cable to meet specific EMC standards for CE, C-Tick, or FCC. Cable specifications depend on the installation type.



ATTENTION: Shielded motor cable is mandatory for CE-compliant installations

ArmorConnect Connections **Control Power Overview — 4-pin Auxiliary Power**

Figure 20 - ArmorConnect Receptacles - Standard Version Gland



Factory-installed ArmorConnect gland plate and terminal connections

Figure 21 - Internal ArmorConnect Connections (for Reference)
Standard Version




Table 2 - ArmorConnect Gland Plate Conductor Color Code

Terminal Designations	Description	Color Code
A1 (+)	Control Power Input	Brown
A2 (-)	Control Power Common	Blue
A3 (+)	Unswitched Control Power	White
PE	Ground	Green/Yellow
1/L1	Line Power – Phase A	Black
2/L2	Line Power – Phase B	White
3/L3	Line Power – Phase C	Red

ArmorConnect Cable Ratings

The ArmorConnect power media cables are rated per UL Type TC 600V 90 °C Dry 75 °C Wet, Exposed Run (ER) or MTW 600V 90 °C or ST00W 105 °C 600V - Canadian Standards Association (CSA) ST00W 600V FT2. For additional information regarding ArmorConnect power media see ArmorConnect Power and Control Media Selection Guide, publication [280PWR-SG001](#).

Power cable assemblies and associated wiring devices are suitable for installation in motor groups in accordance with 7.2.10.4 of NFPA 79.

Branch Circuit Protection Requirements for ArmorConnect Three-Phase Power Media When Used with ArmorStart Controllers

When using ArmorConnect three-phase power media with the ArmorStart ST controller, fuses or circuit breakers can be used for the motor branch circuit protective device, for the group motor installations.

For rated ArmorConnect motor cable assemblies:

Circuit Breaker: Suitable for use on a circuit capable of delivering not more than 30 000 rms symmetrical amperes at 480V AC maximum, when protected by a catalog number 140G-H6C3-C60 circuit breaker with a maximum ampere rating of 60 A and an interrupting rating not less than of 65 000 rms symmetrical amperes, 480V.

Fuses: Suitable for use on a circuit capable of delivering not more than 30 000 rms symmetrical amperes at 480V AC maximum when protected by Class CC, J, or T fuses, with a maximum ampere rating of 60 A.




WARNING: The total circuit impedance including the impedance of each cable assembly, must be low enough to confirm that any short circuit or ground fault current that can flow through any assembly, is large enough to operate the magnetic trip of the circuit breaker. See your local electrical code for acceptable practices for this evaluation.

Ethernet and I/O Connections **Note:** Pinouts are based on view into the connector.


The ArmorStart ST controller uses a sealed D-coded M12 (micro) style Ethernet connector.

Figure 22 - EtherNet/IP Connector (M12) - Female




- Pin 1 - (White/Orange) TxData+
- Pin 2 - (White/Green) RecV Data+
- Pin 3 - (Orange) TxData-

Figure 23 - I/O Receptacle Input Pinout (M12) - Female



- Pin 1 - +24V (A3 pwr)
- Pin 2 - Input 1
- Pin 3 - Common
- Pin 4 - Input 2
- Pin 5 - NC (no connection)


Figure 24 - I/O Receptacle Output Pinout (M12) - Female



- Pin 1 - NC (no connection)
- Pin 2 - NC (no connection)
- Pin 3 - Common
- Pin 4 - Output +24V DC (A1 pwr)
- Pin 5 - NC (no connection)


Power Connections

Figure 25 - Motor Connector Pinout (M29) - Female




- Pin 1 - T1 (black)
- Pin 2 - T2 (white)
- Pin 3 - T3 (red)
- Pin 4 - Ground (green/yellow)

Figure 26 - EM Brake Contactor Connector (M22) - Female




Pin 1 - Ground (green/yellow)
Pin 2 - B1 (black)
Pin 3 - B2 (white)

Figure 27 - Dynamic Brake Connection (M22) - Female




Pin 1 - Ground (green/yellow)
Pin 2 - BR+ (black)
Pin 3 - BR- (white)

Figure 28 - Incoming Control Power (M22) – 24V DC Only - Male



Pin 1 - 24V DC switched (brown)
Pin 2 - 24V DC unswitched (white)
Pin 3 - Common unswitched (blue)
Pin 4 - Common switched (blue)

Figure 29 - Incoming Three-phase Power (M35) - Male



Pin 1 - L1 (black)
Pin 2 - Ground (green/yellow)
Pin 3 - L3 (red)
Pin 4 - L2 (white)

Maintenance

The ArmorStart ST controller does not require regular maintenance. When using ArmorConnect media or conductors, verify that the connections remain tight where exposed to shock and vibration. Check that the heatsink has good airflow. Bulletin 284 includes an internal circulating fan to support heat conduction in high ambient applications. This fan operates when control power is applied and cannot be controlled by any other means. Monitor the fan speed to receive early warning of fan failure. If the fan rpm falls below 1740, a Hardware Fault F14 is generated. Also in parameter 61, Last Pr Fault indicates a FAN RPM fault has occurred.

IMPORTANT The FAN RPM fault reset function is modified to allow normal operation for 24 hours before the fault reoccurs. The replacement fan is PN 284-FAN. Refer to [Hardware Fault - Fan RPM Warning on page 226](#) for information regarding the monitoring of the Fan RPM.

Notes:

Functional Safety

Bulletin 281E Safety Version ArmorStart ST Controller Connections and Dimensions

Dimensions are shown in millimeters (inches). Dimensions are not intended to be used for manufacturing purposes. All dimensions are subject to change.

Figure 30 - Terminal Designations and Dimensions for Bulletin 281E Safety Version Controller (RRG Option)







Figure 31 - Bulletin 281E Safety Version ArmorStart ST Controller Internal Wiring



Bulletin 284E Safety Version ArmorStart ST Controller Connections and Dimensions

Dimensions are shown in millimeters (inches). Dimensions are not intended to be used for manufacturing purposes. All dimensions are subject to change.

Figure 32 - Terminal Designations and Dimensions for Bulletin 284E Safety Version Controller (RRG Option)



DETAIL A





Figure 33 - Bulletin 284E Safety Version ArmorStart ST Controller Internal Wiring





Figure 34 - Safety Cable System Overview



- ❶ CAT5e Bulkhead Connector and Receptacle – Example **Cat.No. 1585A-DD4JD**
- ❷ CAT5e Patchcord, IP67, M12 D-Code, Male Straight, Male Right Angle – Example **Cat.No. 1585D-M4TBDE-***
- ❸ CAT5e, Patch Cable, IP20, RJ45 Male to RJ45 Male – Example **Cat.No. 1585J-M4TB-***
- ❹ Three-phase Power Receptacles - Female receptacles are a panel mount connector with flying leads – Example **Cat. No. 280-M35F-M1**
- ❺ Three-phase Power Trunk- Patchcord cable with integral female or male connector on each end – Example **Cat. No. 280-PWR35A-M***
- ❻ Three-phase Motor Cable - Example **Cat. Nos. 284-PWRM29A-M3 or 280-PWRM29A-M3**
- ❼ Three-phase Power Tee connects to a single M35 drop line to trunk connectors – **Cat. No. 280-T35**
- ❽ Control Power Receptacles - Female receptacles are a panel mount connector with flying leads – **Cat. No. 888N-D4AF1-1F**
- ❾ Control/Auxiliary Power Media Patchcords – Patchcord cable with integral female or male connector on each end – Example **Cat. No. 889N-F4AFNM-***
- ❿ Control/Auxiliary Power Tees - The Tee is used with a cordset or patchcord to connect several ArmorStart ST controllers to the same control power source.– Example **Cat. No. 898N-43PB-N4KT**
- ⓫ Patch cable between Safety I/O module input and ArmorStart connector labeled "SM" and "P/M". This cable provides status and control feedback to the safety system. – Example **Cat. No. 889D-F4AEDM-***

Safety Wiring

Safety I/O Module and TÜV Requirements

Each ArmorStart ST safety distributed motor controller is intended to be combined with the 1732ES-IB12XOBV2 or 1732ES-IB8XOBV4 safety I/O module to form a subsystem that is part of the overall machine stop function. The motor controllers are connected to the safety I/O module through specified cable assemblies. The combination of one of these controllers, the safety module, and the specified interconnecting cables are referred to as the ArmorStart safety-related parts. The part numbers for each of these components is specified in the following table. The safety I/O module and PLC program must be configured as outlined. See configuration of Safety I/O Module and PLC program.





Table 3 - Safety-related Parts

Catalog Number	Description
281...S*	Bulletin 281 distributed motor controller – controller is full-voltage, reverse start
* - denotes safety version of Bulletin 281 controller	
284...S*	Bulletin 284 distributed motor controller – controller is variable-frequency AC drive
* - denotes safety version of Bulletin 284 controller	
1732ES-IB12XOBV2 or 1732ES-IB8XOBV4	Guard I/O EtherNet/IP Safety Module
889D-F4HJDM-*, 889D-F4AEDM-* or equivalent	SM cable assembly - Interconnecting cable assembly between safety module input and ArmorStart controller connector labeled "SI". Assembly provides contactor position feedback.
* - denotes length	P/M cable assembly - Interconnecting cable assembly between safety module output and ArmorStart controller connector labeled "SO". Assembly provides output contactor coil power.

ArmorBlock Guard I/O Modules

	Description	Cat. No.
	<p>The ArmorBlock I/O family provides a low-cost, hardened, digital I/O product suitable for On-Machine™ use. Water- and corrosion-proof, it can mount anywhere on a machine, so OEMs and end-users reduce installation and operating costs. ArmorBlock® Guard I/O™ is available in 16-point combined input and output versions, for use with your choice of safety input and actuator devices. This module supports multi-cast and unicast for user flexibility, and features embedded EtherNet/IP that enables flexibility in choice of topographies.</p>	<p>1732ES-IB12X0BV2 - 24V DC, 12 Input/ 2 Bipolar Pair Out, EtherNet/IP Safety</p> <hr/> <p>1732ES-IB8X0BV4 - 24V DC, 8 Input/ 4 Bipolar Pair Out, EtherNet/IP Safety</p>




ArmorBlock Guard I/O Recommended Cables and Connectors

Micro Cables

Description	Cat. No.
 DC Micro (M12) Male Cordset	889D-F4HJ ⁽¹⁾
 DC Micro Style Patchcord	889D-F4HJDM ⁽¹⁾

(1) Replace symbol with 1 (1 m [3.3 ft]), 2 (2 m [6.6 ft]), 5 (5 m [16.4 ft]), or 10 (10 m [32.8 ft]) for standard cable length.

Safety I/O Connector Pin Assignments

Face View Pinout				Female 
Input Configuration		Output Configuration		
Pin	Signal	Pin	Signal	
1	Test Output n+1	1	Output +24V DC Power	
2	Safe Input n+1	2	Output n+1 (sinking)	
3	Input Common	3	Output Power Common	
4	Safe Input n	4	Output n (sourcing)	
5	Test Output n	5	Output Power Common	

Note: ArmorStart 284E and 281E safety version controllers use "Test output N+1" and "Safe Inputs N+1"

Safety Function Definition

Safety-related stop functions in machines are capable of Cat. 4/PL e according to EN ISO 13849-1 and SIL 3 according to EN 62061/IEC 61508. The stop function that is provided conforms to IEC 60204-1:2006 Category 0.

Limitations of the Safety-related Parts

You must provide other components to implement the safety function: A Bulletin 1756 GuardLogix® programmable controller or equivalent that is equipped with EtherNet/IP CIP Safety™ communication capability and the proper media for connection.

The programmable controller must execute logic to process the "SI" feedback and command the safety output contactor open. This logic results in a Category 0 stop at the motor where the ArmorStart controller is connected. See configuration of safety I/O module and Safety PLC Program.


Safety Configuration

Catalog Number 1732ES-IB12X0BV2 or 1732ES-IB8X0BV4 Safety I/O Module and PLC Program

Configure the 1732ES-* as follows:

Configure the output that is connected to the I/O output cable assembly for:


- Dual (bipolar mode)
- Safety Pulse Test



Configure the input that is connected to the I/O Input cable assembly as follows:

- Channel Type = Single
- Point Mode = Safety Pulse Test Input from Test Source X
- Source = Pulsed output from X

Note: Input must be n+1, for example: 1, 3, 5, 7.



ArmorStart ST Controller - No Special Configuration Is Required

Safety PLC Program:

- Before applying output power from the drive, check the safety feedback status of SI (SM1/SM2) from the Safety I/O block. SI are the normally closed auxiliary contact signals from each contactor. When there is no demand on the safety system, a properly configured program and cable connection shows an input signal.
- The program must force the output contactors to the open state when a safety-related stop is demanded (Turn 1732ES Output X OFF).
- Read the safety feedback 100 milliseconds later, which can be improved based on program scan time. A properly configured program and connection shows the SI signal off.
- 1732ES Output X must remain OFF if the SI feedback is 0 after the safety function is demanded. This setting tests the safety-related parts. If SI is 0 after a safety function is demanded, there can be a faulty component. (see Note 1 and Note 2)

Note 1: The program must inhibit the contactor closure to satisfy Category 4 of EN ISO 13849-1.

Note 2: The SM feedback logic must be implemented only after the safety function is demanded. It must be ignored during normal operation. One of the series contactors is used for the normal stop/start function for these controllers. Therefore, a malfunctioning output contactor cannot be distinguished from a normal running state.

There is no visual LED that indicates the status of the internal ArmorStart ST safety contactors. This indication is found on the 1732ES via LED or via the network I/O module status. But a Message instruction can be used to inspect the status of ArmorStart P/M signal over the network by using the following Class-Instance-Attribute.

- Verify 284E wiring P/M to 1732ES over the Network
- Create a [MSG] instruction in Logix with the following:
 - Service Code of Get Single
 - Class 0x000F
 - Instance 113 [parameter 113]
 - Attribute 1
- Stop Input bit 2 is set "1" if both A1/A2 and P&M are active

If any of these tests fail, there is a safety system failure that **MUST IMMEDIATELY** de-energize the contactors via SO (P/M) and trigger a Safety Fault Condition.

See Using Guardlocking Interlock Switch and Light Curtains with DeviceNet Guard I/O, publication [SAFETY-AT018](#), for programming examples.

Safety-related Specifications Component Response Time

Component	Response Time (ms)
1732ES-IB12XOBV2 or 1732ES-IB8XOBV4	See ArmorBlock Guard I/O DeviceNet Installation Instructions, publication 1732DS-IN001
Bulletin 281	20...57
Bulletin 284	8...17

Probability of a Dangerous Failure Per Hour and $MTTF_d$ for Uncontrolled Stop

ArmorStart Safety Controller That Is Used in Combination with ArmorStart Safety-related Parts	MTTF _d (Years)	Average Probability of a Dangerous Failure Per Hour (1/h)
Bulletin 281...	100	6.0E-9
Bulletin 284...	100	6.0E-9

Maintenance and Internal Part Replacement

The ArmorStart ST safety controllers do not have any internal maintenance procedures. See the 1732ES-IB12XOBV2 or 1732ES-IB8XOBV4 safety module documentation for maintenance requirements that pertain to it. We recommend that the operation of the 1732ES-IB12XOBV2 or 1732ES-IB8XOBV4 safety module and the ArmorStart output contactor circuits, be verified once per year by performing the contactor circuit verification procedure. The contactor circuit verification procedure must be performed on an ArmorStart Safety controller that has experienced an output short circuit fault before placing the controller back into service.

Contactor Circuit Verification Procedure

- Initiate a stop from the safety PLC to the 1732ES-IB12XOBV2 or 1732ES-IB8XOBV4
- Verify that the ArmorStart controller output motor voltage is removed.
- Verify the output contactor that is located in the ArmorStart controller has transitioned from closed to open by examining the related 1732ES input.

Troubleshooting

1732ES-IB12X0BV2 or 1732ES-IB8X0BV4 Safety Module

See 1732ES documentation for troubleshooting instructions.

ArmorStart ST - Safety Bulletin 281/284 Distributed Motor Controllers Safety Circuit Troubleshooting


Symptom	ArmorStart Controller LED Status Indication			Probable Cause	Recommended Action
	Power	Fault	Run		
Motor does not start	Off	Off	Off	<ol style="list-style-type: none"> The disconnect switch of the ArmorStart controller is open. 24V DC not supplied to A1 and A2 at A1/A2 connector because cable or connections are defective. Polarity is reversed. 	<ol style="list-style-type: none"> Check disconnect switch. Verify cable and connections. Verify positive voltage A3 to A2 and A1 to A2.
	Off	Flashing	Off	There is an ArmorStart controller fault, and power to A1 has been removed.	See ArmorStart Manual for controller fault.
	On	Off	Off	<p>After standard stop⁽¹⁾</p> <ol style="list-style-type: none"> The controller is not receiving a RUN command. <p>After safety stop⁽²⁾</p> <ol style="list-style-type: none"> The controller is not receiving a RUN command. SI cable connections (SM1, SM2) open. SI feedback is open inside control module. 1732ES-IB12X0BV2 or 1732ES-IB8X0BV4 is reporting open SM feedback from the IN0...INn inputs. 	<p>After standard stop⁽¹⁾</p> <ol style="list-style-type: none"> Check RUN command source. <p>After safety stop⁽²⁾</p> <ol style="list-style-type: none"> Check RUN command source. Check SI cable and connections. Check SI feedback inside control module. See I/O Indicators in 1732ES-IB12X0BV2 or 1732ES-IB8X0BV4 manual.
	On	Flashing	Off	ArmorStart controller fault is inhibiting ArmorStart controller start function.	See ArmorStart Manual for controller fault.
	On	Off	On	<ol style="list-style-type: none"> Three-phase power is not being supplied to controller (Bulletin 281 controllers). 24V DC not supplied to P and M at A1/A2 connector because cable or connections are defective. 1732ES-IB12X0BV2 or 1732ES-IB8X0BV4 OUT0...OUTn outputs are not supplying 24V DC to pins P and M. 	<ol style="list-style-type: none"> Verify 3-phase voltage at ArmorStart controller input. Verify cable and connections. See I/O Indicators in 1732ES-IB12X0BV2 or 1732ES-IB8X0BV4 manual.

(1) Standard stop – The 1732ES-IB12X0BV2 or 1732ES-IB8X0BV4 does not remove 24V DC from P and M when a standard stop is executed. The safety circuit does not inhibit a restart of the controller after a standard stop.

(2) Safety stop – The 1732ES-IB12X0BV2 or 1732ES-IB8X0BV4 removes 24V DC from P when a safety stop is executed. This action opens both contactors. A restart of the controller stop is inhibited if the SM feedback is open. The program in the safety controller does not let the 1732ES-IB12X0BV2 or 1732ES-IB8X0BV4 apply 24V DC to P and M in the cable.

ArmorConnect Connections Control Power Overview — 4-pin Auxiliary Power

Figure 35 - ArmorConnect Receptacles



Factory-installed ArmorConnect gland plate and terminal connections

Figure 36 - ArmorConnect Connections





Table 4 - ArmorConnect Gland Plate Conductor Color Code

Terminal Designations	Description	Color Code	
A1 (+)	Control Power Input	Brown	
A2 (-)	Control Power Common	Black/Blue	
A3 (+)	Unswitched Control Power	White	
PE	Ground	Green/Yellow	
1/L1	Line Power – Phase A	Black	
2/L2	Line Power – Phase B	White	
3/L3	Line Power – Phase C	Red	
SI	SM1	Safety Monitor Input	Brown
	SM2	Safety Monitor Input	White
SO	P	Safety Output	Blue
	M	Safety Output Common	Brown

I/O Connections


ArmorStart ST controller uses a sealed D-coded M12 (micro) style Ethernet connector.

Figure 37 - Safety Monitor (SM1/SM2) - Male



- Pin 1 - SM1 (brown)
- Pin 2 - SM2 (white)
- Pin 3 - NC (no connection) (blue)
- Pin 4 - NC (no connection) (black)

Figure 38 - Safety Output Power (P/M) - Male



- Pin 1 - NC (no connection) (brown)
- Pin 2 - M (white)
- Pin 3 - NC (no connection) (blue)
- Pin 4 - P (black)

Introduction to EtherNet/IP and Device Level Ring Technology

Terminology

See the table for the meaning of common terms.

This Term	Means
Consumer	A destination device in the CIP networking model. See CIP.
CSMA/CD	Carrier sense multiple access/collision detection (CSMA/CD) is the access method that is used in Ethernet. When a device wants to gain access to the network, it checks to see if the network is quiet (senses the carrier). If it is not, it waits a random amount of time before retrying. If the network is quiet and two devices access the line simultaneously, their signals collide. When the collision is detected, they both back off and each waits a random amount of time before retrying.
Determinism	The ability to predict when information is delivered. Important in time-critical applications.
DHCP	The Dynamic Host Configuration Protocol (DHCP) is an Internet Protocol, similar to BOOTP, for automating the configuration of computers that use TCP/IP. DHCP can be used to automatically assign IP addresses, to deliver IP stack configuration parameters, such as the subnet mask and default router, and to provide other configuration information, such as the addresses for printer, time, and news servers.
DNS	The domain name system (DNS) is a hierarchical, distributed method of organizing the name space of the Internet. The DNS administratively groups hosts into a hierarchy of authority that allows addressing and other information to be widely distributed and maintained. The DNS has a significant advantage because it does not need to rely on a centrally maintained file that maps host names to addresses.
Ethernet	A physical layer standard that uses carrier sense multiple access with collision detection (CSMA/CD) methods.
EtherNet/IP	Ethernet industrial protocol applies a Common Industrial Protocol (CIP) over Ethernet by encapsulating messages in TCP/UDP/IP.
Ethernet network	A local area network that is designed for the high-speed exchange of information between computers and related devices.
Explicit Messaging	Non-time critical messaging that is used for device configuration and data collection, such as program downloads or peer-to-peer messaging between two PLC units.
Full duplex	A mode of communication that lets a device send and receive information simultaneously, which effectively doubles the bandwidth.
Fully qualified domain name	A fully qualified domain name (FQDN) is a domain name that includes all higher-level domains relevant to the entity named. Think of the DNS as a tree-structure with each node having its own label. Then a fully qualified domain name for a specific node would be its label followed by the labels of all other nodes between it and the root of the tree. For example, for a host, an FQDN would include the string that identifies the particular host, plus all domains of which the host is a part, up to and including the top-level domain (the root domain is always null). For example, PARIS.NISC.SRI.COM is a fully qualified domain name for the host at 192.33.33.109.
Gateway	A module or set of modules that provides communications between nodes on dissimilar networks.
Hardware address	Each Ethernet device has a unique hardware address (sometimes called a MAC address) that is 48 bits. The address appears as six digits that are separated by colons (such as, xx:xx:xx:xx:xx:xx). Each digit has a value from 0 to 255 (0x00 to 0xFF). This address is assigned in the hardware and cannot be changed. The hardware address is required to identify the device if you are using a BOOTP utility.

This Term	Means
Host name	The host name is the unique name for a computer within its domain. It's always the first element of a full name, and, with its domain and top-level domain suffix, creates the unique name of that computer on the Internet. For example, let's say a trading website is www.trading.com. The host name is www, which is not unique on the web, but is unique within the trading domain. The host name can also see the fully qualified domain name (FQDN), or in this example, www.trading.com. Both naming methods seem to be used interchangeably in various documents. For the purposes of this document, the host name sees the FQDN, or as in this example, www.trading.com.
Hub	A central connecting device that joins devices together in a star configuration. Hubs are generally not suitable for use in I/O control systems, since they are time-critical applications that cannot tolerate lost packets.
Implicit messaging	Real-time messaging of I/O data.
IP	Internet Protocol (IP) that provides the routing mechanism for messages. All messages contain not only the address of the destination station, but also the address of a destination network, which lets messages get sent to multiple networks within an organization or around the world.
IP address	A 32-bit identification number for each node on an Internet Protocol network. These addresses are represented as four sets of 8-bit numbers (numbers from 0 to 255), with decimals between them. Each node on the network must have a unique IP address.
Latency	The time between the initiating of a request for data and the beginning of the actual data transfer.
Multicast	In the CIP Producer/Consumer model, one producer multicasts (broadcasts) the data once to all consumers.
Producer	The source of information in the CIP networking model. See CIP.
Subnet mask	An extension of the IP address that lets a site use a single net ID for multiple networks.
Switch	A network device that cross connects devices or network segments. A switch provides each sender/receiver the full network bandwidth (2x in full-duplex mode), reduces collisions, and increases determinism.
TCP	The Transport Control Protocol (TCP) is a more dependable but slower transport protocol than UDP. It is used for explicit (not time critical) messaging in EtherNet/IP.

Introduction to EtherNet/IP

Automation architectures must provide you with three primary services:

- Control services involve the exchange of time-critical data between controlling devices and I/O devices.
- Networks must provide you with configuration capabilities to build and maintain your automation systems.
- Automation architecture must provide for collection of data.

EtherNet/IP, provides installation flexibility and leverages commercially available industrial infrastructure products. It is also compatible with other communication standards, such as Hypertext Transfer Protocol (HTTP), Simple Networks Management Protocol (SNMP), and Dynamic Host Configuration (DHCP).

EtherNet/IP is a CIP adaptation of TCP/IP that fully uses the IEEE standard. The relationship between the TCP/IP and CIP to form EtherNet/IP is shown in the ISO/OSI 7-layer model is shown in [Figure 40](#). The OSI model is an ISO standard for network communications that define all functions from a physical layer to the protocol.

This diagram shows how Rockwell Automation EtherNet/IP communication modules fit into a control system.

Figure 39 - EtherNet/IP Communication Modules in a Control System





Figure 40 - OSI Model for ISO Standard for Network Communications




This approach provides real-time technology into the Ethernet domain. With the network extensions of CIP Safety, CIP Sync, and CIP Motion, CIP networks provide for safety communication, time synchronization, and simple-to-high performance motion all over the same EtherNet/IP network.

Linear Network Introduction


A linear network is a collection of devices that are daisy-chained together.

Figure 41 - Linear Network Collection of Devices



In this topology, a communication issue in the media or device helps stop nodes downstream from communicating.

Figure 42 - Communication Issue in the Media or Device Line



The EtherNet/IP embedded switch technology lets this topology be implemented at the device level. No additional switches are required.

The primary advantages of a linear network are:

- The network simplifies installation and reduces wiring and installation costs.
- The network requires no special software configuration.
- Embedded switch products offer improved CIP Sync application performance on linear networks.

The primary disadvantage of a linear network is that any break of the cable disconnects all devices downstream from the break from the rest of the network.


IMPORTANT Products with EtherNet/IP embedded switch technology have two ports to connect to a linear or DLR network in a single subnet.
You cannot use these ports as two Network Interface Cards (NICs) connected to two different subnets

Device Level Ring


Introduction

A Device Level Ring (DLR) protocol defines a set of behaviors, see [Figure 43](#). A ring supervisor keeps packets of information from circulating infinitely around the ring by blocking one of the ports. A beacon frame constantly is detected on both ring supervisor ports. If a beacon frame is not detected the supervisor detects the physical layer issue and reconfigures the network to a linear topology without the loss of any node communication or data. Once repaired the ring supervisor reconfigures back to ring mode.

Figure 43 - DLR Protocol



As shown in [Figure 44](#), when a physical layer failure is detected the adjacent nodes to the fault generate a link status message that the ring supervisor acknowledges. The ring supervisor unblocks the port to allow communication. The neighboring nodes to the fault identify the fault and reconfigure themselves to support a linear topology. Now, both the ring supervisor and nodes are configured to support a linear topology.

Figure 44 - Physical Layer Failure Is Detected

When the physical layer fault is corrected, the supervisor will “hear” the beacon frame again on both ports. Once the beacon frame is detected, the ring supervisor re-establishes and configures the ring topology. All neighboring nodes detect this update and reconfigure themselves back to ring. A DLR network is a single-fault tolerant network that is intended for the interconnection of automation devices.

At least one ring supervisor must be configured before a ring is formed.

IMPORTANT Any nodes that do not support DLR must not be directly connected to the ring.

The node must be connected to the ring through a switch that supports DLR.

The advantages of the DLR network include:

- Simple installation
- Resilience to a single point of failure on the network
- Fast recovery time when a single fault occurs on the network

The primary disadvantage of the DLR topology is the additional effort that is required to create and use the network as compared to a linear or star network.

IMPORTANT Products with EtherNet/IP embedded switch technology have two ports to connect to a linear or DLR network in a single subnet. You cannot use these ports as two Network Interface Cards (NICs) connected to two different subnets.

IMPORTANT ArmorStart EtherNet/IP cannot be configured as a ring supervisor.

Number of Nodes on a DLR Network

Rockwell Automation recommends that you use no more than 50 nodes on a single DLR or linear network. If your application requires more than 50 nodes, we recommend that the DLR networks are segmented.

With smaller networks:

- There is better management of traffic on the network.
- The networks are easier to maintain.
- There is a lower likelihood of multiple faults.

Additionally, on a DLR network with more than 50 nodes, network recovery times from faults are higher. For DLR networks with 50 or less nodes, ring recovery time can be as low as 3 ms. If more than 50 nodes are required without segmentation, contact your local Allen-Bradley distributor. A detail review is recommended to confirm that bandwidth and response time are within application requirements.

Ethernet Switches

Ethernet managed switches are key components that provide determinism and the required throughput to achieve automation needs. Switches are able to manage network traffic that reduces unnecessary delays or bandwidth needs. A properly designed EtherNet/IP infrastructure that implement segregation via managed switch technology achieves a more dependable and secure network.

Ethernet Media

Today, unshield twisted pair (UTP) wiring is the standard in most applications and provides for greatest flexibility and ease of installation and maintenance. Category 5e (e-enhanced) cable is specifically designed to meet automation needs of today.

Figure 45 - Network Media - Ethernet M12 D-Code Media



EtherNet/IP General Wiring Guideline

Ethernet is found in automation equipment, panels, and components. There are a few guidelines, that if followed, will reduce the number of issues an EtherNet/IP application may experience.

- Many EtherNet/IP applications share space with power conductors. If the Ethernet media must cross power conductors, do so at right angles. This configuration reduces the coupling effect and reduce the potential for communication noise.
- Where possible, route the EtherNet/IP media five feet or more from high-voltage sources (for example, lights, ballasts, motors, ...) or sources of radio frequency, such as variable frequency drives.
- Verify that the application or equipment follows industry acceptable grounding practices.
- Maintain media lengths between nodes to less than 100 m (328 ft). It can be challenging to maintain these guidelines, however these reduce potential application issues.


Requested Packet Interval

The Requested Packet Interval (RPI) is the update rate that is specified for a particular piece of data on the network. This value specifies how often to produce the data for that device. For example, if you specify an RPI of 50 ms, it means that every 50 ms the device must send data to the controller or the controller must send data to the device.


Only data-producing modules require an RPI. For example, a local EtherNet/IP communication module requires no RPI because it produces no data for the system. Instead it functions only as a bridge.

To set an RPI, follow these steps.


1. Verify the ArmorStart EtherNet/IP module AOP is installed, started, and connected to the controller.
2. In the Controller Organizer tree, right-click the ArmorStart EtherNet/IP module and choose Properties.



The Module Properties dialog box appears.



3. Click the Connection tab.



4. From the Requested Packet Interval (RPI) menu, enter the rate at which you want data to be updated over a connection.

Only set the RPI to the rate the application requires.

IMPORTANT The RPI determines the number of packets per second that the module produces on a connection. Each module can produce only a limited number of packets per second. Exceeding this limit helps stop the module from opening more connections.

5. Click OK.


Product Commissioning

IP Address

The IP address identifies each node on the IP network (or system of connected networks). Each TCP/IP node on a network must have a unique IP address.

The IP address is 32 bits long and has a net ID part and Host ID part. Networks are classified A, B, C, or other. The class of the network determines how an IP address is formatted.

Figure 46 - IP Address on the IP Network



You can distinguish the class of the IP address from the first integer in its dotted-decimal IP address as follows:

Range of First Integer	Class	Range of First Integer	Class
0...127	A	192...223	C
128...191	B	224...255	other

There are reserved values that you cannot use as the first octet in the address. These numbers are examples of values you cannot use:

- 001.xxx.xxx.xxx
- 127.xxx.xxx.xxx
- 223 to 255.xxx.xxx.xxx

The specific reserved values that cannot be used vary according to the conditions of each application. The previous values are only examples of reserved values.

Each node on the same physical network must have an IP address of the same class and must have the same net ID. Each node on the same network must have a different Host ID thus that gives it a unique IP address.

Gateway Address

A gateway connects individual physical networks into a system of networks. When a node must communicate with a node on another network, a gateway transfers the data between the two networks. This field is set to 192.168.1.1 by default, when the IP range is [192.168.1] 002...254.

Subnet Mask

Subnet addressing is an extension of the IP address scheme that lets a site use a single network ID for multiple physical networks. The routing outside of the site continues by dividing the IP address into a net ID and a host ID via the class. Inside a site, the subnet mask is used to redivide the IP address into a custom network ID portion and host ID portion. This field is set to 255.255.255.0 by default.

If you change the subnet mask of an already-configured module, you must cycle the power to the module for the change to take effect.

Configuring EtherNet/ IP Address

Before using the ArmorStart controller, you may need to configure an IP address, subnet mask, and optional Gateway address. The rotary network address switches found on the I/O section of the ArmorStart controller are set to 999 and DHCP is enabled as the factory default. The ArmorStart controller reads these switches first to determine if the switches are set to a valid IP address between 1...254. When switches are set to a valid number, then the IP address is 192.168.1._ _ _ [switch setting].

The IP address can also be set by using DHCP.

- If DHCP is preferred, use Rockwell Automation BootP/DHCP utility, version 2.3 or later, which ships with RSLogix 5000® or RSLinx software.
- Or use a third-party DHCP server.

This document assumes that you have set the IP address to 192.168.1.1. You can change this IP address to any address either statically or dynamically.



ATTENTION: To avoid unintended operation, the adapter must be assigned a fixed IP address. If a DHCP server is used, it must be configured to assign a fixed IP address for your adapter. Failure to observe this precaution can result in unintended machine motion or loss of process control.

Manually Configure the Network Address Switches

Remove the protective caps from the rotary switches. Set the network address by adjusting the three switches on the front of the I/O module.

Figure 47 - Switches on the I/O Module





Figure 48 - Network Address Example



Valid IP address switch settings range from 002 to 254. When the switches are set to a valid number, then the IP address of the adapter is 192.168.1.xxx (where xxx represents the number set on the switches; see [Figure 48](#)). The subnet mask of the adapter is 255.255.255.0 and the gateway address is set to 192.168.1.1. A power cycle is required for any new IP address to take effect.


Note: When the switches are set to 192.168.1.1, the subnet mask is set to 255.255.255.0 and the gateway address is set to 0.0.0.0.

Note: The upper three octets are fixed. DHCP or the embedded web server must be used to configure the IP address to a value other than 192.168.1.xxx.

If the switches are set to an invalid number (such as 000 or a value greater than 254), then the adapter checks to see if DHCP is enabled. If DHCP is enabled, the adapter requests an address from a DHCP server. If DHCP is not enabled, then the adapter uses the IP address (along with other TCP configurable parameters) stored in nonvolatile memory.

IMPORTANT See [Figure 49](#). The ArmorStart controller is shipped with the control module rotary switches set to a value of 99. **DO NOT modify this setting.** If these settings are changed, then the unit stops responding and the switches must be manually set to node address 63 and power cycled.

Figure 49 - Rotary Switch on Control Module



Rockwell Automation BootP/DHCP Utility

The Rockwell Automation BootP/DHCP utility is a standalone program that incorporates the functionality of standard BootP/DHCP software with a user-friendly graphical interface. It is located in the Utils directory on the RSLogix 5000 installation CD. The ArmorStart EtherNet/IP adapter must have DHCP enabled (factory default) to use the utility.


IMPORTANT ArmorStart EtherNet/IP does not support BOOTP.

To configure your adapter by using the BootP/DHCP utility, perform the following steps:

1. Run the BootP/DHCP software.

In the BootP/DHCP Request History panel, the hardware addresses of the devices that are issuing BootP/DHCP requests are shown.


Figure 50 - BootP/DHCP Request History Panel



2. Double-click the hardware address of the device that you want to configure.

The New Entry dialog with the Ethernet Address (MAC) of the device is shown.


Figure 51 - New Entry Dialog Box



3. Enter the IP address that you want to assign to the device, and click OK.

The device is added to the Relation List, which displays the Ethernet Address (MAC) and the corresponding IP address, host name, and Description (if applicable).

Figure 52 - Relation List



When the address displays in the IP address column in the Request History section, it signifies that the IP address assignment has been made.


4. To assign this configuration to the device, highlight the device in the Relation List panel, and click the Disable BOOTP/DHCP button.

When power is cycled to the device, it uses the configuration you assigned and does not issue a DHCP request.

5. To enable DHCP for a device with DHCP disabled, highlight the device in the Relation List, and click the Enable DHCP button.

You must have an entry for the device in the Relation List panel to re-enable DHCP.

Figure 53 - Enable DHCP Button




Save the Relation List

You can save the Relation List to use later. To save the Relation List, perform the following steps:


1. Select Save As... from the File menu.

Figure 54 - Save the Relation List



The Save As Dialog is shown.

Figure 55 - Save As Dialog Box



2. Select the folder that you want to Save in.
3. Enter a File name for the Relation List (for example, Control System Configuration), and click Save.

You can leave the Save as type at the default setting: BOOTP

You can then open the file that contains the Relation List at a later session.

DHCP IP Support

DHCP (Dynamic Host Configuration Protocol) software automatically assigns IP addresses to client stations logging on to a TCP/IP network.

When DHCP is enabled (factory default Enabled), then the unit requests its network configuration from a DHCP/BOOTP server. Any configuration that is received from a DHCP server is stored in nonvolatile memory.

ArmorStart EtherNet/IP remembers the last successful address if DHCP is enabled. The unit tries to obtain the same IP address from the DHCP server. If the server is not present (for example, server fails to power up), then the unit uses the IP address it previously received from the server. The DHCP timeout = 30 s.

Use caution when configuring your adapter with DHCP software. A DHCP server typically assigns a finite lease time to the offered IP address. When 50% of the leased time has expired, the ArmorStart Ethernet adapter attempts to renew its IP address with the DHCP server. The possibility exists that the adapter can be assigned a different IP address, which would cause the adapter to cease communicating with the controller.

Rockwell Automation Embedded Web Server

Internal Web Server

ArmorStart EtherNet/IP internal web server lets you view information and configure the ArmorStart controller via a web browser. The embedded web server is used to access configuration and status data. Security in the form of an administrative password can be set. The default Login is Administrator. **There is no password set by default.**

IMPORTANT You must set the password to a unique value for authorized personnel. If the login and password are lost, then you must reset the device to the factory defaults, which results in a loss of its configuration.

To access the internal web browser, open your computer's internet browser and enter the IP address of the desired ArmorStart controller (for example, 192.168.1.1).

Note: 192.168.1.1 is **NOT** the factory default IP address as DHCP is enabled by default.

Figure 56 - Internal Web Browser

The screenshot shows the internal web browser interface for an ArmorStart 284E PF40 480V 0.5HP controller. The interface includes a navigation menu on the left and a main content area with the following data:

Device Name	ArmorStart 284E PF40 480V 0.5HP
Device Description	
Device Location	
Ethernet Address (MAC)	00:00:BC:C1:90:17
IP Address	192.168.1.1
Product Revisions:	
ArmorStart 284E PF40 480V 0.5HP	1.001
Main Control Board	2.004
Boot Code	2.002
PowerFlex 40 3P 460V .50HP	6.001
ArmorStart 284E PF40 480V 0.5HP	66.004
EtherNet/IP Spot Code	1.001
EtherNet/IP FPGA Code	1.060
Firmware Version Date	Sep 17 2010, 15:36:28
Serial Number	A012069D
Status	Run
Uptime	0 days, 5h32m:51s

Additional features visible in the interface include a 'Resources' section with a link to 'Visit AB.com for additional information' and a 'Contacts' section. At the bottom, there is a 'Seconds Between Refresh' field set to 15 and a 'Disable Refresh with 0.' option. The footer contains the copyright notice: 'Copyright © 2010 Rockwell Automation, Inc. All Rights Reserved.'

From here, you are able to view parameter settings, device status, and diagnostics from multiple tab views.


Figure 57 - Multiple Tab Views



Network Configuration

To access the network configuration, log in to the Administrative Setting. The factory default login is Administrator. The factory default password is not used. You must change the password so unauthorized personnel do not gain access and modify the device configuration.

Figure 58 - Network Configurations




From this screen, you can change the Ethernet Configuration. In the example that is shown, the default IP address was changed from 192.168.1.1 to 10.10.10.101. To access the web page after a power cycle, the new address must be used.

It is also important to leave the Ethernet link configuration P1/P2 set to auto negotiate to minimize network issues. But if this configuration is not acceptable you must verify that all devices on the network are set to the same setting or network issues can result.

Parameter Configuration

ArmorStart EtherNet/IP embedded web server provides you the ability to view and modify the device configuration without having to access Studio 5000. To view the device configuration from the web server, select the Parameters folder. For the parameter configuration, you log in through the Administrative Settings, or when prompted.

Figure 59 - Starter Setup




In Figure 59, the Starter set-up parameters are viewed. You can view all parameters from this screen. To modify a parameter, click the “Edit” button.

Figure 60 - Enter Network Password



You are prompted to enter the default user name (Administrator). There is no password set by default. You are expected to change the user name (login) and password to avoid unauthorized access to the device configuration.

Figure 61 - Overload Class Settings




The example screen shows a change of the Overload Class setting to 15. Once all changes are made, select Apply.

Email Notification Configuration

ArmorStart EtherNet/IP internal web server supports the e-mailing of warning and trip messages via Simple Mail Transfer Protocol (SMTP). The configuration parameters for the IP address, user login, and port number of the SMTP Server, are configurable through the Administrative Settings page of the internal web server. You configure the device name, device description, and device trip type.

Figure 62 - Email Notification Configuration



Email triggers when a:

- Trip occurs
- Trip is cleared
- Warning occurs
- Warning is cleared

Note: “Cleared Event” e-mails are only sent when all events have been cleared and if a trip event email has previously been sent. For example, if the device is configured to send emails when a phase loss trip and an overload trip are detected, no email is sent when both the overload and the phase loss are cleared.

The following is an example trip email:

Subject: ArmorStart 281E, 0.5...2.5 A, 24V DC has detected a trip.

Body:

Trip Type: Overload

Trip Info: Load has drawn excessive current that is based on the trip class that is selected.

Device Name: ArmorStart 281E, 0.5...2.5 A, 24V DC
(From Identity Object)

Device Description: Lift conveyor On-Machine™ motor starter
(From email Config web page)

Device Location: Customer Plant
(From email Config web page)

Contact Info: J Customer
(From email Config web page)
j.customer@microsoft.com



Device Connections

The device supports both scheduled (Class 1) and unscheduled (Class 3 and UCMM) CIP connections. A maximum of two Class 1 CIP connections (one exclusive owner and one listen only) are supported, one per PLC. Six Class 3 CIP connections are supported.

Ownership

In a Studio 5000 system, modules multicast data. Therefore, multiple modules can receive the same data simultaneously from a single module. When choosing a communication format, decide whether to establish an owner-controller or listen-only relationship with the module.

Table 5 - Communication Relationship

Ownership Type	Description
Owner controller	<p>The controller that creates the primary configuration and communication connection to a module. The owner controller writes configuration data and can establish a connection to the module.</p> <p>An owner connection is any connection that does not include Listen-Only in its Comm Format.</p> 
Listen-only connection	<p>An I/O connection where another controller owns/provides the configuration data for the I/O module. A controller with a listen-only connection monitors only the module. It does not write configuration data and can only maintain a connection to the I/O module when the owner controller is actively controlling the I/O module.</p> <p>Listen-only connection</p> 

Ethernet Statistics Web Page

The Ethernet Statistics web page of a scanner provides a summary of the status of communication activity on the Ethernet network.

The most commonly monitored fields are circled in the graphic and described in the table that follows.



This table describes the field that is most commonly used on the Ethernet Statistics web page.

Table 6 - Ethernet Statistics Web Page


Field	Specifies
Ethernet Port 1 (These definitions apply to the same fields in the Ethernet Port 2 section.)	
Interface State	Whether the port is turned off or on. Active or inactive indicates whether there is a cable that is connected.
Link Status	Whether the port is blocked for DLR protocol frames.
Speed	Whether the Ethernet port is operating at 10 MBps or 100 MBps.
Duplex	Whether the Ethernet port is operating at half duplex or full duplex.
Autonegotiate Status	Whether the port speed and Duplex mode were determined via autonegotiation or whether they were manually configured.
Media Counters Port 1	
Alignment Errors	A frame containing bits that do not total an integral multiple of eight.
FCS Errors	A frame containing 8 bits, at least one of which has been corrupted.
Single Collisions	The number of outgoing packets that encountered only one collision during transmission.
Multiple Collisions	The number of outgoing packets that encountered 2...15 collisions during transmission.

Field	Specifies
SQE Test Errors	A test to detect the collision-present circuit between a transceiver and a network interface card (NIC). IMPORTANT: Because most NICs now have an integrated transceiver, the SQE test is unnecessary. Ignore this media counter.
Deferred Transmissions	The number of outgoing packets whose transmission is deferred because the network is busy when the first attempt is made to send them.
Late Collisions	The number of times two devices transmit data simultaneously.
Excessive Collisions	The number of frames that experience 16 consecutive collisions.
MAC Transmit Errors	Frames for which transmission fails due to an internal MAC sublayer transmit error.
Carrier Sense Errors	Times that the carrier sense condition was lost or never asserted when attempting to transmit a frame.
Frame Too Long	The number of incoming packets that exceed the maximum Ethernet packet size.
MAC Receive Errors	Frames for which reception on the Ethernet interface failed due to an internal MAC sublayer receive error.

Connection Manager Cmd Object Info Web Page

The Connection Manager Cmd Object Info web page of a scanner provides a summary of connection request activity on the Ethernet network.

The most commonly used field on this page is Connections Closed due to a Timeout. This field shows the number of CIP connection timeouts that have occurred on the module.




Ring Statistics Web Page

IMPORTANT The Ring Statistics web page, and the descriptions in this section, only apply to modules you can use in a Device Level Ring (DLR) network:

- 1756-EN2TR communication module
- 1756-EN3TR communication module

The Ring Statistics web page of a scanner provides a operating state summary of the module in a DLR application.

The most commonly monitored fields are circled in the graphic and described in the table that follows.



This table describes the field that is most commonly used on the Ring Statistics web page.

Table 7 - Ring Statistics Web Page


Field	Specifies
Ring Supervisor	
Ring Supervisor Mode	Whether a module is configured to function as supervisor node or a ring node.
Ring Supervisor Status	Whether a module that is configured to function as a supervisor node is functioning as the active ring supervisor or a backup supervisor node.
Ring Fault Location	
Last Active Node on Port 1	The IP or MAC ID address of the last active node between port 1 on the module and the faulted part of the network.
Last Active Node on Port 2	The IP or MAC ID address of the last active node between port 2 on the module and the faulted part of the network.
Active Ring Supervisor	
Address	The IP or MAC ID address of the active ring supervisor.
Precedence	The precedence value of the module. If the operation of the active supervisor node is interrupted, the backup supervisor with the next highest precedence value becomes the active supervisor node.

Adding an ArmorStart Selection to Studio 5000 Software


Setup

This section shows you how to add an ArmorStart AOP to Studio 5000 software. It is assumed that you have downloaded and installed the AOP so that the Studio 5000 software can fully support the ArmorStart EtherNet/IP. The AOP can be downloaded from: <http://support.rockwellautomation.com/controlflash/LogixProfiler.asp>.


1. Open Studio 5000 software by double-clicking the icon on your desktop.



2. To create a new project, select File > New.




3. Enter the name of the project and select your controller from the Type pull-down menu. (For this example, catalog number 1769-L35E and software version 19 are used.) Click OK.



4. To add a new module to the tree, right-click  Ethernet and select New Module. This action lets you add a new ArmorStart selection to the Logix Project.




5. Select the ArmorStart controller in your application and click OK.




6. The AOP is shown in the next example. Enter a Name for this ArmorStart selection and an Ethernet address. For this example, the Private Network setting is used. This setting must be set to match the IP address switch setting on the ArmorStart selection. Click OK.

Note: See [Configuring EtherNet/IP Address](#) in Chapter 5 to set an IP address on the device.





Connect and Configure ArmorStart Controller with Add-on Profile (AOP)

This section shows the AOP tabs and how they can be used to connect, obtain status, and configure the ArmorStart selection. Before the walkthrough is started, the Studio 5000 software must be open and an AOP displayed as shown next.




Choose the Module Definition as shown. You can change from parameter view to a more user-friendly graphic view.



Offline Connection

General Tab

Click the General tab to display the following:




This tab lets you name your module, which must be descriptive and representative of the module. You must also input the IP address of the module so that communication can be established. The IP Address must be the one defined when the BootP/DHCP Server, the Rotary Network Address Switches, or the ArmorStart internal web server. is used.

For most cases, the Host Name and Module Definition section of this tab do not require any adjustment. Changes to either of these sections must only be made if you are familiar with the functionality of each of these sections.

Connection Tab

Click the Connection tab to display the following:



The Request Packet Interval (RPI) indicates the maximum frequency at which data is received. It is possible that data can come more quickly than the time interval assigned in the RPI. In most cases, the default 20 ms is the optimal setting. If you check the Inhibit Module option, connection to controller tags are broken. The Major Fault on Controller if Connection Fails While in Run Mode option, must be checked to make sure that the controller processes the connection fault with the ArmorStart controller. The Use Unicast Connection over EtherNet/IP is checked to use the Unicast mode instead of the EtherNet/IP mode. This choice appears only for modules that are using Studio 5000 software version 18 or later that supports Unicast.

Parameters and Configuration Tab

Based on the configuration in the module definition tab, configure the ArmorStart controller by using one of the following screens. The parameters are divided into groups that are based on the type of ArmorStart controller and set-up function.

Parameter View, Selected

ID	Name	Value	Min	Max	
131	Motor NP Volts	460	70	460	Set to the motor
132	Motor NP Hertz	60	10	400	Set to the motor
133	Motor OL Current	1.4	0.0	1.6	Set to the maxin
134	Minimum Freq	0.0	0.0	400.0	Sets the lowest
135	Maximum Freq	60	0	400	Sets the highes
136	Start Source	Comm Port			Sets the control
137	Stop Mode	Ramp+EM Brk			The stop mode
138	Speed Reference	Comm Port			The speed refer
139	Accel Time 1	10.0	0.0	600.0	The rate of acc
140	Decel Time 1	10.0	0.1	600.0	The rate of dec
143	Motor OL Ret	Disabled			Enables/disabl

Reset Defaults Reset Fault Set

i The values displayed here are read directly from the project when offline and from the ArmorStart when online. These values are not sent to the ArmorStart when a connection is established. Click Set to write updated values.

w You must go online with this Parameters tab to ensure the controller and ArmorStart configurations are consistent with each other.

Status: Offline OK Cancel Apply Help

Functional Group View, Selected

Speed Reference: Output Tag

Speed Limits & Ramp Rates

Max Frequency: 60 Hz

Min Frequency: 0.0 Hz

Accel Time 1: 10.0 s

Decel Time 1: 10.0 s

Jog Frequency

Frequency: 10.0 Hz

Accel/Decel: 10.0 s

i The S Curve displayed is for illustrative purposes and may not reflect the exact S Curve behavior.

i The values displayed here are read directly from the project when offline and from the ArmorStart when online. These values are not sent to the ArmorStart when a connection is established. Click Set to write updated values.

w You must go online with this module profile to ensure the controller and ArmorStart configurations are consistent with each other.

Status: Offline OK Cancel Apply Help


Online Connection

Note: If you are using a catalog number 1756-ENBT Ethernet module to communicate with the PLC, verify that you have updated the firmware of the module to Revision 6.001 or later. The latest firmware can be found at <http://support.rockwellautomation.com/controlflash/>.


1. If a controller path is not set in the field that is shown, you must first set a path before the controller can go online. Click the  RSwho button shown.




2. Expand and browse the AB_ETHIP-1, Ethernet driver.




3. Select the Controller path. Then click Go Online.




4. The following appears and for this example, click Download to connect to the controller.




5. If a download confirmation dialog box appears, click Download again.
6. Click Yes to bring the controller back to Remote Run.




- The controller is now online. If at any point you go offline and a path is selected, you can also go online by clicking the Offline pull-down in the upper left corner of the screen. Click Go Online to connect to the ArmorStart device, as shown next.



If a yellow triangle appears next to the ArmorStart Icon in the Controller Organizer Tree as shown next, it means that the connection is faulted. The problem must be fixed before you can connect to the ArmorStart device.




First make sure that you have selected the correct AOP for the device being communicated to, for example the correct horse power or product type. Second, reset the ArmorStart device to factory defaults from the web page. Lastly, reset the module properties from the Module Definition window as shown.




Correlation

When the AOP is first opened and the PLC project is online with the ArmorStart device a correlation step occurs. The Correlation pop-up window is displayed, as shown next.



This window indicates that the AOP is comparing the parameter data entered offline vs. the parameter data that is stored in the ArmorStart device. If any discrepancies are found between the parameters in the AOP and the parameters in the ArmorStart device, a window pops up, as shown. The window prompts you to decide which parameters to keep.



If you want to keep the parameters in the AOP, select Download. If you want to keep the parameters in the ArmorStart device, select Upload. Otherwise, select Cancel. When you click Cancel, you are locked out of viewing the values. If you are connected to a new ArmorStart device and just created the ArmorStart object and have not made changes in the parameters, the ArmorStart correlation must not find any discrepancy.

Note: If you change any parameters offline, you must go online with the PLC then open the corresponding AOP. This step triggers the correlations step to make those changes effective in the ArmorStart device.

Module Info Tab

Click the Module Info tab to display the following:

The screenshot displays the Module Info tab with two main sections: Identification and Status. The Identification section lists the following details:

Identification	
Vendor:	Allen-Bradley
Product Type:	Motor Starter
Product Code:	284E-FVD1P4
Revision:	1.1
Serial Number:	A0120B9D
Product Name:	ArmorStart 284E PF40 480V 0.5HP

The Status section lists the following details:

Status	
Major Fault:	Recoverable
Minor Fault:	None
Internal State:	Major fault
Configured:	Configured
Owned:	Owned
Module Identity:	Match

Below the status information, there are two buttons: "Refresh" and "Reset Module". At the bottom of the window, the status is shown as "Status: Running" and there are four buttons: "OK", "Cancel", "Apply", and "Help".

This tab displays general identification information and status information about the ArmorStart device. It is important to note that the information that is displayed in this tab is not constantly updated. After you click the Module Info tab, the AOP queries the ArmorStart device once for the information that is displayed in this tab and does not query the ArmorStart device for the values again. If after the initial query the status of the ArmorStart device changes, for example a fault occurs, the change in the status will not be automatically updated. The **Refresh** button must be pressed to request the AOP for another ArmorStart query.

Note: A connection status (offline, online, downloading, or uploading) is provided at the bottom left of the tab window. The connection status appears in all tabs.

Internet Protocol Tab

Click the Internet Protocol tab to display the following:

Internet Protocol (IP) Settings
IP settings can be manually configured or can be automatically configured if the network supports this capability.

Manually configure IP settings
 Obtain IP settings automatically using BOOTP
 Obtain IP settings automatically using DHCP
 IP settings set by switches on the module

IP Settings Configuration

Physical Module IP Address: 192 . 168 . 1 . 1 Subnet Mask: 255 . 255 . 255 . 0
Gateway Address: 0 . 0 . 0 . 0

Domain Name: Primary DNS Server Address: 10 . 10 . 10 . 1
Host Name: Secondary DNS Server Address: 0 . 0 . 0 . 0


[Refresh communication](#) ←

Status: Running

If the IP address was created by using the Rotary Network Address Switches, default settings for the IP would already be established and you cannot make any changes in this tab. In most cases, you would not need to make any changes in this tab and it only displays the current IP Settings Configuration.

Port Configuration Tab


Click the Port Configuration tab to display the following:



This tab is used to enable or disable a physical port in the module. The ports are normally in Auto Negotiate mode, which in general, is the recommended setting. Otherwise, you have to physically set the Speed or Duplex selection in this tab. It is important to note that although there are two physical ports, they act as one. Therefore, when you press either of the Port Diagnostic buttons, information that comes from both of the physical ports is displayed.

Network Tab

Click this tab to display the following:



This tab displays information about the network configuration, such as the type of topology (linear or Device Level Ring).

Auto-generated Tags

After you install and configure the AOP, the controller tags are generated. The tags names are descriptive and automatically generated which greatly simplifies programming. The next figure shows an example of the auto-generated tags for an ArmorStart selection.

Name	Alias For
+ ASEIP_DEMO:I	
- ASEIP_DEMO:O	
+ ASEIP_DEMO:O.CommandData	
- ASEIP_DEMO:O.RunForward	
- ASEIP_DEMO:O.ResetFault	
- ASEIP_DEMO:O.OutA	
- ASEIP_DEMO:O.OutB	
- ASEIP_DEMO:O.Pt00Deviceln	
- ASEIP_DEMO:O.Pt01Deviceln	
- ASEIP_DEMO:O.Pt02Deviceln	
- ASEIP_DEMO:O.Pt03Deviceln	
- ASEIP_DEMO:O.Pt04Deviceln	
- ASEIP_DEMO:O.Pt05Deviceln	
- ASEIP_DEMO:O.Pt06Deviceln	
- ASEIP_DEMO:O.Pt07Deviceln	
- ASEIP_DEMO:O.Pt08Deviceln	
- ASEIP_DEMO:O.Pt09Deviceln	
- ASEIP_DEMO:O.Pt10Deviceln	
- ASEIP_DEMO:O.Pt11Deviceln	
- ASEIP_DEMO:O.Pt12Deviceln	
- ASEIP_DEMO:O.Pt13Deviceln	
- ASEIP_DEMO:O.Pt14Deviceln	
- ASEIP_DEMO:O.Pt15Deviceln	

The next tables provide more clarification regarding the Produce and Consume assemblies and how they correlate with the auto-generated names.

When an AOP is used, the data in the Consumed and Produced Assemblies is automatically created as descriptive tag names. To re-enforce this point, a few of the commands are highlighted to demonstrate the AOP tag alignment to the Consumed and Produced Assemblies in the next tables.

Table 8 - Default Consume Assembly for Bulletin 284E Controller

Instance 166 Consumed Inverter Type Starter with Network Inputs								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Out B	Out A	—	JogReverse	JogForward	ResetFault	RunReverse	RunForward
1	DriveInput4 ⁽¹⁾	DriveInput3 ⁽¹⁾	DriveInput2 ⁽¹⁾	DriveInput1 ⁽¹⁾	DecelCtrl_1	DecelCtrl_0	AccelCtrl_1	AccelCtrl_0
2	FreqCommand (Low) (xxx.x Hz)							
3	FreqCommand (High) (xxx.x Hz)							
4	Pt07Deviceln	Pt06Deviceln	Pt05Deviceln	Pt04Deviceln	Pt03Deviceln	Pt02Deviceln	Pt01Deviceln	Pt00Deviceln
5	Pt15Deviceln	Pt14Deviceln	Pt13Deviceln	Pt12Deviceln	Pt11Deviceln	Pt10Deviceln	Pt9Deviceln	Pt8Deviceln

(1) See Digital In 1...4 SEL - Parameters 151...154.

Table 9 - Bulletin 284E Consume Assembly Command Tags

Controller Output/ Command Tags		
Ex. Controller Name	Name	Logix Tag Name
AS_DEMO	RunForward	AS_DEMO:0.RunForward
AS_DEMO	RunReverse	AS_DEMO:0.RunReverse
AS_DEMO	ResetFault	AS_DEMO:0.ResetFault
AS_DEMO	JogForward	AS_DEMO:0.JogForward
AS_DEMO	JogReverse	AS_DEMO:0.JogReverse
AS_DEMO	OutA	AS_DEMO:0.OutA
AS_DEMO	OutB	AS_DEMO:0.OutB
AS_DEMO	AccelCtrl_0	AS_DEMO:0.AccelCtrl_0
AS_DEMO	AccelCtrl_1	AS_DEMO:0.AccelCtrl_1
AS_DEMO	DecelCtrl_0	AS_DEMO:0.DecelCtrl_0
AS_DEMO	DecelCtrl_1	AS_DEMO:0.DecelCtrl_1
AS_DEMO	DriveInput1	AS_DEMO:0.DriveInput1
AS_DEMO	DriveInput2	AS_DEMO:0.DriveInput2
AS_DEMO	DriveInput3	AS_DEMO:0.DriveInput3
AS_DEMO	DriveInput4	AS_DEMO:0.DriveInput4
AS_DEMO	FreqCommand	AS_DEMO:0.FreqCommand
AS_DEMO	Pt00Deviceln	AS_DEMO:0.Pt00Deviceln
AS_DEMO	Pt01Deviceln	AS_DEMO:0.Pt01Deviceln
AS_DEMO	Pt02Deviceln	AS_DEMO:0.Pt02Deviceln
AS_DEMO	Pt03Deviceln	AS_DEMO:0.Pt03Deviceln
AS_DEMO	Pt04Deviceln	AS_DEMO:0.Pt04Deviceln
AS_DEMO	Pt05Deviceln	AS_DEMO:0.Pt05Deviceln
AS_DEMO	Pt06Deviceln	AS_DEMO:0.Pt06Deviceln
AS_DEMO	Pt07Deviceln	AS_DEMO:0.Pt07Deviceln
AS_DEMO	Pt08Deviceln	AS_DEMO:0.Pt08Deviceln
AS_DEMO	Pt09Deviceln	AS_DEMO:0.Pt09Deviceln
AS_DEMO	Pt10Deviceln	AS_DEMO:0.Pt10Deviceln

Controller Output/ Command Tags		
Controller Name	Name	Logix Tag Name
AS_DEMO	Pt11DeviceIn	AS_DEMO:0.Pt11DeviceIn
AS_DEMO	Pt12DeviceIn	AS_DEMO:0.Pt12DeviceIn
AS_DEMO	Pt13DeviceIn	AS_DEMO:0.Pt13DeviceIn
AS_DEMO	Pt14DeviceIn	AS_DEMO:0.Pt14DeviceIn

Table 10 - Default Produce Assembly for Bulletin 284E Controller.

Produce Assembly - Instance 151 "Drive Status" - Bulletin284E Starters								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved - {name}:I.Fault ⁽¹⁾							
1	Reserved - {name}:I.Fault ⁽¹⁾							
2	Reserved - {name}:I.Fault ⁽¹⁾							
3	Reserved - {name}:I.Fault ⁽¹⁾							
4	AtReference	Network ReferenceStatus	NetControlStatus	Ready	RunningReverse	RunningForward	WarningPresent	TripPresent
5	Output ContactorStatus	Brake ContactorStatus	DisconnectClosed	Hand	In3	In2	In1	In0
6	OutputFrequency (Low) (xxx.x Hz)							
7	OutputFrequency (High) (xxx.x Hz)							
8	Pt07DeviceOut	Pt06DeviceOut	Pt05DeviceOut	Pt04DeviceOut	Pt03DeviceOut	Pt02DeviceOut	Pt01DeviceOut	Pt00DeviceOut
9	LogicEnable	Pt14DeviceOut	Pt13DeviceOut	Pt12DeviceOut	Pt11DeviceOut	P10DeviceOut	Pt09DeviceOut	Pt08DeviceOut
10	Value of the parameter pointed to by "Parameter 13 Prod Assy Word 0" (low byte)" - Int00DeviceOut							
11	Value of the parameter pointed to by "Parameter 13 Prod Assy Word 0" (high byte)" - Int00DeviceOut							
12	Value of the parameter pointed to by "Parameter 14 Prod Assy Word 1" (low byte)" - Int01DeviceOut							
13	Value of the parameter pointed to by "Parameter 14 Prod Assy Word 1" (high byte)" - Int01DeviceOut							
14	Value of the parameter pointed to by "Parameter 15 Prod Assy Word 2" (low byte)" - Int02DeviceOut							
15	Value of the parameter pointed to by "Parameter 15 Prod Assy Word 2" (high byte)" - Int02DeviceOut							
16	Value of the parameter pointed to by "Parameter 16 Prod Assy Word 3" (low byte)" - Int03DeviceOut							
17	Value of the parameter pointed to by "Parameter 16 Prod Assy Word 3" (high byte)" - Int03DeviceOut							

(1) Identifies if a Communication Fault exists. If a communication loss is present, the PLC writes four bytes of 1's to this tag. You must monitor this tag to verify that the data is valid.

IMPORTANT Your PLC control program monitors the **I.Fault** tag to verify that the data is accurate. When a communications fault occurs, the data in the consume and produce tags does not accurately reflect the status.

Table 11 - Bulletin 284E Produced Assembly Status Tags

Controller Input/ Status Tags		
Ex. Controller Name	Name	Logix Tag Name
AS_DEMO	Fault	AS_DEMO:I.Fault
AS_DEMO	TripPresent	AS_DEMO:I.TripPresent
AS_DEMO	WarningPresent	AS_DEMO:I.WarningPresent
AS_DEMO	RunningForward	AS_DEMO:I.RunningForward
AS_DEMO	RunningReverse	AS_DEMO:I.RunningReverse
AS_DEMO	Ready	AS_DEMO:I.Ready
AS_DEMO	NetworkControlStatus	AS_DEMO:I.NetworkControlStatus
AS_DEMO	NetworkReferenceStatus	AS_DEMO:I.NetworkReferenceStatus
AS_DEMO	AtReference	AS_DEMO:I.AtReference
AS_DEMO	In0	AS_DEMO:I.In0
AS_DEMO	In1	AS_DEMO:I.In1
AS_DEMO	In2	AS_DEMO:I.In2
AS_DEMO	In3	AS_DEMO:I.In3
AS_DEMO	Hand	AS_DEMO:I.Hand
AS_DEMO	DisconnectClosed	AS_DEMO:I.DisconnectClosed
AS_DEMO	BrakeContactorStatus	AS_DEMO:I.BrakeContactorStatus
AS_DEMO	OutputContactorStatus	AS_DEMO:I.OutputContactorStatus
AS_DEMO	OutputFrequency	AS_DEMO:I.OutputFrequency
AS_DEMO	Pt00DeviceOut	AS_DEMO:I.Pt00DeviceOut
AS_DEMO	Pt01DeviceOut	AS_DEMO:I.Pt01DeviceOut
AS_DEMO	Pt02DeviceOut	AS_DEMO:I.Pt02DeviceOut
AS_DEMO	Pt03DeviceOut	AS_DEMO:I.Pt03DeviceOut
AS_DEMO	Pt04DeviceOut	AS_DEMO:I.Pt04DeviceOut
AS_DEMO	Pt05DeviceOut	AS_DEMO:I.Pt05DeviceOut
AS_DEMO	Pt06DeviceOut	AS_DEMO:I.Pt06DeviceOut
AS_DEMO	Pt07DeviceOut	AS_DEMO:I.Pt07DeviceOut
AS_DEMO	Pt08DeviceOut	AS_DEMO:I.Pt08DeviceOut
AS_DEMO	Pt09DeviceOut	AS_DEMO:I.Pt09DeviceOut
AS_DEMO	Pt10DeviceOut	AS_DEMO:I.Pt10DeviceOut
AS_DEMO	Pt11DeviceOut	AS_DEMO:I.Pt11DeviceOut
AS_DEMO	Pt12DeviceOut	AS_DEMO:I.Pt12DeviceOut
AS_DEMO	Pt13DeviceOut	AS_DEMO:I.Pt13DeviceOut
AS_DEMO	Pt14DeviceOut	AS_DEMO:I.Pt14DeviceOut
AS_DEMO	LogicEnabled	AS_DEMO:I.LogicEnabled
AS_DEMO	Int00DeviceOut	AS_DEMO:I.Int00DeviceOut
AS_DEMO	Int01DeviceOut	AS_DEMO:I.Int01DeviceOut
AS_DEMO	Int02DeviceOut	AS_DEMO:I.Int02DeviceOut
AS_DEMO	Int03DeviceOut	AS_DEMO:I.Int03DeviceOut

Table 12 - Bulletin 284E Consume Assembly/Command Tag Explanation

Controller Output/ Command Tags	Tag Description/Use
RunForward	Command VFD forward
RunReverse	Command VFD reverse
ResetFault	Fault reset
JogForward	Command Jog forward per internal frequency
JogReverse	Command Jog reverse per internal frequency
OutA	Output A
OutB	Output B
AccelCtrl_0	VFD acceleration ramp 1
AccelCtrl_1	VFD acceleration ramp 2
DecelCtrl_0	VFD deceleration ramp 1
DecelCtrl_1	VFD deceleration ramp 2
DriveInput1	VFD Digit Input 1
DriveInput2	VFD Digit Input 2
DriveInput3	VFD Digit Input 3
DriveInput4	VFD Digit Input 4
FreqCommand	Logix commanded frequency
Pt00Deviceln	Network input to DeviceLogix engine
Pt01Deviceln	Network input to DeviceLogix engine
Pt02Deviceln	Network input to DeviceLogix engine
Pt03Deviceln	Network input to DeviceLogix engine
Pt04Deviceln	Network input to DeviceLogix engine
Pt05Deviceln	Network input to DeviceLogix engine
Pt06Deviceln	Network input to DeviceLogix engine
Pt07Deviceln	Network input to DeviceLogix engine
Pt08Deviceln	Network input to DeviceLogix engine
Pt09Deviceln	Network input to DeviceLogix engine
Pt10Deviceln	Network input to DeviceLogix engine
Pt11Deviceln	Network input to DeviceLogix engine
Pt12Deviceln	Network input to DeviceLogix engine
Pt13Deviceln	Network input to DeviceLogix engine
Pt14Deviceln	Network input to DeviceLogix engine
Pt15Deviceln	Network input to DeviceLogix engine

Table 13 - Bulletin 284E Produced Assembly/Status Tag Explanation

Controller Input/ Status Tags	Tag Description/Use
Fault	Communication Fault between PLC and Device (all 1's = Fault, all 0's = Normal)
TripPresent	Fault exists with unit
WarningPresent	Warning of potential fault
RunningForward	Motor commanded to run forward
RunningReverse	Motor commanded to run reverse
Ready	Control Power and 3-phase present
NetworkControlStatus	Start and Stop command comes from network (PLC or Connected Explicit Messaging)
NetworkReferenceStatus	Speed reference comes from the network (not DeviceLogix)
AtReference	At commanded speed reference
In0	Input 0
In1	Input 1
In2	Input 2
In3	Input 3
Hand	HOA is in Auto mode
DisconnectClosed	Disconnect is closed
BrakeContactorStatus	Source brake contactor status (1=close, 0=open)
OutputContactorStatus	Output contactor status (1=close, 0=open)
OutputFrequency	VFD frequency
Pt00DeviceOut	DeviceLogix network output status
Pt01DeviceOut	DeviceLogix network output status
Pt02DeviceOut	DeviceLogix network output status
Pt03DeviceOut	DeviceLogix network output status
Pt04DeviceOut	DeviceLogix network output status
Pt05DeviceOut	DeviceLogix network output status
Pt06DeviceOut	DeviceLogix network output status
Pt07DeviceOut	DeviceLogix network output status
Pt08DeviceOut	DeviceLogix network output status
Pt09DeviceOut	DeviceLogix network output status
Pt10DeviceOut	DeviceLogix network output status
Pt11DeviceOut	DeviceLogix network output status
Pt12DeviceOut	DeviceLogix network output status
Pt13DeviceOut	DeviceLogix network output status
Pt14DeviceOut	DeviceLogix network output status
LogicEnabled	DeviceLogix is enabled
Int00DeviceOut	Data reference by Parameter 13
Int01DeviceOut	Data reference by Parameter 14
Int02DeviceOut	Data reference by Parameter 15
Int03DeviceOut	Data reference by Parameter 16

Table 14 - Default Consume Assembly for Bulletin 281E Controller

Instance 162 Default Consumed DOL and Reversing Starter								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	OutB	OutA	—	—	—	ResetFault	RunReverse	RunForward
1	Pt07Deviceln	Pt06Deviceln	Pt05Deviceln	Pt04Deviceln	Pt03Deviceln	Pt02Deviceln	Pt01Deviceln	Pt00Deviceln
2	Pt15Deviceln	Pt14Deviceln	Pt13Deviceln	Pt12Deviceln	Pt11Deviceln	Pt10Deviceln	Pt09Deviceln	Pt08Deviceln

Table 15 - Bulletin 281E Controller Output/Command Tags

Ex. Controller Name	Name	Logix Tag Name
DEMO_REV	RunForward	DEMO_REV:0.RunForward
DEMO_REV	RunReverse	DEMO_REV:0.RunReverse
DEMO_REV	ResetFault	DEMO_REV:0.ResetFault
DEMO_REV	OutA	DEMO_REV:0.OutA
DEMO_REV	OutB	DEMO_REV:0.OutB
DEMO_REV	Pt00Deviceln	DEMO_REV:0.Pt00Deviceln
DEMO_REV	Pt01Deviceln	DEMO_REV:0.Pt01Deviceln
DEMO_REV	Pt02Deviceln	DEMO_REV:0.Pt02Deviceln
DEMO_REV	Pt03Deviceln	DEMO_REV:0.Pt03Deviceln
DEMO_REV	Pt04Deviceln	DEMO_REV:0.Pt04Deviceln
DEMO_REV	Pt05Deviceln	DEMO_REV:0.Pt05Deviceln
DEMO_REV	Pt06Deviceln	DEMO_REV:0.Pt06Deviceln
DEMO_REV	Pt07Deviceln	DEMO_REV:0.Pt07Deviceln
DEMO_REV	Pt08Deviceln	DEMO_REV:0.Pt08Deviceln
DEMO_REV	Pt09Deviceln	DEMO_REV:0.Pt09Deviceln
DEMO_REV	Pt10Deviceln	DEMO_REV:0.Pt10Deviceln
DEMO_REV	Pt11Deviceln	DEMO_REV:0.Pt11Deviceln
DEMO_REV	Pt12Deviceln	DEMO_REV:0.Pt12Deviceln
DEMO_REV	Pt13Deviceln	DEMO_REV:0.Pt13Deviceln
DEMO_REV	Pt14Deviceln	DEMO_REV:0.Pt14Deviceln
DEMO_REV	Pt15Deviceln	DEMO_REV:0.Pt15Deviceln

Table 16 - Default Produce Assembly for Bulletin 281E Controller

Instance 150 "Starter Stat" - Default Status Assembly for Bulletin 281E Starters								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved - {name}:I.Fault ⁽¹⁾							
1	Reserved - {name}:I.Fault ⁽¹⁾							
2	Reserved - {name}:I.Fault ⁽¹⁾							
3	Reserved - {name}:I.Fault ⁽¹⁾							
4	—	—	—	Ready	RunningReverse	RunningForward	WarningPresent	TripPresent
5	—	—	DisconnectClosed	Hand	In3	In2	In1	In0
6	Pt07DeviceOut	Pt06DeviceOut	Pt05DeviceOut	Pt04DeviceOut	Pt03DeviceOut	Pt02DeviceOut	Pt01DeviceOut	Pt00DeviceOut
7	LogicEnable	Pt14DeviceOut	Pt13DeviceOut	Pt12DeviceOut	Pt11DeviceOut	Pt10DeviceOut	Pt09DeviceOut	Pt08DeviceOut
8	Value of the parameter pointed to by "Parameter 13 Prod Assy Word 0" (low byte)" - ProducedWord0Param							
9	Value of the parameter pointed to by "Parameter 13 Prod Assy Word 0" (high byte)" - ProducedWord0Param							
10	Value of the parameter pointed to by "Parameter 14 Prod Assy Word 1" (low byte)" - ProducedWord1Param							
11	Value of the parameter pointed to by "Parameter 14 Prod Assy Word 1" (high byte)" - ProducedWord1Param							
12	Value of the parameter pointed to by "Parameter 15 Prod Assy Word 2" (low byte)" - ProducedWord2Param							
13	Value of the parameter pointed to by "Parameter 15 Prod Assy Word 2" (high byte)" - ProducedWord2Param							
14	Value of the parameter pointed to by "Parameter 16 Prod Assy Word 3" (low byte)" - ProducedWord3Param							
15	Value of the parameter pointed to by "Parameter 16 Prod Assy Word 3" (high byte)" - ProducedWord3Param							

(1) Identifies if a Communication Fault exists. If a communication loss is present the PLC writes four bytes of 1s to this tag. You must monitor this tag to verify that the data is valid.

IMPORTANT Your PLC control program monitors the **I.Fault** tag to verify that the data is accurate. When a communications fault occurs, the data in the consume and produce tags does not accurately reflect the status.

Table 17 - Bulletin 281E Controller Input/ Status Tags

Ex. Controller Name	Name	Logix Tag Name
DEMO_REV	Fault	DEMO_REV:I.Fault
DEMO_REV	TripPresent	DEMO_REV:I.TripPresent
DEMO_REV	WarningPresent	DEMO_REV:I.WarningPresent
DEMO_REV	RunningForward	DEMO_REV:I.RunningForward
DEMO_REV	RunningReverse	DEMO_REV:I.RunningReverse
DEMO_REV	Ready	DEMO_REV:I.Ready
DEMO_REV	In0	DEMO_REV:I.In0
DEMO_REV	In1	DEMO_REV:I.In1
DEMO_REV	In2	DEMO_REV:I.In2
DEMO_REV	In3	DEMO_REV:I.In3
DEMO_REV	Hand	DEMO_REV:I.Hand
DEMO_REV	DisconnectClosed	DEMO_REV:I.DisconnectClosed
DEMO_REV	Pt00DeviceOut	DEMO_REV:I.Pt00DeviceOut
DEMO_REV	Pt01DeviceOut	DEMO_REV:I.Pt01DeviceOut
DEMO_REV	Pt02DeviceOut	DEMO_REV:I.Pt02DeviceOut
DEMO_REV	Pt03DeviceOut	DEMO_REV:I.Pt03DeviceOut
DEMO_REV	Pt04DeviceOut	DEMO_REV:I.Pt04DeviceOut
DEMO_REV	Pt05DeviceOut	DEMO_REV:I.Pt05DeviceOut
DEMO_REV	Pt06DeviceOut	DEMO_REV:I.Pt06DeviceOut
DEMO_REV	Pt07DeviceOut	DEMO_REV:I.Pt07DeviceOut
DEMO_REV	Pt08DeviceOut	DEMO_REV:I.Pt08DeviceOut
DEMO_REV	Pt09DeviceOut	DEMO_REV:I.Pt09DeviceOut
DEMO_REV	Pt10DeviceOut	DEMO_REV:I.Pt10DeviceOut
DEMO_REV	Pt11DeviceOut	DEMO_REV:I.Pt11DeviceOut
DEMO_REV	Pt12DeviceOut	DEMO_REV:I.Pt12DeviceOut
DEMO_REV	Pt13DeviceOut	DEMO_REV:I.Pt13DeviceOut
DEMO_REV	Pt14DeviceOut	DEMO_REV:I.Pt14DeviceOut
DEMO_REV	LogicEnabled	DEMO_REV:I.LogicEnabled
DEMO_REV	ProducedWord0Param	DEMO_REV:I.ProducedWord0Param
DEMO_REV	ProducedWord1Param	DEMO_REV:I.ProducedWord1Param
DEMO_REV	ProducedWord2Param	DEMO_REV:I.ProducedWord2Param
DEMO_REV	ProducedWord3Param	DEMO_REV:I.ProducedWord3Param

Table 18 - Bulletin 281E Consume Assembly Command Tag Explanation

Controller Output/ Command Tags	Tag Description/Use
RunForward	Command VFD forward
RunReverse	Command VFD reverse
ResetFault	Fault reset
OutA	OutputA
OutB	OutputB
Pt00Deviceln	Network input to DeviceLogix engine
Pt01Deviceln	Network input to DeviceLogix engine
Pt02Deviceln	Network input to DeviceLogix engine
Pt03Deviceln	Network input to DeviceLogix engine
Pt04Deviceln	Network input to DeviceLogix engine
Pt05Deviceln	Network input to DeviceLogix engine
Pt06Deviceln	Network input to DeviceLogix engine
Pt07Deviceln	Network input to DeviceLogix engine
Pt08Deviceln	Network input to DeviceLogix engine
Pt09Deviceln	Network input to DeviceLogix engine
Pt10Deviceln	Network input to DeviceLogix engine
Pt11Deviceln	Network input to DeviceLogix engine
Pt12Deviceln	Network input to DeviceLogix engine
Pt13Deviceln	Network input to DeviceLogix engine
Pt14Deviceln	Network input to DeviceLogix engine
Pt15Deviceln	Network input to DeviceLogix engine

Table 19 - Bulletin 281E Produced Assembly Status Tag Explanation

Controller Input/Status Tags	Tag Description/Use
Fault	Communication Fault between PLC and Device (all 1's = Fault, all 0's = Normal)
TripPresent	Fault exists with unit
WarningPresent	Warning of potential fault
RunningForward	Motor commanded to run forward
RunningReverse	Motor commanded to run reverse
Ready	Control Power and 3-phase present
In0	Input 0
In1	Input 1
In2	Input 2
In3	Input 3
Hand	HOA is in Auto mode
DisconnectClosed	Disconnect is closed
Pt00DeviceOut	DeviceLogix network output status
Pt01DeviceOut	DeviceLogix network output status
Pt02DeviceOut	DeviceLogix network output status
Pt03DeviceOut	DeviceLogix network output status
Pt04DeviceOut	DeviceLogix network output status
Pt05DeviceOut	DeviceLogix network output status
Pt06DeviceOut	DeviceLogix network output status
Pt07DeviceOut	DeviceLogix network output status
Pt08DeviceOut	DeviceLogix network output status
Pt09DeviceOut	DeviceLogix network output status
Pt10DeviceOut	DeviceLogix network output status
Pt11DeviceOut	DeviceLogix network output status
Pt12DeviceOut	DeviceLogix network output status
Pt13DeviceOut	DeviceLogix network output status
Pt14DeviceOut	DeviceLogix network output status
LogicEnabled	DeviceLogix is enabled
ProducedWord0Param	Data reference by Parameter 13
ProducedWord1Param	Data reference by Parameter 14
ProducedWord2Param	Data reference by Parameter 15
ProducedWord3Param	Data reference by Parameter 16

Bulletin 281E/284E Programmable Parameters

Basic Set-up Parameters

To configure the basic ArmorStart functionality, see Table 20. These parameters are the minimum set-up configurations that are required for Bulletin 281E or Bulletin 284E controllers. There are additional capabilities and motor protection that are not enabled or left at their default values.

Table 20 - Quick Parameter Setup

Bulletin 281E Controller	Bulletin 284E Controller
106 FLA Setting	131 Motor NP Volts
107 Overload Class	132 Motor NP Hertz
108 OL Reset Level	133 Motor OL Current
	134 Minimum Freq
	135 Maximum Freq
	137 Stop Mode
	138 Speed Reference
	139 Accel Time 1
	140 Decel Time 1

Parameter Groups

Common to Bulletin 281E and Bulletin 284E Units					Bulletin 284E Units Only
Basic Status	Produced Assembly Config Group	Starter Protection	User I/O Config	Miscellaneous Config	Drive I/O Config
1 Hdw Inputs 2 DeviceIn Data 3 DeviceOut Data 4 Trip Status 5 Starter Status 6 InternalLinkStat 7 Starter Command 22 Breaker Type 56 Base Enclosure 57 Base Options 58 Wiring Options 59 Starter Enclosure 60 Starter Options 61 Last Pr Fault 62 Warning Status 63 Base Trip	13 Int00DeviceOut Cfg 14 Int01DeviceOut Cfg 15 Int02DeviceOut Cfg 16 Int03DeviceOut Cfg	23 Pr FltResetMode 24 Pr Fault Enable 25 Pr Fault Reset 26 Str Net FltState 27 Str Net FltValue 28 Str Net IdlState 29 Str Net IdlValue	30 Anti-bounce On Delay 31 Anti-bounce OFF Delay 32 In Sink/Source 33 OutA Pr FltState 34 OutA Pr FltValue 35 OutA Net FltState 36 OutA Net FltValue 37 OutA Net IdlState 38 OutA Net IdlValue 39 OutB Pr FltState 40 OutB Pr FltValue 41 OutB Net FltState 42 OutB Net FltValue 43 OutB Net IdlState 44 OutB Net IdlValue	8 Network Override 9 Comm Override 45 Keypad Mode 46 Keypad Disable 47 Set To Defaults	48 Drive Control 49 DrvIn Pr FltState 50 DrvIn Pr FltValue 51 DrvIn Net FltState 52 DrvIn Net FltValue 53 DrvIn Net IdlState 54 DrvIn Net IdlValue

Bulletin281E Units Only	Bulletin 284E Units Only				
Starter Display	Drive Display	Drive Setup	Drive Advanced Setup		
101 Phase A Current 102 Phase B Current 103 Phase C Current 104 Average Current 105 Therm Utilized Starter Setup 106 FLA Setting 107 Overload Class 108 OL Reset Level	101 Output Freq 102 Commanded Freq 103 Output Current 104 Output Voltage 105 DC Bus Voltage 106 Drive Status 107 Fault 1 Code 108 Fault 2 Code 109 Fault 3 Code 110 Process Display 112 Control Source 113 Contrl In Status 114 Dig In Status 115 Comm Status 116 Control SW Ver 117 Drive Type 118 Elapsed Run Time 122 Output Power 123 Output Power Fctr 124 Drive Temp 125 Counter Status 126 Timer Status 129 Torque Current	131 Motor NP Volts 132 Motor NP Hertz 133 Motor OL Current 134 Minimum Freq 135 Maximum Freq 136 Start Source 137 Stop Mode 138 Speed Reference 139 Accel Time 1 140 Decel Time 1 141 Reset To Defaults 143 Motor OL Ret	151 Digital In 1 Sel 152 Digital In 2 Sel 153 Digital In 3 Sel 154 Digital In 4 Sel 155 Relay Out Sel 156 Relay Out Level 167 Accel Time 2 168 Decel Time 2 169 Internal Freq 170 Preset Freq 0 171 Preset Freq 1 172 Preset Freq 2 173 Preset Freq 3 174 Preset Freq 4 175 Preset Freq 5 176 Preset Freq 6 177 Preset Freq 7 178 Jog Frequency 179 Jog Accel/Decel 180 DC Brake Time	181 DC Brake Level 182 DB Resistor Sel 183 S Curve % 184 Boost Select 185 Start Boost 186 Brake Voltage 187 Brake Frequency 188 Maximum Voltage 189 Current Limit 1 190 Motor OL Select 191 PWM Frequency 192 Auto Rstrt Tries 193 Auto Rstrt Delay 194 Start At PowerUp 195 Reverse Disable 196 Flying Start En 197 Compensation 198 SW Current Trip 199 Process Factor 200 Fault Clear	201 Program Lock 205 Comm Loss Action 206 Comm Loss Time 214 Slip Hertz @ FLA 217 Bus Reg Mode 218 Current Limit 2 219 Skip Frequency 220 Skip Freq Band 221 Stall Fault Time 224 Var PWM Disable 225 Torque Perf Mode 226 Motor NP FLA 227 Autotune 228 IR Voltage Drop 229 Flux Current Ref 260 EM Brk OFF Delay 261 EM Brk On Delay 262 MOP Reset Sel 263 DB Threshold 264 Comm Write Mode

ArmorStart EtherNet/IP Parameters

Introduction

This chapter describes each programmable parameter and its function.

How to Program Parameters

Each distributed motor controller type has a common set of parameters followed by a set of parameters that pertain to the individual starter type. Parameters 1...100 are common to all ArmorStart devices.

IMPORTANT Parameter value changes take effect immediately unless otherwise noted in the parameter list. These changes may be immediate even during the "running" status.

Bulletin 281E Controller

Basic Status Group

Hdw Inputs This parameter provides status of hardware inputs.	Parameter Number	1
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	15
	Default Value	0

Bit				Function
3	2	1	0	
—	—	—	X	In0
—	—	X	—	In1
—	X	—	—	In2
X	—	—	—	In3

DeviceIn Data This parameter provides status of network device inputs.	Parameter Number	2
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	65535
	Default Value	0

Bit																Function
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Pt00DeviceIn
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	Pt01DeviceIn
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Pt02DeviceIn
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Pt03DeviceIn
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Pt04DeviceIn
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	Pt05DeviceIn
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	Pt06DeviceIn
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	Pt07DeviceIn
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	Pt08DeviceIn
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	Pt09DeviceIn
—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	Pt10DeviceIn
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	Pt11DeviceIn
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt12DeviceIn
—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt14DeviceIn
X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt15DeviceIn

DeviceOut Data This parameter provides status of network device outputs.	Parameter Number	3
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	32767
	Default Value	0

Bit																Function
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Pt00DeviceOut
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	Pt01DeviceOut
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Pt02DeviceOut
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Pt03DeviceOut
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Pt04DeviceOut
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	Pt05DeviceOut
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	Pt06DeviceOut
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	Pt07DeviceOut
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	Pt08DeviceOut
—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	Pt09DeviceOut
—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	Pt10DeviceOut
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	Pt11DeviceOut
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt12DeviceOut
—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt13DeviceOut
X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Reserved

Trip Status This parameter provides trip identification.	Parameter Number	4
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	16383
	Default Value	0

Bit																Function
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Short Circuit
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Overload
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Phase Loss
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	Reserved
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Reserved
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Control Power
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	I/O Fault
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	Over Temperature
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	Phase Imbalance
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	A3 Power Loss
—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	Reserved
—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	Reserved
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	EEPROM
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	HW Fault
X	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Reserved

Starter Status This parameter provides the status of the starter.	Parameter Number	5
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	16383
	Default Value	0

Bit																Function
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	TripPresent
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	WarningPresent
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	RunningForward
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	RunningReverse
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Ready
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Net Ctl Status
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	Reserved
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	At Reference
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	Reserved
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	Reserved
—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	Keypad Hand Mode
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	HOA Status
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	DisconnectClosed
X	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Reserved

InternalLinkStat Status of the internal network connections.	Parameter Number	6
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	31
	Default Value	0

Bit																Function:
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Explicit Connection
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	I/O Connection
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Explicit Fault
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	I/O Fault
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	I/O Idle
X	X	X	X	X	X	X	X	X	X	X	X	—	—	—	—	Reserved

Starter Command The parameter provides the status of the starter command.	Parameter Number	7
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	255
	Default Value	0

Bit								Function:
7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	X	Run Fwd
—	—	—	—	—	—	X	—	Run Rev
—	—	—	—	—	X	—	—	Fault Reset
—	—	—	—	X	—	—	—	Reserved
—	—	—	X	—	—	—	—	Reserved
—	—	X	—	—	—	—	—	Reserved
—	X	—	—	—	—	—	—	OutA
X	—	—	—	—	—	—	—	OutB

Breaker Type This parameter identifies the Bulletin 140M used in this product. 0 = 140M-D8N-C10 1 = 140M-D8N-C25	Parameter Number	22
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Base Enclosure Indicates the ArmorStart Base unit enclosure rating. Bit 0 = IP67 Bit 1 = Reserved Bit 2...15 = Reserved	Parameter Number	56
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	1

Base Options Indicates the options for the ArmorStart Base unit. Bit 0 = Output Fuse Bit 1 = Safety Monitor Bit 2 = CP Fuse Detect Bits 3...7 = Reserved Bit 8 = 10A Base Bit 9 = 25A Base Bit 10...15 = Reserved	Parameter Number	57
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	517
	Default Value	0

Wiring Options Bit 0 = Conduit Bit 1 = Round Media Bit 2 = 28xG Gland Bits 3...15 = Reserved	Parameter Number	58
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	4
	Default Value	0

Starter Enclosure Bit 0 = IP67 Bit 1 = Reserved Bit 2 = Sil3/Cat4 Bit 3...15 = Reserved	Parameter Number	59
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	4
	Default Value	1

Starter Options Bit 0 = Full Keypad Bit 1 = Safety Monitor Bit 2 = Source Brake Bit 3 = Reserved Bit 4 = Reserved Bit 5 = Reserved Bit 6 = Reserved Bit 7 = Reserved Bit 8 = Reserved Bit 9...15 = Reserved	Parameter Number	60
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	66535
	Default Value	0

Last PR Fault 0 = None 1 = Hardware Short Circuit 2 = Software Short Circuit 3 = Motor Overload 4 = Reserved 5 = Phase Loss 6...12 = Reserved 13 = Control Power Loss 14 = Control Power Fuse 15 = I/O Short 16 = Output Fuse 17 = Overtemp 18 = Reserved 19 = Phase Imbalance 20 = Reserved 21 = A3 Power Loss 22 = Internal Comm 23...26 = Reserved 27 = MCB EEPROM 28 = Base EEPROM 29 = Reserved 30 = Wrong Base 31 = Wrong CTs 32...100 = Reserved	Parameter Number	61
	Access Rule	GET
	Data Type	UINT
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	100
	Default Value	0

Warning Status This parameter warns you of a condition, without faulting.	Parameter Number	62
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	65535
	Default Value	0

Warnings are always enabled. The warning conditions are reported even if the corresponding fault conditions are disabled.

Warning bits in the Warning Status parameter are cleared automatically when the warning condition is no longer present.

Bit															Warning	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1		0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Reserved
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	Reserved
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Phase Loss
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	Reserved
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Reserved
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Control Power
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	I/O Warning
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	Reserved
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	Phase Imbalance
—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	A3 Power Loss
—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	Reserved
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	Reserved
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	Reserved
—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Hardware
X	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Reserved

Base Trip The parameter determines the status of the Base Module Trip Status.	Parameter Number	63
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	65535
	Default Value	0

Bit															Warning	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1		0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	EEPROM Fault
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	Internal Comm
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Hardware Fault
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	Control Module
X	X	X	X	X	X	X	X	X	X	X	X	—	—	—	—	Reserved

Produced Assembly Config Group

Int00DeviceOut Cfg This parameter is used to specify Int00DeviceOut of produced assembly 150 or 151.	Parameter Number	13
	Access Rule	GET/SET
	Data Type	USINT
	Group	Produced Assembly Config
	Units	—
	Minimum Value	1
	Maximum Value	108
	Default Value	1

Int01DeviceOut Cfg This parameter is used to specify Int01DeviceOut of produced assembly 150 or 151.	Parameter Number	14
	Access Rule	GET/SET
	Data Type	USINT
	Group	Produced Assembly Config
	Units	—
	Minimum Value	1
	Maximum Value	108
	Default Value	4

Int02DeviceOut Cfg This parameter is used to specify Int02DeviceOut of produced assembly 150 or 151.	Parameter Number	15
	Access Rule	GET/SET
	Data Type	USINT
	Group	Produced Assembly Config
	Units	—
	Minimum Value	1
	Maximum Value	108
	Default Value	5

Int03DeviceOut Cfg This parameter is used to specify Int03DeviceOut of produced assembly 150 or 151.	Parameter Number	16
	Access Rule	GET/SET
	Data Type	USINT
	Group	Produced Assembly Config
	Units	—
	Minimum Value	1
	Maximum Value	108
	Default Value	6

Starter Protection Group

Pr FltReset Mode This parameter configures the Protection Fault reset mode. 0 = Manual 1 = Automatic (Faults are cleared automatically when the fault condition is corrected)	Parameter Number	23
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Pr Fault Enable This parameter enables the Protection Fault by setting the bit to 1.	Parameter Number	24
	Access Rule	GET/SET
	Data Type	WORD
	Group	Starter Protection
	Units	—
	Minimum Value	12419
	Maximum Value	13287
	Default Value	12419

Bit														Function
13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	X	Short Circuit ⁽¹⁾
—	—	—	—	—	—	—	—	—	—	—	—	X	—	Overload ⁽¹⁾
—	—	—	—	—	—	—	—	—	—	—	X	—	—	Phase Loss
—	—	—	—	—	—	—	—	—	—	X	—	—	—	Reserved
—	—	—	—	—	—	—	—	—	X	—	—	—	—	Reserved
—	—	—	—	—	—	—	—	X	—	—	—	—	—	Control Power
—	—	—	—	—	—	—	X	—	—	—	—	—	—	I/O Fault
—	—	—	—	—	—	X	—	—	—	—	—	—	—	Over Temperature ⁽¹⁾
—	—	—	—	—	X	—	—	—	—	—	—	—	—	Phase Imbalance
—	—	—	—	X	—	—	—	—	—	—	—	—	—	A3 Power Loss
—	—	—	X	—	—	—	—	—	—	—	—	—	—	Reserved
—	—	X	—	—	—	—	—	—	—	—	—	—	—	Reserved
—	X	—	—	—	—	—	—	—	—	—	—	—	—	EEPROM ⁽¹⁾
X	—	—	—	—	—	—	—	—	—	—	—	—	—	HW Fault ⁽¹⁾

(1) Cannot be disabled

Pr Fault Reset This parameter resets the Protection Fault on a transition of 0 > 1.	Parameter Number	25
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Str Net FltState This parameter along with Parameter 27 (Str Net FltValue), defines how the starter responds when a fault occurs as determined by Parameter 27. Allows Starter to hold last state or go to FltValue on NetFaults. 0 = Goto Fault Value 1 = Hold Last State	Parameter Number	26
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Str Net FltValue This parameter determines how the starter is commanded if a fault occurs. State the Starter goes to on a Net Flt if Parameter 26 (Str Net FltState) = 0 (Goto Fault Value). 0 = OFF 1 = ON	Parameter Number	27
	Access Rule	GET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Str Net IdlState This parameter along with Parameter 29 (Str Net IdlValue), defines how the starter will respond when a network is idle as determined by Parameter 29. 0 = Goto Idle Value 1 = Hold Last State	Parameter Number	28
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Str Net IdlValue This parameter determines the state that starter assumes when the network is idle and Parameter 28 (Str Net IdlState) is set to "0". 0 = OFF 1 = ON	Parameter Number	29
	Access Rule	GET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

User I/O Configuration Group

Anti-bounce On Delay This parameter lets the installer program a time duration before an input is reported "ON" (Anti-bounce).	Parameter Number	30
	Access Rule	GET/SET
	Data Type	UINT
	Group	User I/O Config.
	Units	ms
	Minimum Value	0
	Maximum Value	65
	Default Value	0

Anti-bounce OFF Delay This parameter lets the installer program a time duration before an input is reported "OFF" (Anti-bounce).	Parameter Number	31
	Access Rule	GET/SET
	Data Type	UINT
	Group	User I/O Config.
	Units	ms
	Minimum Value	0
	Maximum Value	65
	Default Value	0

In Sink/Source This parameter lets the installer program the inputs to be sink or source. 0 = Sink 1 = Source	Parameter Number	32
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutA Pr FltState This parameter along with Parameter 34 (OutA Pr FltValue), defines how Output A will respond when a protection trip occurs. 0 = Goto Pr FltValue 1 = Ignore Pr Flt When set to "1", Output A continues to operate as command via the network. When set to "0", Output A opens or closes as determined by setting in Parameter 34.	Parameter Number	33
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutA Pr FltValue This parameter determines the state the Output A assumes when a trip occurs and Parameter 33 (OutA Pr FltState) is set to "0". 0 = Open 1 = Close	Parameter Number	34
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutA Net FltState This parameter along with Parameter 36 (OutA Net FltValue), defines how Output A will respond when a network fault occurs. 0 = Goto Net FltValue 1 = Hold Last State When set to "1", Output A will hold state before trip occurrence. When set to "0", Output A opens or closes as determined by setting in Parameter 36.	Parameter Number	35
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutA Net FltValue This parameter determines the state that Output A assumes when a network fault occurs and Parameter 35 (OutA Net FltState) is set to "0". 0 = Open 1 = Close	Parameter Number	36
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutA Net IdlState This parameter along with Parameter 38 (OutA Net IdlValue), defines how Output A will respond when the network is idle. 0 = Goto Net IdlValue 1 = Hold Last State When set to "0", Output A opens or closes as determined by the setting in Parameter 38.	Parameter Number	37
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutA Net IdlValue This parameter determines the state that Output A assumes when the network is idle and Parameter 37 (OutA Net IdlState) is set to "0". 0 = Open 1 = Close	Parameter Number	38
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutB Pr FltState</p> <p>This parameter along with Parameter 40 (OutB Pr FltValue), defines how Output B will respond when a protection trip occurs. 0 = Goto PrFlt Value 1 = Ignore PrFlt When set to "1", Output B continues to operate as command via the network. When set to "0", Output B opens or closes as determined by setting in Parameter 40.</p>	Parameter Number	39
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutB Pr FltValue</p> <p>This parameter determines the state the Out B assumes when a protection trip occurs and Parameter 39 (OutB Pr FltState) is set to "0". 0 = Open 1 = Close</p>	Parameter Number	40
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutB Net FltState</p> <p>This parameter along with Parameter 42 (OutB Net FltValue), defines how Output B will respond when a network fault occurs. 0 = Goto Idle Value 1 = Hold Last State When set to "1", Output B will hold state before trip occurrence. When set to "0", Output B opens or closes as determined by setting in Parameter 42.</p>	Parameter Number	41
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutB Net FltValue</p> <p>This parameter determines the state that Output B assumes when a network fault occurs and Parameter 41 (OutB Net FltState) is set to "0". 0 = Open 1 = Close</p>	Parameter Number	42
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutB Net IdlState This parameter along with Parameter 44 (OutB Net IdlValue), defines how Output B will respond when the network is idle. 0 = Goto PrFlt Value 1 = Ignore PrFlt When set to "0", Output B opens or closes as determined by the setting in Parameter 44.	Parameter Number	43
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutB Net IdlValue This parameter determines the state that Output B assumes when the network is idle and Parameter 43 (OutB Net IdlState) is set to "0". 0 = Open 1 = Close	Parameter Number	44
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Miscellaneous Configuration Group

Network Override This parameter lets the local logic override a Network fault. 0 = Disable 1 = Enable	Parameter Number	8
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Comm Override This parameter lets local logic override the absence of an I/O connection. 0 = Disable 1 = Enable	Parameter Number	9
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Keypad Mode This parameter selects if the keypad operation is maintained or momentary. 0 = Maintained 1 = Momentary	Parameter Number	45
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Keypad Disable This parameter disables all keypad function except for the “OFF” and “RESET” buttons. 0 = Not Disabled 1 = Disabled	Parameter Number	46
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Set to Defaults This parameter if set to “1” will set the device to the factory defaults (but will not cause the ArmorStart controller to restart). 0 = No Operation 1 = Set to Defaults	Parameter Number	47
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Starter Display Group (Bulletin 281E Controller Only)

Phase A Current This parameter provides the current of Phase A measured in increments of 1/10 th of an ampere.	Parameter Number	101
	Access Rule	GET/SET
	Data Type	INT
	Group	Starter Display
	Units	xx.x amps
	Minimum Value	0
	Maximum Value	32767
	Default Value	0

Phase B Current This parameter provides the current of Phase B measured in increments of 1/10 th of an ampere.	Parameter Number	102
	Access Rule	GET/SET
	Data Type	INT
	Group	Starter Display
	Units	xx.x amps
	Minimum Value	0
	Maximum Value	32767
	Default Value	0

Phase C Current This parameter provides the current of Phase C measured in increments of 1/10 th of an ampere.	Parameter Number	103
	Access Rule	GET/SET
	Data Type	INT
	Group	Starter Display
	Units	xx.x amps
	Minimum Value	0
	Maximum Value	32767
	Default Value	0

Average Current This parameter provides the average current that is measured in increments of 1/10 th of an ampere.	Parameter Number	104
	Access Rule	GET/SET
	Data Type	INT
	Group	Starter Display
	Units	xx.x amps
	Minimum Value	0
	Maximum Value	32767
	Default Value	0

Therm Utilized This parameter displays the % Thermal Capacity used.	Parameter Number	105
	Access Rule	GET/SET
	Data Type	USINT
	Group	Starter Display
	Units	% FLA
	Minimum Value	0
	Maximum Value	100
	Default Value	0

Starter Set-up Group (Bulletin 281E Controller Only)

FLA Setting The full load current rating of the motor is programmed in this parameter.	Parameter Number	106
	Access Rule	GET/SET
	Data Type	INT
	Group	Starter Setup
	Units	xx.x amps
	Minimum Value	See Table 21.
	Maximum Value	See Table 21.
	Default Value	See Table 21.

Table 21 - FLA Setting Ranges and Default Values (with indicated setting precision)

FLA Current Range (A)		Default Value
Minimum Value	Maximum Value	
0.24	1.2	0.24
0.5	2.5	0.5
1.1	5.5	1.1
3.2	16.0	3.2

Overload Class This parameter lets the installer select the overload class. 1 = Overload Class 10 2 = Overload Class 15 3 = Overload Class 20	Parameter Number	107
	Access Rule	GET/SET
	Data Type	USINT
	Group	Starter Setup
	Units	xx.x amps
	Minimum Value	1
	Maximum Value	3
	Default Value	1

OL Reset Level This parameter lets the installer select the % Thermal Capacity that an overload can be cleared.	Parameter Number	108
	Access Rule	GET/SET
	Data Type	USINT
	Group	Starter Setup
	Units	% FLA
	Minimum Value	0
	Maximum Value	100
	Default Value	75

Bulletin 284E Controller**Basic Status Group**

Hdw Inputs This parameter provides status of hardware inputs.	Parameter Number	1
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	15
	Default Value	0

Bit				Function
3	2	1	0	
—	—	—	X	In0
—	—	X	—	In1
—	X	—	—	In2
X	—	—	—	In3

DeviceIn Data This parameter provides status of network device inputs.	Parameter Number	2
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	65535
	Default Value	0

Bit																Function
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Pt00DeviceIn
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	Pt01DeviceIn
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Pt02DeviceIn
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Pt03DeviceIn
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Pt04DeviceIn
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	Pt05DeviceIn
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	Pt06DeviceIn
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	Pt07DeviceIn
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	Pt08DeviceIn
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	Pt09DeviceIn
—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	Pt10DeviceIn
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	Pt11DeviceIn
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt12DeviceIn
—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt14DeviceIn
X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt15DeviceIn

DeviceOut Data This parameter provides status of network device outputs.	Parameter Number	3
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	32767
	Default Value	0

Bit																Function
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Pt00DeviceOut
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	Pt01DeviceOut
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Pt02DeviceOut
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Pt03DeviceOut
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Pt04DeviceOut
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	Pt05DeviceOut
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	Pt06DeviceOut
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	Pt07DeviceOut
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	Pt08DeviceOut
—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	Pt09DeviceOut
—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	Pt10DeviceOut
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	Pt11DeviceOut
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt12DeviceOut
—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Pt13DeviceOut
X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Reserved

Trip Status This parameter provides trip identification.	Parameter Number	4
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	65535
	Default Value	0

Bit																Function
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Short Circuit
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Overload
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Phase Short
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	Ground Fault
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Stall
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Control Power
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	I/O Fault
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	Over Temperature
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	Over Current
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	A3 Power Loss
—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	Internal Comm ⁽¹⁾
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	DC Bus Fault
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	EEPROM
—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	HW Fault ⁽¹⁾
X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Restart Retries
X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Misc. Fault ⁽¹⁾

(1) See Parameter 61, [Last PR Fault](#), for details.

Starter Status This parameter provides the status of the starter.	Parameter Number	5
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	65535
	Default Value	0

Bit																Function
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	TripPresent
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	WarningPresent
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	RunningForward
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	RunningReverse
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Ready
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Net Ctl Status
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	Net Ref Status
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	At Reference
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	DrvOpto1
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	DrvOpto2
—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	Keypad Jog
—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	Keypad Hand
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	HOA Status
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	Disconnect Closed
—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Contactor 1 ⁽¹⁾
X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Contactor 2 ⁽²⁾

(1) Refers to source brake contactor status

(2) Refers to output contactor status

InternalLinkStat This parameter provides status of the internal network connections.	Parameter Number	6
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	31
	Default Value	0

Bit																Function:
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Explicit Connection
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	I/O Connection
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Explicit Fault
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	I/O Fault
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	I/O Idle
X	X	X	X	X	X	X	X	X	X	X	—	—	—	—	—	Reserved

Starter Command The parameter provides the status of the starter command.	Parameter Number	7
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	255
	Default Value	0

Bit								Function:
7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	X	Run Fwd
—	—	—	—	—	—	X	—	Run Rev
—	—	—	—	—	X	—	—	Fault Reset
—	—	—	—	X	—	—	—	Jog Fwd
—	—	—	X	—	—	—	—	Jog Rev
—	—	X	—	—	—	—	—	Reserved
—	X	—	—	—	—	—	—	OutA
X	—	—	—	—	—	—	—	OutB

Breaker Type This parameter identifies the Bulletin 140M used in this product. 0 = 140M-D8N-C10 1 = 140M-D8N-C25	Parameter Number	22
	Access Rule	GET
	Data Type	BOOL
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	—

Base Enclosure Indicates the ArmorStart Base unit enclosure rating. Bit 0 = IP67 Bits 1 . . . 15 = Reserved	Parameter Number	56
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	—
	Default Value	0

Base Options Indicates the options for the ArmorStart Base unit. Bit 0 = Output Fuse Bit 1 = Safety Monitor Bit 2 = CP Fuse Detect Bits 3 . . . 7 = Reserved Bit 8 = 10A Base Bit 9 = 25A Base Bit 10 . . . 15 = Reserved	Parameter Number	57
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	—
	Default Value	0

Wiring Options Bit 0 = Conduit Bit 1 = Round Media Bits 2 . . . 15 = Reserved	Parameter Number	58
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	—
	Default Value	0

Starter Enclosure Bit 0 = IP67 Bits 1...15 = Reserved	Parameter Number	59
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	—
	Default Value	0

Starter Options Bit 0 = Full Keypad Bit 1 = Safety Monitor Bit 2 = Source Brake Bit 3 = Reserved Bit 4 = Dynamic Brake Bit 5 = Output Contactor Bit 6 = EMI Filter Bit 7 = Reserved Bit 8 = Fused DynBrake Bit 9...15 = Reserved	Parameter Number	60
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	66535
	Default Value	0

Last PR Fault 1 = Hdw Short Ckt 2 = Reserved 3 = Motor Overload (PF Fault Code 7) 4 = Drive Overload (PF Fault Code 64) 5 = Phase U to Gnd (PF Fault Code 38) 6 = Phase V to Gnd (PF Fault Code 39) 7 = Phase W to Gnd (PF Fault Code 40) 8 = Phase UV Short (PF4 Fault Code 41) 9 = Phase UW Short (PF Fault Code 42) 10 = Phase VW Short (PF Fault Code 43) 11 = Ground Fault (PF Fault Code 13) 12 = Stall (PF Fault Code 6) 13 = Control Pwr Loss 14 = Control Pwr Fuse 15 = Input Short 16 = Output Fuse 17 = Over Temp 18 = Heatsink OvrTmp (PF Fault Code 8) 19 = HW OverCurrent (PF Fault Code 12) 20 = SW OverCurrent (PF Fault Code 63) 21 = A3 Power Loss 22 = Internal Comm 23 = Drive Comm Loss (PF Fault Code 81) 24 = Power Loss (PF Fault Code 3) 25 = Under Voltage (PF Fault Code 4) 26 = Over Voltage (PF Fault Code 5) 27 = MCB EEPROM 28 = Base EEPROM 29 = Drive EEPROM (PF Fault Code 100) 30 = Wrong Base 31 = Fan RPM 32 = Power Unit (PF Fault Code 70) 33 = Drive I/O Brd (PF Fault Code 122) 34 = Restart Retries (PF Fault Code 33) 35 = Drive Aux In Flt (PF Fault Code 2) 36 = Analog Input (PF Fault Code 29) 37 = Dry Param Reset (PF Fault Code 48) 38 = SCV Autotune (PF Fault Code 80) 39 = Source Brake 40 = Reserved 41 = DB1 Comm 42 = DB1 Fault 43 = DB Switch Short 45 = Incompatible Drive Firmware	Parameter Number	61
	Access Rule	GET
	Data Type	UINT
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	43
	Default Value	0

Warning Status This parameter warns you of a condition, without faulting.	Parameter Number	62
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	65535
	Default Value	0

Bit																Warning ⁽¹⁾
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Reserved
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	Reserved
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Phase Loss
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	Reserved
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Reserved
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Control Power
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	I/O Warning
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	Reserved
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	Phase Imbalance
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	A3 Power Loss
—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	Reserved
—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	Reserved
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	Reserved
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	Hardware
—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Reserved
X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Miscellaneous ⁽²⁾

(1) The warning is triggered simultaneously, the fault is generated. If the fault is disabled, a warning will still occur.

(2) Includes DB1 Thermal Warning

Base Trip The parameter provides the Base Module Trip Status.	Parameter Number	63
	Access Rule	GET
	Data Type	WORD
	Group	Basic Status
	Units	—
	Minimum Value	0
	Maximum Value	65535
	Default Value	0

Bit																Warning
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	EEPROM Fault
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	Internal Comm
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Hardware Fault
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	Control Module
X	X	X	X	X	X	X	X	X	X	X	X	—	—	—	—	Reserved

Produced Assembly Config Group

Int00DeviceOut Cfg This parameter is used to specify Int00DeviceOut of produced assembly 150 or 151.	Parameter Number	13
	Access Rule	GET/SET
	Data Type	USINT
	Group	Produced Assembly Config
	Units	—
	Minimum Value	1
	Maximum Value	263
	Default Value	1

Int01DeviceOut Cfg This parameter is used to specify Int01DeviceOut of produced assembly 150 or 151.	Parameter Number	14
	Access Rule	GET/SET
	Data Type	USINT
	Group	Produced Assembly Config
	Units	—
	Minimum Value	1
	Maximum Value	263
	Default Value	4

Int02DeviceOut Cfg This parameter is used to specify Int02DeviceOut of produced assembly 150 or 151.	Parameter Number	15
	Access Rule	GET/SET
	Data Type	USINT
	Group	Produced Assembly Config
	Units	—
	Minimum Value	1
	Maximum Value	263
	Default Value	5

Int03DeviceOut Cfg This parameter is used to specify Int03DeviceOut of produced assembly 150 or 151.	Parameter Number	16
	Access Rule	GET/SET
	Data Type	USINT
	Group	Produced Assembly Config
	Units	—
	Minimum Value	1
	Maximum Value	263
	Default Value	6

Starter Protection Group

Pr FltResetMode⁽¹⁾ This parameter is the Protection Fault reset mode. 0 = Manual 1 = Automatic (Faults are cleared automatically when the fault condition is corrected.)	Parameter Number	23
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

(1) When “Pr FltReset Mode” is set to 0=manual mode, and Parameter 192 (Auto Rstrt Tries) is set to allow the drive faults to auto-reset, the “Pr FltReset Mode” takes precedence. In this case, the ArmorStart remains faulted until the fault is manually cleared.

Pr Fault Enable This parameter enables the Protection Fault by setting the bit to 1.	Parameter Number	24
	Access Rule	GET/SET
	Data Type	WORD
	Group	Starter Protection
	Units	—
	Minimum Value	64927
	Maximum Value	65535
	Default Value	64927

Bit															Function	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1		0
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	Short Circuit ⁽¹⁾
—	—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	Overload ⁽¹⁾
—	—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	Phase Loss ⁽¹⁾
—	—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	Ground Fault ⁽¹⁾
—	—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	Stall ⁽¹⁾
—	—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	Control Power
—	—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	I/O Fault
—	—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	Over Temperature ⁽¹⁾
—	—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	Over Current ⁽¹⁾
—	—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	A3 Power Loss
—	—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	Internal Comm ⁽¹⁾
—	—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	DC Bus Fault ⁽¹⁾
—	—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	EEPROM ⁽¹⁾
—	—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	HW Fault ⁽¹⁾
—	X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Restart Retries ⁽¹⁾
X	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	Misc. Fault ⁽¹⁾

(1) Cannot be disabled

Pr Fault Reset This parameter resets the Protection Fault on a transition of 0 > 1.	Parameter Number	25
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Str Net FltState This parameter along with Parameter 27 (Str Net FltValue), defines how the starter will respond when a fault occurs as determined by Parameter 27. 0 = Goto Fault Value 1 = Hold Last State Allows Starter to hold last state or go to FltValue on NetFaults.	Parameter Number	26
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Str Net FltValue This parameter determines how the starter will be commanded if a fault occurs. State the Starter will go to on a Net Flt if Parameter 26 (Str Net FltState) = 0 (Goto Fault Value). 0 = OFF 1 = ON	Parameter Number	27
	Access Rule	GET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Str Net IdlState This parameter along with Parameter 29 (Str Net IdlValue), defines how the starter will respond when a network is idle as determined by Parameter 29. 0 = Goto Idle Value 1 = Hold Last State	Parameter Number	28
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Str Net IdlValue This parameter determines the state that starter assumes when the network is idle and Parameter 28 (Str Net IdlState) is set to "0". 0 = OFF 1 = ON	Parameter Number	29
	Access Rule	GET
	Data Type	BOOL
	Group	Starter Protection
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

User I/O Configuration Group

Anti-bounce On Delay This parameter lets the installer program a time duration before being reported "ON" (Anti-bounce).	Parameter Number	30
	Access Rule	GET/SET
	Data Type	UINT
	Group	User I/O Config.
	Units	ms
	Minimum Value	0
	Maximum Value	65
	Default Value	0

Anti-bounce OFF Delay This parameter lets the installer program a time duration before being reported "OFF" (Anti-bounce).	Parameter Number	31
	Access Rule	GET/SET
	Data Type	UINT
	Group	User I/O Config.
	Units	ms
	Minimum Value	0
	Maximum Value	65
	Default Value	0

In Sink/Source This parameter lets the installer program the inputs to be sink or source. 0 = Sink 1 = Source	Parameter Number	32
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutA Pr FltState This parameter along with Parameter 34 (OutA Pr FltValue), defines how Output A will respond when a trip occurs. 0 = Goto PrFlt Value 1 = Ignore PrFlt When set to "1", Output A continues to operate as command via the network. When set to "0", Output A opens or closes as determined by the setting in Parameter 34.	Parameter Number	33
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutA Pr FltValue</p> <p>This parameter determines the state the Output A assumes when a trip occurs and Parameter 33 (OutA Pr FltState) is set to "0".</p> <p>0 = Open 1 = Close</p>	Parameter Number	34
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutA Net FltState</p> <p>This parameter along with Parameter 36 (OutA Net FltValue), defines how Output A will respond when a network fault occurs.</p> <p>0 = Goto Net FltValue 1 = Hold Last State</p> <p>When set to "1", Output A will hold state before trip occurrence. When set to "0", Output A opens or closes as determined by the setting in Parameter 36.</p>	Parameter Number	35
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutA Net FltValue</p> <p>This parameter determines the state that Output A assumes when a network fault occurs and Parameter 35 (OutA Net FltState) is set to "0".</p> <p>0 = Open 1 = Close</p>	Parameter Number	36
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutA Net IdlState</p> <p>This parameter along with Parameter 38 (OutA Net IdlValue), defines how Output A will respond when the network is idle.</p> <p>0 = Goto Net IdlValue 1 = Hold Last State</p> <p>When set to "0", Output A opens or closes as determined by the setting in Parameter 38.</p>	Parameter Number	37
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutA Net IdlValue This parameter determines the state that Output A assumes when the network is idle and Parameter 37 (OutA Net IdlState) is set to "0". 0 = Open 1 = Close	Parameter Number	38
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutB Pr FltState This parameter along with Parameter 40 (OutB Pr FltValue), defines how Output B will respond when a protection trip occurs. 0 = Goto PrFlt Value 1 = Ignore PrFlt When set to "1", Output B continues to operate as command via the network. When set to "0", Output B opens or closes as determined by setting in Parameter 40.	Parameter Number	39
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutB Pr FltValue This parameter determines the state the Out B assumes when a protection trip occurs and Parameter 39 (OutB Pr FltState) is set to "0". 0 = Open 1 = Close	Parameter Number	40
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

OutB Net FltState This parameter along with Parameter 42 (OutB Net FltValue), defines how Output B will respond when a network fault occurs. 0 = Goto Idle Value 1 = Hold Last State When set to "1", Output B will hold state before trip occurrence. When set to "0", Output B opens or closes as determined by setting in Parameter 42.	Parameter Number	41
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutB Net FltValue</p> <p>This parameter determines the state that Output B assumes when a network fault occurs and Parameter 41 (OutB Net FltState) is set to "0".</p> <p>0 = Open 1 = Close</p>	Parameter Number	42
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutB Net IdlState</p> <p>This parameter along with Parameter 44 (OutB Net IdlValue), defines how Output B will respond when the network is idle.</p> <p>0 = Goto PrFlt Value 1 = Ignore PrFlt</p> <p>When set to "0", Output B opens or closes as determined by the setting in Parameter 44.</p>	Parameter Number	43
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>OutB Net IdlValue</p> <p>This parameter determines the state that Output B assumes when the network is idle and Parameter 43 (OutB Net IdlState) is set to "0".</p> <p>0 = Open 1 = Close</p>	Parameter Number	44
	Access Rule	GET/SET
	Data Type	BOOL
	Group	User I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Miscellaneous Configuration Group

<p>Network Override</p> <p>This parameter lets the local logic override a Network fault.</p> <p>0 = Disable 1 = Enable</p>	Parameter Number	8
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Comm Override This parameter lets local logic override the absence of an I/O connection. 0 = Disable 1 = Enable	Parameter Number	9
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Keypad Mode This parameter selects if the keypad operation is maintained or momentary. 0 = Maintained 1 = Momentary	Parameter Number	45
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Keypad Disable This parameter disables all keypad function except for the “OFF” and “RESET” buttons. 0 = Not Disabled 1 = Disabled	Parameter Number	46
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Set to Defaults This parameter if set to “1” will set the device to the factory defaults (but will not cause the ArmorStart controller to restart). 0 = No Operation 1 = Set to Defaults	Parameter Number	47
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Misc. Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Drive I/O Configuration Group (Bulletin 284E controller only)

Drive Control This parameter provides the status of drive parameters.	Parameter Number	48
	Access Rule	GET
	Data Type	WORD
	Group	Drive I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	4095
	Default Value	0

Bit												Function
11	10	9	8	7	6	5	4	3	2	1	0	
—	—	—	—	—	—	—	—	—	—	—	X	Accel 1 En
—	—	—	—	—	—	—	—	—	—	X	—	Accel 2 En
—	—	—	—	—	—	—	—	—	X	—	—	Decel 1 En
—	—	—	—	—	—	—	X	—	—	—	—	Decel 2 En
—	—	—	—	—	—	—	X	—	—	—	—	Freq Sel 0
—	—	—	—	—	—	X	—	—	—	—	—	Freq Sel 1
—	—	—	—	—	X	—	—	—	—	—	—	Freq Sel 2
—	—	—	—	X	—	—	—	—	—	—	—	Reserved
—	—	—	X	—	—	—	—	—	—	—	—	Drv In 1
—	—	X	—	—	—	—	—	—	—	—	—	Drv In 2
—	X	—	—	—	—	—	—	—	—	—	—	Drv In 3
X	—	—	—	—	—	—	—	—	—	—	—	Drv In 4

DrvIn Pr FltState This parameter, along with Parameter 50 (DrvIn Pr FltValue), defines how the Drive Digital Inputs 1...4 will respond when a protection trip occurs. When set to "1", Drive Digital Inputs 1...4 continue to operate as command via the network. When set to "0", Drive Digital Inputs 1...4 will open or close as determined by setting in Parameter 50. 0 = Go to PrFlt Value 1 = Ignore PrFlt	Parameter Number	49
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Drive I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Drvin Pr FltValue This parameter determines the state of Drive Digital Inputs 1...4, assumes when a trip occurs and Parameter 49 (Drvin Pr FltState) is set to "0". 0 = Open 1 = Close	Parameter Number	50
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Drive I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Drvin Net FltState This parameter, along with Parameter 52 (Drvin Net FltValue), defines how the Drive Digital Inputs 1...4 will respond when a network fault occurs. When set to "1", Drive Digital Inputs 1...4 hold to last state occurs. When set to "0", will go to Drvin Net FltValue as determined by Parameter 52. 0 = Go to Fault Value 1 = Hold Last State	Parameter Number	51
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Drive I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Drvin Net FltValue This parameter determines the state of Drive Digital Inputs 1...4 when a network fault occurs and Parameter 51 (Drvin Net FltState) is set to "0". 0 = OFF 1 = ON	Parameter Number	52
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Drive I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Drvin Net IdlState This parameter, along with Parameter 54 (Drvin Net IdlValue), defines how the Drive Digital Inputs 1...4 will respond when a network is idle. When set to "1", hold to last state occurs. When set to "0", will go to Drvin Net IdlState as determined by Parameter 54. 0 = Go to Fault Value 1 = Hold Last State	Parameter Number	53
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Drive I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

DrvIn Net IdlValue This parameter determines the state that Drive Digital Inputs 1...4 assume when the network is idle and Parameter 53 (DrvIn Net IdlState) is set to "0". 0 = OFF 1 = ON	Parameter Number	54
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Drive I/O Config.
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Drive Display Group (Bulletin 284E controller only)

Output Freq Output frequency present at T1, T2, T3.	Parameter Number	101
	Related Parameters	102, 110, 134, 135, 138
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	0.1 Hz
	Minimum Value	0.0
	Maximum Value	400.0 Hz
	Default Value	Read Only

Commanded Freq Value of the active frequency command. Displays the commanded frequency even if the drive is not running.	Parameter Number	102
	Related Parameters	101, 113, 134, 135, 138
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	0.1 Hz
	Minimum Value	0.0
	Maximum Value	400.0 Hz
	Default Value	Read Only

Output Current Output Current present at T1, T2, T3.	Parameter Number	103
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	0.01
	Minimum Value	0.00
	Maximum Value	Drive rated amps x 2
	Default Value	Read Only

Output Voltage Output Voltage present at T1, T2, T3.	Parameter Number	104
	Related Parameters	131, 184, 188
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	1V AC
	Minimum Value	0
	Maximum Value	480V
	Default Value	Read Only

DC Bus Voltage Present DC Bus voltage level	Parameter Number	105
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	1V DC
	Minimum Value	Based on Drive Rating
	Maximum Value	
	Default Value	Read Only

Drive Status Present operating condition of the drive Bit 0 = Running Bit 1 = Forward Bit 2 = Accelerating Bit 3 = Decelerating	Parameter Number	106
	Related Parameter	195
	Access Rule	GET
	Data Type	Byte
	Group	Drive Display
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	Read Only

Fault 1 Code A code that represents the drive fault. The code appears in this parameter as the most recent fault that has occurred. (See Internal Drive Faults in Chapter 10 for more information).	Parameter Number	107
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	—
	Minimum Value	F2
	Maximum Value	F122
	Default Value	Read Only

Fault 2 Code A code that represents a drive fault. The code appears in this parameter as the second most recent fault that has occurred.	Parameter Number	108
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	—
	Minimum Value	F2
	Maximum Value	F122
	Default Value	Read Only

Fault 3 Code A code that represents a drive fault. The code appears in this parameter as the third most recent fault that has occurred.	Parameter Number	109
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	—
	Minimum Value	F2
	Maximum Value	F122
	Default Value	Read Only

Process Display The output frequency that is scaled by the process factor (Parameter 199).	Parameter Number	110
	Related Parameter	101. 199
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	—
	Minimum Value	0.00
	Maximum Value	9999
	Default Value	Read Only

Control Source Displays the source of the Start Command and Speed Reference. 1 = Internal Frequency 4 = Preset Freq x 5 = Network Control 9 = Jog Freq	Parameter Number	112
	Related Parameters	136, 138, 151...154 (Digital In x Sel) must be set to Option 4, 169, 170...177 (Preset Freq x), 240...247 (StpLogic x)
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	1
	Minimum Value	0
	Maximum Value	9
	Default Value	Read Only

Contrl In Status Status of control inputs. These can be used in DeviceLogix. Bit 0 = Start/Run FWD Input Bit 1 = Direction/Run REV Input Bit 2 = Stop Input Bit 3 = Dynamic Brake Transistor On	Parameter Number	113
	Related Parameter	102, 134, 135
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	1
	Minimum Value	0
	Maximum Value	1
	Default Value	Read Only

Dig In Status Status of the control terminal block digital inputs: Bit 0 = Digital In 1 Sel Bit 1 = Digital In 2 Sel Bit 2 = Digital In 3 Sel Bit 3 = Digital In 4 Sel	Parameter Number	114
	Related Parameter	151...154
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	1
	Minimum Value	0
	Maximum Value	1
	Default Value	Read Only

Comm Status Status of communications ports: Bit 0 = Receiving Data Bit 1 = Transmitting Data Bit 2 = Internal Communications Bit 3 = Communication Error	Parameter Number	115
	Related Parameter	205, 206
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	1
	Minimum Value	0
	Maximum Value	1
	Default Value	Read Only

Elapsed Run Time Accumulated time drive is outputting power. Time is displayed in 10-hour increments.	Parameter Number	118
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	1 = 10 hrs
	Minimum Value	0
	Maximum Value	9999
	Default Value	Read Only

Output Power The output power present at T1, T2, and T3.	Parameter Number	122
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	
	Minimum Value	0.00
	Maximum Value	Drive rated power X 2
	Default Value	Read Only

Output Power Fctr The angle in electrical degrees between motor voltage and current.	Parameter Number	123
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	0.1°
	Minimum Value	0.0°
	Maximum Value	180.0°
	Default Value	Read Only

Drive Temp Present operating temperature of the drive power section.	Parameter Number	124
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	1 °C
	Minimum Value	0
	Maximum Value	120
	Default Value	Read Only

Counter Status The current value of the counter when the counter is enabled.	Parameter Number	125
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	1
	Minimum Value	0
	Maximum Value	9999
	Default Value	Read Only

Timer Status The current value of the timer when timer is enabled.	Parameter Number	126
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	0.1 sec
	Minimum Value	0
	Maximum Value	9999
	Default Value	Read Only

Torque Current The current value of the motor torque current.	Parameter Number	129
	Access Rule	GET
	Data Type	UINT
	Group	Drive Display
	Units	0.01
	Minimum Value	0.00
	Maximum Value	Drive Rated amps x 2
	Default Value	Read Only

Drive Setup Group (Bulletin 284E controller only)

Motor NP Volts  Stop drive before changing this parameter. Set to the motor nameplate rated volts.	Parameter Number	131
	Related Parameters	104, 184, 185...187
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Setup
	Units	1V AC
	Minimum Value	20
	Maximum Value	480V
	Default Value	Based on Drive Rating

Motor NP Hertz  Stop drive before changing this parameter. Set to the motor nameplate rated frequency.	Parameter Number	132
	Related Parameters	184, 185...187, and 190
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Setup
	Units	1 Hz
	Minimum Value	15
	Maximum Value	400
	Default Value	60 Hz

Motor OL Current Set to the maximum allowable current. The drive faults on an F7 Motor Over load if the value of this parameter is exceeded by 150% for 60 s.	Parameter Number	133
	Related Parameter	155, 189, 190, 198, 214, 218, 260...261
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Setup
	Units	0.1 A
	Minimum Value	0.0
	Maximum Value	Drive rated amps x 2
	Default Value	Based on Drive Rating

Minimum Freq Sets the lowest frequency that the drive will output continuously.	Parameter Number	134
	Related Parameter	101, 102, 113, 135, 185...187, 260, 261
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Setup
	Units	0.1 Hz
	Minimum Value	0.0
	Maximum Value	400
	Default Value	0.0

Maximum Freq O Stop drive before changing this parameter. Sets the highest frequency that the drive will output continuously.	Parameter Number	135
	Related Parameter	101, 102, 113, 134, 135, 178, 185...187
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Setup
	Units	0.1 Hz
	Minimum Value	0.0
	Maximum Value	400
	Default Value	60.0

Stop Mode Valid Stop Modes for the Bulletin 284E ArmorStart controller are the following: 0 = Ramp, CF Ramp to Stop. Stop command clears active fault. 1 = Coast, CF Coast to Stop. Stop command clears active fault. 2 = DC Brake, CF DC Injection Braking Stop. Stop command clears active fault. 3 = DCBrkAuto, CF DC injection Braking with Auto Shutoff. Standard DC Injection Braking for value set in Parameter 180 (DC Brake Time) or Drive shuts off if the drive detects that the motor is stopped. Stop command clears active fault. 4 = Ramp , Ramp to Stop 5 = Coast , Coast to Stop 6 = DC Brake , DC Injection Braking Stop 7 = DC BrakeAuto , DC Injection Stop with Auto Shutoff Standard DC Injection Braking for value set in Parameter 180 (DC Brake Time) or Drive shuts off if current limit is exceeded. 8 = Ramp + EM B, CF Ramp to Stop with EM Brake Control. Stop command clears active fault. Ⓢ 9 = Ramp + EM Brk Ramp to Stop with EM Brake Control ⁽¹⁾	Parameter Number	137
	Related Parameters	136, 180...182, 205, 260, 261 ⁽¹⁾
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Setup
	Units	—
	Minimum Value	0
	Maximum Value	9
	Default Value	9

(1) See Parameter [155](#) to set the EM brake actuation condition.

Speed Reference Valid Speed References for the Bulletin 284E ArmorStart controller are the following: 1 = Internal Freq 4 = Preset Freq 5 = Comm Port 9 = Jog Freq	Parameter Number	138
	Related Parameters	101, 102, 112, 139, 140, 151...154, 169, 170...177, 232, 240...247, and 250...257
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Setup
	Units	—
	Minimum Value	0
	Maximum Value	7
	Default Value	5

Accel Time 1 Sets the rate of acceleration for all speed increases. $\frac{\text{Maximum Freq}}{\text{Accel Time}} = \text{Accel Rate}$	Parameter Number	139
	Related Parameters	138, 140, 151...154, 167, 170...177, and 240...247
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Setup
	Units	0.1 sec
	Minimum Value	0.0 sec
	Maximum Value	600.0 sec
	Default Value	10.0 sec

<p>Decel Time 1</p> <p>Sets the rate of deceleration for all speed decreases.</p> $\frac{\text{Maximum Freq}}{\text{Decel Time}} = \text{Decel Rate}$	Parameter Number	140
	Related Parameters	138, 139, 151...154, 168, 170...177, and 240...247
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Setup
	Units	0.1 sec
	Minimum Value	0.1 sec
	Maximum Value	600.0 sec
	Default Value	10.0 sec

<p>Reset To Defaults</p> <p> Stop drive before changing this parameter.</p> <p>Resets all parameter values to factory defaults.</p> <p>0 = Ready/Idle (Default) 1 = Factory Rset</p>	Parameter Number	141
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Drive Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>Motor OL Ret</p> <p>Enables/disables the Motor overload Retention function. When Enabled, the value that is held in the motor overload counter is saved at power-down and restored at power-up. A change to this parameter setting resets the counter.</p> <p>0 = Disabled (Default) 1 = Enabled</p>	Parameter Number	143
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Drive Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Drive Advanced Setup Group (Bulletin 284E controller only)

Digital In 1 SEL (151) Digital In 2 SEL (152) Digital In 3 SEL (153) Digital In 4 SEL (154)	Parameter Number	151...154
	Related Parameters	112, 114, 138...140, 167, 168, 170...179, 240...247
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	See Table 22 for details.
	Minimum Value	
	Maximum Value	
	Default Value	
 Stop drive before changing this parameter. Selects the function for the digital inputs.		

Table 22 - Digital Input Options

Option	Name	Description
1	Acc2 & Dec2	<ul style="list-style-type: none"> When active, Parameter 167 (Accel Time 2) and Parameter 168 (Decel Time 2) are used for all ramp rates except Jog. Can only be tied to one input.
2	Jog	<ul style="list-style-type: none"> When input is present, drive accelerates according to the value set in Parameter 179 (Jog Accel/Decel) and ramps to the value set in Parameter 178 (Jog Frequency). When the input is removed, drive ramps to a stop according to the value set in Parameter 179 (Jog Accel/Decel). A valid Start command will override this input.
4	Preset Freq (Parameters 151 and 152 Default)	See Parameters 170...173 and 174...177.
6	Comm Port	This option is the default setting.
7	Clear Fault	When active, clears active fault.
8	RampStop, CF	Causes drive to immediately ramp to stop regardless of how Parameter 137 (Stop Mode) is set.
9	CoastStop, CF	Causes drive to immediately ramp to stop regardless of how Parameter 137 (Stop Mode) is set.
10	DCInjStop, CF	Causes drive to immediately begin a DC Injection stop regardless of how Parameter 137 (Stop Mode) is set.
11	Jog Forward (Parameter 154 Default)	Drive accelerates to Parameter 178 (Jog Frequency) according to Parameter 179 (Jog Accel/Decel) and ramps to stop when input becomes inactive. A valid start will override this command.
12	Jog Reverse	Drive accelerates to Parameter 178 (Jog Frequency) according to Parameter 179 (Jog Accel/Decel) and ramps to stop when input becomes inactive. A valid start will override this command.
16	MOP Up	Increases the value of Parameter 169 (Internal Freq) at a rate 2 Hz per second. Default of Parameter 169 is 60 Hz.
17	MOP Down	Decreases the value of Parameter 169 (Internal Freq) at a rate 2 Hz per second. Default of Parameter 169 is 60 Hz.
27 ⁽¹⁾	Em Brk Rls	If EM Brake function is enabled, this input releases the brake. See parameter 155 and set to EM Brk Cntrl (22).

(1) Provides programmable control of Em Brk via digital input (1...4)

Relay Out Sel Sets the condition that changes the state of the output relay contacts.	Parameter Number	155
	Related Parameters	133, 156, 192, 240...247, 250...257, 260, 261
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	22
	Default Value	22

Table 23 - Options for the Output Relay Contacts

Options	Name	Description
0	Ready/Fault (Default)	Relay changes state when power is applied, which indicates that the drive is ready for operation. Relay returns drive to shelf state when power is removed or a fault occurs.
1	At Frequency	Drive reached commanded frequency.
6	Above Freq	Drive exceeds the frequency (Hz) value set in Parameter 156 (Relay Out Level) Use Parameter 156 to set threshold.
7	Above Cur	Drive exceeds the current (% amps) value set in Parameter 156 (Relay Out Level) Use Parameter 156 to set threshold.
20	ParamControl	Enables the output to be controlled over the network communications by writing to Parameter 156 (Relay Out Level) (0 = OFF, 1 = ON).
22	EM Brk Cntrl	EM Brake is energized. Program Parameter 260 (EM Brk OFF Delay) and Parameter 261 (EM Brk On Delay) for desired action. ⁽¹⁾


(1) The customer is responsible to make sure that the brake release function operates properly and safely.

Relay Out Level Sets the trip point for the digital output relay if the value of Parameter 155 (Relay Out Sel) is 6, 7, 8, 10, 16, 17, 18, or 20.		Parameter Number	156																		
		Related Parameters	155																		
<table border="1"> <thead> <tr> <th>Parameters 155 Setting</th> <th>Parameter 156 Min./Max.</th> </tr> </thead> <tbody> <tr> <td>6</td> <td>0/400 Hz</td> </tr> <tr> <td>7</td> <td>0/180%</td> </tr> <tr> <td>8</td> <td>0/815V</td> </tr> <tr> <td>10</td> <td>0/100%</td> </tr> <tr> <td>16</td> <td>0.1/9999 sec</td> </tr> <tr> <td>17</td> <td>1/9999 counts</td> </tr> <tr> <td>18</td> <td>1/180°</td> </tr> <tr> <td>20</td> <td>0/1</td> </tr> </tbody> </table>		Parameters 155 Setting	Parameter 156 Min./Max.	6	0/400 Hz	7	0/180%	8	0/815V	10	0/100%	16	0.1/9999 sec	17	1/9999 counts	18	1/180°	20	0/1	Access Rule	GET/SET
		Parameters 155 Setting	Parameter 156 Min./Max.																		
		6	0/400 Hz																		
		7	0/180%																		
		8	0/815V																		
		10	0/100%																		
		16	0.1/9999 sec																		
		17	1/9999 counts																		
		18	1/180°																		
		20	0/1																		
Data Type	UINT																				
Group	Drive Advanced Setup																				
Units	0.1																				
Minimum Value	0.0																				
Maximum Value	9999																				
Default Value	0.0																				

Accel Time 2

When active, sets the rate of acceleration for all speed increases except for jog.

$$\frac{\text{Maximum Freq}}{\text{Accel Time}} = \text{Accel Rate}$$




Parameter Number	167
Related Parameters	139, 151...154, 170...177, 240...247
Access Rule	GET/SET
Data Type	UINT
Group	Drive Advanced Setup
Units	0.1 sec
Minimum Value	0.0
Maximum Value	600.0
Default Value	20.0

Decel Time 2

When active, sets the rate of deceleration for all speed decreases except for jog.

$$\frac{\text{Maximum Freq}}{\text{Decel Time}} = \text{Decel Rate}$$



Parameter Number	168
Related Parameters	140, 151...154, 170...177, 240...247
Access Rule	GET/SET
Data Type	UINT
Group	Drive Advanced Setup
Units	0.1 sec
Minimum Value	0.0
Maximum Value	600.0
Default Value	20.0

Internal Freq

Provide the frequency command to drive when Parameter 138 (Speed Reference) is set to "1" (Internal Freq). When enabled, this parameter will change the frequency command in real time.

Parameter Number	169
Related Parameters	138
Access Rule	GET/SET
Data Type	UINT
Group	Drive Advanced Setup
Units	0.1 Hz
Minimum Value	0.0
Maximum Value	400.0
Default Value	60.0

170 (Preset Freq 0) 171 (Preset Freq 1) 172 (Preset Freq 2) 173 (Preset Freq 3) 174 (Preset Freq 4) 175 (Preset Freq 5) 176 (Preset Freq 6) 177 (Preset Freq 7) Provides a fixed frequency command value when Parameters 151...154 (Digital In x Sel) is set to Option 4 (Preset Frequencies).	Parameter Number	170...173, 174...177
	Related Parameters	138...140, 151...154, 167, 168, 240...247, 250...257
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 Hz
	Minimum Value	0.0
	Maximum Value	400.0
	Default Value	See Table 24

Table 24 - Parameters 170...177 Preset Freq Options

	170 Default	0.0 Hz
	171 Default	5.0 Hz
	172 Default	10.0 Hz
	173 Default	20.0 Hz
	174 Default	30.0 Hz
	175 Default	40.0 Hz
	176 Default	50.0 Hz
	177 Default	60.0 Hz
	Min./Max.	0.0/400.0 Hz
	Display	0.1 Hz

Input State of Digital In 1 (I/O Terminal 05 when Parameter 151 = 4)	Input State of Digital In 2 (I/O Terminal 06 when Parameter 152 = 4)	Input State of Digital In 3 (I/O Terminal 07 when Parameter 153 = 4)	Frequency Source	Accel/Decel Parameter Used ⁽¹⁾
0	0	0	170 (Preset Freq 0)	(Accel Time 1)/(Decel Time 1)
1	0	0	171 (Preset Freq 1)	(Accel Time 1)/(Decel Time 1)
0	1	0	172 (Preset Freq 2)	(Accel Time 2)/(Decel Time 2)
1	1	0	173 (Preset Freq 3)	(Accel Time 2)/(Decel Time 2)
0	0	1	174 (Preset Freq 4)	(Accel Time 3)/(Decel Time 3)
1	0	1	175 (Preset Freq 5)	(Accel Time 3)/(Decel Time 3)
0	1	1	176 (Preset Freq 6)	(Accel Time 4)/(Decel Time 4)
1	1	1	177 (Preset Freq 7)	(Accel Time 4)/(Decel Time 4)

(1) When a Digital Input is set to "Accel 2 and Decel 2", and the input is active, that input overrides the settings in this table.

Jog Frequency Sets the output frequency when the jog command is issued.	Parameter Number	178
	Related Parameters	135, 151...154, 179
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 Hz
	Minimum Value	0.0
	Maximum Value	400.0
	Default Value	10.0


Jog Accel/Decel Sets the acceleration and deceleration time when a jog command is issued.	Parameter Number	179
	Related Parameters	151...154, 178
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 sec
	Minimum Value	0.1
	Maximum Value	600.0
	Default Value	10.0

DC Brake Time Sets the length of time that DC brake current is injected into the motor. See Parameter 181 (DC Brake Level).	Parameter Number	180
	Related Parameters	137, 181
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 sec
	Minimum Value	0.0
	Maximum Value	99.9 (Setting of 99.9 = Continuous)
	Default Value	0.0

DC Brake Level Defines the maximum DC brake current, in amps, applied to the motor when Parameter 137 (Stop Mode) is set to either "Ramp" or "DC Brake".	Parameter Number	181
	Related Parameters	137, 180
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 A
	Minimum Value	0.0
	Maximum Value	Drive rated amps X 1.8
	Default Value	Drive rated amps X 0.05



ATTENTION:




- If a hazard of injury due to movement of equipment or material exists, an auxiliary mechanical braking device must be used.
- This feature must not be used with synchronous or permanent magnet motors. Motors may be demagnetized during braking.

DB Resistor Sel		Parameter Number	182
		Related Parameters	137
Stop drive before changing this parameter. Enables/disables external dynamic braking.		Access Rule	GET/SET
		Data Type	UINT
Setting	Min./Max.	Group	Drive Advanced Setup
0	Disabled	Units	1
1	Normal RA Res (5% Duty Cycle)	Minimum Value	0
2	No Protection (100% Duty Cycle)	Maximum Value	99
3...99	x% Duty Cycle Limited (3...99% of Duty Cycle)	Default Value	0

S Curve % Sets the percentage of acceleration or deceleration time that is applied to ramp as S Curve. Time is added, half at the beginning and half at the end of the ramp.	Parameter Number	183
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	1%
	Minimum Value	0
	Maximum Value	100
	Default Value	0% disabled

Figure 63 - S Curve

Example:
 Accel Time = 10 Seconds
 S Curve Setting = 50%
 S Curve Time = 10 x 0.5 = 5 Seconds
 Total Time = 10 + 5 = 15 Seconds




Boost Select Sets the boost voltage (% of Parameter 131 (Motor NP Volts)) and redefines the Volts per Hz curve. Active when Parameter 225 (Torque Perf Mode) = 0 (V/Hz). Drive may add additional voltage unless Option 5 is selected. See Table 25 for details.	Parameter Number	184
	Related Parameters	104, 131, 132, 185...187, 225
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	14
	Default Value	8

Table 25 - Boost Select Options


Options	Description
0	Custom V/Hz
1	30.0, VT
2	35.0, VT
3	40.0, VT
4	45.0, VT
5	0.0 no IR
6	0.0
7	2.5, CT (default for 5 Hp/4.0 kW Drive)
8	5.0, CT (default)
9	7.5, CT
10	10.0, CT
11	12.5, CT
12	15.0, CT
13	17.5, CT
14	20.0, CT

Figure 64 - Boost Select



<p>Start Boost</p> <p>Sets the boost voltage (% of Parameter 131 (Motor NP Volts) and redefines the Volts per Hz curve when Parameter 184 (Boost Select) = 0 (Custom V/Hz) and Parameter 225 (Torque Perf Mode) = 0 (V/Hz)</p>	Parameter Number	185
	Related Parameters	131, 132, 134, 135, 184, 186...188, 225
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	1.1%
	Minimum Value	0.0%
	Maximum Value	25.0%
	Default Value	2.5%

Figure 65 - Start Boost



<p>Brake Voltage</p> <p>Sets the frequency where brake voltage is applied when Parameter 184 (Boost Select) = 0 (Custom V/Hz) and Parameter 225 (Torque Perf Mode) = 0 (V/Hz).</p>	Parameter Number	186
	Related Parameters	131, 132, 134, 135, 184, 185, 187, 188, 225
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	1.1%
	Minimum Value	0.0%
	Maximum Value	100.0%
	Default Value	25.0%


<p>Brake Frequency</p> <p>Sets the frequency where brake frequency is applied when Parameter 184 (Boost Select) = 0 (Custom V/Hz) and Parameter 225 (Torque Perf Mode) = 0 (V/Hz).</p>	Parameter Number	187
	Related Parameters	131, 132, 134, 135, 184, 185, 186, 188, 225
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 Hz
	Minimum Value	0.0 Hz
	Maximum Value	400.0 Hz
	Default Value	15.0 Hz

Maximum Voltage Sets the highest voltage that the drive will output.	Parameter Number	188
	Related Parameters	104, 185, 186, 187
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	1V AC
	Minimum Value	20V AC
	Maximum Value	Drive Rated Volts
	Default Value	Drive Rated Volts

Current Limit 1 Maximum output current that is allowed before current limiting occurs	Parameter Number	189
	Related Parameters	133, 218
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 A
	Minimum Value	0.1 A
	Maximum Value	Drive rated amps X 1.8
	Default Value	Drive rated amps X 1.5


Motor OL Select Drive provides Class 10 motor overload protection. Settings 0...2, select the derating factor for I^2t overload function. 0 = No Derate 1 = Min. Derate 2 = Max. Derate	Parameter Number	190
	Related Parameters	132, 133
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	1
	Minimum Value	0
	Maximum Value	2
	Default Value	0

Figure 66 - Overload Trip Curves



PWM Frequency Sets the carrier frequency for the PWM output waveform. The Figure 67 provides derating guidelines that are based on the PWM frequency setting.	Parameter Number	191
	Related Parameters	224
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 Hz
	Minimum Value	2.0 Hz
	Maximum Value	16.0 Hz
	Default Value	4.0 Hz

Figure 67 - Derating Guidelines that are Based on the PWM Frequency Setting



Auto Rstrt Tries Set the maximum number of times the drive attempts to reset a fault and restart.	Parameter Number	192
	Related Parameter	155, 193
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	1
	Minimum Value	0
	Maximum Value	9
	Default Value	0

Clear a Type 1 Fault and Restart the Drive

1. Set Parameter 192 (Auto Rstrt Tries) to a value other than 0.
2. Set Parameter 193 (Auto Rstrt Delay) to a value other than 0.

Clear an Overvoltage, Undervoltage, or Heatsink OvrTmp Fault without Restarting the Drive

1. Set Parameter 192 (Auto Rstrt Tries) to a value other than 0.
2. Set Parameter 193 (Auto Rstrt Delay) to 0.



ATTENTION: Equipment damage and/or personal injury can result if this parameter is used in an inappropriate application. Do not use this function without review of applicable local, national, and international codes, standards, regulations, or industry guidelines.

Auto Rstrt Delay Sets time between restart attempts when Parameter 192 (Auto Rstrt Tries) is set to a value other than zero.	Parameter Number	193
	Related Parameters	192
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 sec
	Minimum Value	0.0
	Maximum Value	300.0 sec
	Default Value	1.0 sec

Start at PowerUp Stop drive before changing this parameter. Enables/disables a feature that lets a Start or Run command automatically cause the drive to resume running at command speed after the drive input is restored. Requires a digital input configured Run or Start and a valid start contact. 0 = Disabled 1 = Enabled	Parameter Number	194
	Related Parameters	192
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0



ATTENTION: Equipment damage and/or personal injury may result if this parameter is used in an inappropriate application. Do not use this function without considering applicable local, national, and international codes, standards, regulations, or industry guidelines.

Reverse Disable Stop drive before changing this parameter. Enables/disables the function that lets the direction of the motor rotation be changed. The reverse command may come from a digital command or serial command. All reverse inputs including two-wire Run Reverse will be ignored with reverse disabled. 0 = Disabled 1 = Enabled	Parameter Number	195
	Related Parameters	106
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Flying Start En Sets the condition that lets the drive reconnect to a spinning motor at actual RPM. 0 = Disabled 1 = Enabled	Parameter Number	196
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Compensation Enables/disables correction options that may improve problems with motor instability, 0 = Disabled 1 = Electrical (Default) Some drive/motor combinations have inherent instabilities that are exhibited as non-sinusoidal motor currents. This setting attempts to correct this condition 2 = Mechanical Some motor/load combinations have mechanical resonances that can be excited by the drive current regulator. This setting slows down the current regulator response and attempts to correct this condition. 3 = Both	Parameter Number	197
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	3
	Default Value	1

SW Current Trip Enables/disables a software instantaneous (within 100 ms) current trip.	Parameter Number	198
	Related Parameters	133
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 A
	Minimum Value	0.0
	Maximum Value	Drive rated amps x 2
	Default Value	0.0 (Disabled)

Process Factor Scales the output frequency value that is displayed by Parameter 110 (Process Display). Output Freq x Process Factor = Process Display	Parameter Number	199
	Related Parameters	110
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1
	Minimum Value	0.1
	Maximum Value	999.9
	Default Value	30.0

Fault Clear Stop drive before changing this parameter. Resets a fault and clears the fault queue. Used primarily to clear a fault over network communications. 0 = Ready/Idle (Default) 1 = Reset Fault 2 = Clear Buffer (Parameters 107...109 (Fault x Code))	Parameter Number	200
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	2
	Default Value	0

Program Lock Protects parameters against change by unauthorized personnel. 0 = Unlocked 1 = Locked	Parameter Number	201
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

Comm Loss Action Selects the drive's response to a loss of the communication connection or excessive communication errors. 0 = Fault (Default) Drive will fault on an F81 Comm Loss and coast to stop 1 = Coast Stop Stops drive via coast to stop 2 = Stop Stops via Parameter 137 (Stop Mode) setting 3 = Continue Last Drive continues operating at communication commanded speed that is saved in RAM.	Parameter Number	205
	Related Parameters	115, 137, 206
	Access Rule	GET/SET
	Data Type	UINT
	Group	Advanced Program Group
	Units	—
	Minimum Value	0
	Maximum Value	3
	Default Value	0

Comm Loss Time Sets the time that the drive remains in communication loss before implanting the option selected in Parameter 205 (Comm Loss Action).	Parameter Number	206
	Related Parameters	115, 205
	Access Rule	GET/SET
	Data Type	UINT
	Group	Advanced Program Group
	Units	0.1 sec
	Minimum Value	0.1 sec
	Maximum Value	60.0 sec
	Default Value	15.0 sec

Slip Hertz @ FLA Compensates for the inherent slip in an induction motor. This frequency is added to the commanded output frequency based on motor current.	Parameter Number	214
	Related Parameters	133
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 Hz
	Minimum Value	0.0 Hz
	Maximum Value	10.0 Hz
	Default Value	2.0 Hz

Process Time Lo Scales the time value when the drive is running at Parameter 134 (Minimum Freq). When set to a value other than zero, Parameter 110 (Process Display) indicates the duration of the process.	Parameter Number	215
	Related Parameters	110, 134
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	Hz
	Minimum Value	0.00
	Maximum Value	99.99
	Default Value	0.00

Process Time Hi Scales the time value when the drive is running at Parameter 135 (Maximum Freq). When set to a value other than zero, Parameter 110 (Process Display) indicates the duration of the process.	Parameter Number	216
	Related Parameters	110, 135
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	Hz
	Minimum Value	0.0
	Maximum Value	99.99
	Default Value	0.00


Bus Reg Mode Enables the bus regulator. 0 = Disable 1 = Enabled	Parameter Number	217
	Related Parameters	—
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	1

Current Limit 2 Maximum output current that is allowed before current limiting occurs. This parameter is only active if Parameters 151...154 (Digital In x Sel) is set to Option 25 (Current Lmt2) and is active.	Parameter Number	218
	Related Parameters	133, 151...154, 189
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 A
	Minimum Value	0.0 A
	Maximum Value	Drive rated amps x 1.8
	Default Value	Drive rated amps x 1.5

Skip Frequency Sets the frequency at which the drive will not operate.	Parameter Number	219
	Related Parameters	220
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 Hz
	Minimum Value	0.0
	Maximum Value	400.0 Hz
	Default Value	0.0 Hz

Skip Freq Band Determines the bandwidth around Parameter 219 (Skip Frequency). Parameter 220 (Skip Freq Band) is split applying 1/2 above and 1/2 below the actual skip frequency. A setting of 0.0 disables this parameter.	Parameter Number	220
	Related Parameters	219
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 Hz
	Minimum Value	0.0 Hz
	Maximum Value	30.0 Hz
	Default Value	0.0 Hz

Figure 68 - Skip Frequency Band



Stall Fault Time Sets for the fault time that the drive will remain in stall mode before a fault is issued. 0 = 60 sec (Default) 1 = 120 sec 2 = 240 sec 3 = 360 sec 4 = 480 sec 5 = Flt Disabled	Parameter Number	221
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	5
	Default Value	0

<p>Var PWM Disable</p> <p>Stop drive before changing this parameter.</p> <p>Enables/disables a feature that varies the carrier frequency for the PWM output waveform that is defined by Parameter 191 (PWM Frequency).</p> <p>0 = Enabled 1 = Disabled</p> <p>Disabling this feature when low frequency condition exists may result in IGBT stress and nuisance tripping.</p>	Parameter Number	224
	Related Parameters	191
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0

<p>Torque Perf Mode</p> <p>Stop drive before changing this parameter.</p> <p>Enables/disables sensorless vector control operation.</p> <p>0 = V/Hz 1 = Sensrls Vect</p>	Parameter Number	225
	Related Parameters	184...187, 227
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	1

Motor NP FLA Set to the motor nameplate full load amps.	Parameter Number	226
	Related Parameters	
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1 A
	Minimum Value	0.1
	Maximum Value	Drive rated amps x 2
	Default Value	Drive rated amps

Autotune Stop drive before changing this parameter. Provides an automatic method for setting Parameter 228 (IR Voltage Drop) and Parameter 229 (Flux Current Ref), that affect sensorless vector performance. Parameter 226 (Motor NP FLA) must be set to the motor nameplate full load amps before running the Autotune procedure. 0 = Ready/Idle (Default) 1 = Static Tune 2 = Rotate Tune Ready (0) – Parameter returns to this setting following a Static Tune or Rotate Tune. Static Tune (1) – A temporary command that initiates a non-rotational motor stator resistance test for the best possible automatic setting of Parameter 228 (IR Voltage Drop). A start command is required within 30 seconds of setting this parameter following initiation of this setting. The parameter returns to Ready (0) following the test, at which time another start transition is required to operate the drive in normal mode. Used when motor cannot be uncoupled from the load. Rotate Tune (2) – A temporary command that initiates a Static Tune followed by a rotational test for the best possible automatic setting of Parameter 229 (Flux Current Ref). A start command is required following initiation of this setting. The parameter returns to Ready (0) following the test, at which time another start transition is required to operate the drive in normal mode.	Parameter Number	227
	Related Parameters	225, 226, 228, 229
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	3
	Default Value	0



ATTENTION: Rotation of the motor in an undesired direction can occur during this procedure. To guard against possible injury and/or equipment damage, we recommend to disconnect the motor from the load before you continue.

IMPORTANT Used when motor is uncoupled from the load. Results may not be valid if a load is coupled to the motor during this procedure. Applies to rotate tune only.


If the Autotune routine fails, an F80 SVC Autotune fault is displayed.

IR Voltage Drop Value of volts dropped across the resistance of the motor stator.	Parameter Number	228
	Related Parameters	227
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.1V AC
	Minimum Value	0.0
	Maximum Value	230
	Default Value	Based on Drive Rating

Flux Current Ref Value of amps for full motor flux.	Parameter Number	229
	Related Parameter	227
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	0.01 A
	Minimum Value	0.00
	Maximum Value	Motor NP Volts
	Default Value	Based on Drive Rating

EM Brk OFF Delay Sets the time that the drive will remain at minimum frequency before ramping to the commanded frequency and energizing the brake coil relay when Parameter 137 (Stop Mode) is set to Option 8 or 9.	Parameter Number	260
	Related Parameters	134, 137
	Access Rule	GET/SET
	Data Type	UNIT
	Group	Drive Advanced Setup
	Units	0.01 sec
	Minimum Value	0.01 sec
	Maximum Value	10 sec
	Default Value	0.0 sec

Figure 69 - EM Brk OFF Delay



<p>EM Brk On Delay</p> <p>Sets the time that the drive will remain at minimum frequency before stopping and de-energizing the brake coil relay when Parameter 137 (Stop Mode) is set to Option 8 or 9.</p>	Parameter Number	261
	Related Parameters	134, 137
	Access Rule	GET/SET
	Data Type	UNIT
	Group	Drive Advanced Setup
	Units	0.01 sec
	Minimum Value	0.01 sec
	Maximum Value	10.00 sec
	Default Value	0.0 sec

<p>MOP Reset Sel</p> <p>Sets the drive to save the current MOP Reference command. 0 = Zero MOP Ref This option clamps Parameter 169 (Internal Freq) at 0.0 Hz when drive is not running. 1 = Save MOP Ref (Default) Reference is saved in Parameter 169 (Internal Freq).</p>	Parameter Number	262
	Related Parameters	169
	Access Rule	Get/Set
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	1

<p>DB Threshold</p> <p>Sets the DC bus Voltage Threshold for Dynamic Brake operation. If the DC bus voltage falls below the value set in this parameter, the Dynamic Brake will not turn on. Lower values will make the Dynamic Braking function more responsive, but may result in nuisance Dynamic Brake activation.</p>	Parameter Number	263
	Access Rule	GET/SET
	Data Type	UINT
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0.0%
	Maximum Value	110.0%
	Default Value	100%



ATTENTION: Equipment damage can result if this parameter is set to a value that causes the dynamic braking resistor to dissipate excessive power. Parameter settings less than 100% must be carefully evaluated to make sure that wattage rating of the dynamic brake resistors is not exceeded. In general, values less than 90% are not needed. This parameter setting is especially important if Parameter 182 (DB Resistor Sel) is set to “2” (No Protection).

Comm Write Mode Determines whether the parameter changes that were made over the communication port are saved and stored in Non-Volatile Storage (NVS) or RAM only. If they are stored in RAM, the values will be lost at power-down. 0 = Save (Default) 1 = RAM Only	Parameter Number	264
	Access Rule	GET/SET
	Data Type	BOOL
	Group	Drive Advanced Setup
	Units	—
	Minimum Value	0
	Maximum Value	1
	Default Value	0



ATTENTION: Risk of equipment damage exists. If a controller is programmed to write parameter data to Non-Volatile Storage (NVS) frequently, the NVS will quickly exceed its lifecycle and cause the drive to malfunction. Do not create a program that frequently uses configurable outputs to write parameter data to NVS unless Parameter 264 (Comm Write Mode) is set to Option 1.

Linear List of Parameters for Bulletins 281E and 284E

Table 26 - ArmorStart Parameters

Parameter Number	Parameter Name	Description	Factory Default	Group	Controller
1	Hdw Inputs	This parameter provides status of hardware inputs.	0	Basic Status	Common
2	Network Inputs	This parameter provides status of network inputs.	0	Basic Status	Common
3	Network Outputs	This parameter provides status of network outputs.	0	Basic Status	Common
4	Trip Status	This parameter provides trip identification.	0	Basic Status	Common
5	Starter Status	This parameter provides the status of the starter.	0	Basic Status	Common
6	InternalLinkStat	Status of the internal network connections.	0	Basic Status	Common
7	Starter Command	The parameter provides the status of the starter command.	0	Basic Status	Common
8	Network Override	This parameter lets the local logic override a Network fault.	0	Misc. Configuration	Common
9	Comm Override	This parameter lets local logic override an absence of an I/O connection.	0	Misc. Configuration	Common
13	Prod Assy Word 0	This parameter is used to build bytes 0 . . . 1 for produced assembly 150 or 151.	1	Network Configuration	Common
14	Prod Assy Word 1	This parameter is used to build bytes 2 . . . 3 for produced assembly 150 or 151.	1	Network Configuration	Common
15	Prod Assy Word 2	This parameter is used to build bytes 4 . . . 5 for produced assembly 150 or 151.	1	Network Configuration	Common
16	Prod Assy Word 3	This parameter is used to build bytes 6 . . . 7 for produced assembly 150 or 151.	1	Network Configuration	Common
22	Breaker Type	This parameter identifies the Bulletin 140M used in this product.	0 = 140M-D8N-C10	Basic Status	Common
23	Pr FltReset Mode	This parameter configures the Protection Fault reset mode.	0 = Manual	Starter Protection	Common
24	Pr Fault Enable	This parameter enables the Protection Fault by setting the bit to 1.	12419	Starter Protection	Common
25	Pr Fault Reset	This parameter resets the Protection Fault on a transition 0 > 1.	0	Starter Protection	Common
26	Str Net FltState	This parameter along with Parameter 27 (Str Net FltValue), defines how the starter will respond when a fault occurs as determined by Parameter 27.	0 = Goto Fault Value	Starter Protection	Common
27	Str Net FltValue	This parameter determines how the starter will be commanded if a fault occurs.	0 = OFF	Starter Protection	Common
28	Str Net IdlState	This parameter determines response when Idle fault occurs.	0 = Goto Fault Value	Starter Protection	Common
29	Str Net IdlValue	This parameter determines the state that starter assumes when the network is idle and Parameter 28 (Str Net IdlState) is set to "Goto Fault Value".	0 = OFF	Starter Protection	Common
30	Off-to-On Delay	This parameter lets the installer program a time duration before being reported ON.	0	User I/O Configuration	Common
31	On-to-Off Delay	This parameter lets the installer program a time duration before being reported OFF.	0	User I/O Configuration	Common
32	In Sink/Source	This parameter lets the installer program the inputs to be sink or source.	0 = Sink	User I/O Configuration	Common
33	OutA Pr FltState	This parameter along with Parameter 34 (OutA Pr FltValue), defines how Output A will respond when a trip occurs.	0 = Goto PrFlt Value	User I/O Configuration	Common
34	OutA Pr FltValue	This parameter determines the state the Output A.	0 = Open	User I/O Configuration	Common

Table 26 - ArmorStart Parameters

Parameter Number	Parameter Name	Description	Factory Default	Group	Controller
35	OutA Net FltState	This parameter along with Parameter 36 (OutA Net FltValue), defines how Output A will respond.	0 = Goto Fault Value	User I/O Configuration	Common
36	OutA Net FltValue	This parameter determines the state that Output A assumes when the network is idle.	0 = Open	User I/O Configuration	Common
37	OutA Net IdlState	This parameter along with Parameter 38 (OutA Net IdlValue), defines how Output A will respond when the network is idle.	0 = Goto Idle Value	User I/O Configuration	Common
38	OutA Net IdlValue	This parameter determines the state that Output A assumes when the network is idle and Parameter 37 (OutA Net IdlState) is set to "0".	0 = Open	User I/O Configuration	Common
39	OutB Pr FltState	This parameter along with Parameter 40 (OutB Pr FltValue), defines how Output B will respond when a protection trip occurs.	0 = Goto PrFlt Value	User I/O Configuration	Common
40	OutB Pr FltValue	This parameter determines the state the Out B assumes when a protection trip occurs and Parameter 39 (OutB Pr FltState) is set to "0".	0 = Open	User I/O Configuration	Common
41	OutB Net FltState	This parameter along with Parameter 42 (OutB Net FltValue), defines how Output B will respond when a network fault occurs.	0 = Goto Idle Value	User I/O Configuration	Common
42	OutB Net FltValue	This parameter determines the state that Output B assumes when a network fault occurs and Parameter 41 (OutB Net FltState) is set to "0".	0 = Open	User I/O Configuration	Common
43	OutB Net IdlState	This parameter along with Parameter 44 (OutB Net IdlValue), defines how Output B will respond when the network is idle.	0 = Goto PrFlt Value	User I/O Configuration	Common
44	OutB Net IdlValue	This parameter determines the state that Output B assumes when the network is idle and Parameter 43 (OutB Net IdlState) is set to "0".	0 = Open	User I/O Configuration	Common
45	Keypad Mode	This parameter selects if the keypad operation is maintained or momentary.	0 = Maintained	Misc. Configuration	Common
46	Keypad Disable	This parameter disables all keypad function except for the OFF and RESET buttons.	0 = Not Disabled	Misc. Configuration	Common
47	Set To Defaults	This parameter if set to 1 will set the device to the factory defaults.	0 = No Operation	Misc. Configuration	Common
48	Drive Control	This parameter provides the status of drive parameters.	0	Drive I/O Configuration	284E
49	DrvIn Pr FltState	This parameter, along with Parameter 50 (DrvIn Pr FltValue), defines how the Drive Digital Inputs 1...4 will respond when a protection trip occurs.	0 = Go to PrFlt Value	Drive I/O Configuration	284E
50	DrvIn Pr FltValue	This parameter determines the state of Drive Digital Inputs 1...4, assumes when a trip occurs.	0 = Open	Drive I/O Configuration	284E
51	DrvIn Net FltState	This parameter, along with Parameter 52 (DrvIn Net FltValue), defines how the Drive Digital Inputs 1...4 will respond when a network fault occurs.	0 = Go to Fault Value	Drive I/O Configuration	284E
52	DrvIn Net FltValue	This parameter determines the state of Drive Digital Inputs 1...4 when a network fault occurs and Parameter 51 (DrvIn Net FltState) is set to "0".	0 = OFF	Drive I/O Configuration	284E
53	DrvIn Net IdlState	This parameter, along with Parameter 54 (DrvIn Net FltValue), defines how the Drive Digital Inputs 1...4 will respond when a DeviceNet™ network is idle.	0 = Go to Fault Value	Drive I/O Configuration	284E
54	DrvIn Net FltValue	This parameter determines the state that Drive Digital Inputs 1...4 assume when the network is idle and Parameter 53 (DrvIn Net FltState) is set to "0".	0 = OFF	Drive I/O Configuration	284E
56	Base Enclosure	Indicates the ArmorStart Base unit enclosure rating.	1	Basic Status	Common

Table 26 - ArmorStart Parameters

Parameter Number	Parameter Name	Description	Factory Default	Group	Controller
57	Base Options	Indicates the options for the ArmorStart Base unit.	0	Basic Status	Common
58	Wiring Options	This parameter provides the Wiring Options.	0	Basic Status	Common
59	Starter Enclosure	This parameter provides the Starter Enclosure.	1	Basic Status	Common
60	Starter Options	This parameter provides the Starter Options.	0	Basic Status	Common
61	Last PR Fault	This parameter provides the Last PR Fault.	0 = None	Basic Status	Common
62	Warning Status	This parameter provides the Warning Status.	0	Basic Status	Common
63	Base Trip	This parameter provides the Base Module Trip Status.	0	Basic Status	Common
101	Phase A Current	This parameter provides the current of Phase A.	0	Starter Display	DOL
102	Phase B Current	This parameter provides the current of Phase B.	0	Starter Display	DOL
103	Phase C Current	This parameter provides the current of Phase C.	0	Starter Display	DOL
104	Average Current	This parameter provides the average current.	0	Starter Display	DOL
105	Therm Utilized	This parameter displays the % Thermal Capacity used.	0	Starter Display	DOL
106	FLA Setting	The full load current rating of the motor	See Table 21.	Starter Setup	DOL
107	Overload Class	Selects the overload class.	1 = Overload Class 10	Starter Setup	DOL
108	OL Reset Level	Selects the % Thermal Capacity that an overload can be cleared.	75	Starter Setup	DOL
101	Output Freq	Output frequency present at T1, T2 & T3 (U, V & W)	Read Only	Drive Display	284E
102	Commanded Freq	Value of the active frequency command	Read Only	Drive Display	284E
103	Output Current	Output current present at T1, T2 & T3 (U, V & W)	Read Only	Drive Display	284E
104	Output Voltage	Output voltage present at T1, T2 & T3 (U, V & W)	Read Only	Drive Display	284E
105	DC Bus Voltage	Present DC bus voltage level	Read Only	Drive Display	284E
106	Drive Status	Present operating condition of the drive.	Read Only	Drive Display	284E
107...109	Fault x Code	A code that represents a drive fault.	Read Only	Drive Display	284E
110	Process Display	The output frequency that is scaled by Parameter 199 (Process Factor).	Read Only	Drive Display	284E
112	Control Source	Displays the source of the Start Command and Speed Reference.	5 = RS485 (DSI) Port	Drive Display	284E
113	Control In	Status of control inputs. These can be used in DeviceLogix	Read Only	Drive Display	284E
114	Dig In Status	Status of the control terminal block digital inputs.	0	Drive Display	284E
115	Comm Status	Status of the communications ports	0	Drive Display	284E
116	Control SW Ver	Main Control Board software version for AC Drive.	Read Only	Drive Display	284E
118	Elapsed Run Time	Accumulated time drive is outputting power.	Read Only	Drive Display	284E
122	Output Power	Output power present at T1, T2 & T3 (U, V & W).	Read Only	Drive Display	284E
123	Output Power Fctr	The angle in electrical degrees between motor voltage and motor current.	Read Only	Drive Display	284E
124	Drive Temp	Present operating temperature of the drive power section.	Read Only	Drive Display	284E
125	Counter Status	The current value of the counter when the counter is enabled.	Read Only	Drive Display	284E
126	Timer Status	The current value of the timer when timer is enabled.	Read Only	Drive Display	284E
129	Torque Current	Displays the current value of the motor torque current as measured by the drive.	Read Only	Drive Display	284E

Table 26 - ArmorStart Parameters

Parameter Number	Parameter Name	Description	Factory Default	Group	Controller
131	Motor NP Volts	Set to the motor nameplate rated volts.	Based on Drive Rating	Drive Setup	284E
132	Motor NP Hertz	Set to the motor nameplate rated frequency.	60 Hz	Drive Setup	284E
133	Motor OL Current	Set to the maximum allowable current.	Based on Drive Rating	Drive Setup	284E
134	Minimum Freq	Sets the lowest frequency that the drive will output continuously.	0.0 Hz	Drive Setup	284E
135	Maximum Freq	Sets the highest frequency that the drive will output continuously.	60 Hz	Drive Setup	284E
136	Start Source	Sets the control scheme that is used to start the Bulletin 284E ArmorStart controller.	5 = Comm Port (RS485 (DSI))	Drive Setup	284E
137	Stop Mode	Sets the Valid Stop Mode for the Bulletin 284E ArmorStart controller.	9 = Ramp + EM Brk	Drive Setup	284E
138	Speed Reference	Sets the Valid Speed References for the Bulletin 284E ArmorStart controller.	5 = Comm Port	Drive Setup	284E
139	Accel Time 1	Sets the rate of acceleration for all speed increases.	10.0 s	Drive Setup	284E
140	Decel Time 1	Sets the rate of deceleration for all speed decreases.	10.0 s	Drive Setup	284E
141	Reset To Defaults	Used to reset drive to factory default settings	0 = Ready/Idle	Drive Setup	284E
143	Motor OL Ret	Enables/Disables the Motor Overload Retention function.	0 = Disabled	Drive Setup	284E

Table 27 - Bulletin 284E Advance Setup Parameter Descriptions

Parameter Number	Parameter Name	Description	Factory Default	Group
151...154	Digital In 1 Sel Digital In 2 Sel Digital In 3 Sel Digital In 4 Sel	Selects the function for the digital inputs.	See Table 22.	Drive Advanced Setup
155	Relay Out Sel	Sets the condition that changes the state of the output relay contacts.	0 = Ready/Fault See Table 23.	Drive Advanced Setup
156	Relay Out Level	Sets the trip point for the digital output relay if the value of Parameter 155 (Relay Out Sel) is 6, 7, 8, 10, 16, 17, 18, or 20.	0.0	Drive Advanced Setup
169	Internal Freq	Provide the frequency command to drive when Parameter 138 (Speed Reference) is set to "1" (Internal Freq).	60.0 Hz	Drive Advanced Setup
170...177	Preset Freq 0 Preset Freq 1 Preset Freq 2 Preset Freq 3 Preset Freq 4 Preset Freq 5 Preset Freq 6 Preset Freq 7	Provides a fixed frequency command value when Parameters 151...154 (Digital In x Sel) is set to Option 4 (Preset Frequencies).	See Table 24.	Drive Advanced Setup
178	Jog Frequency	Sets the output frequency when the jog command is issued.	10.0 Hz	Drive Advanced Setup
179	Jog Accel/Decel	Sets the acceleration and deceleration time when a jog command is issued.	10.0 s	Drive Advanced Setup
180	DC Brake Time	Sets the length of time that DC brake current is injected into the motor. See Parameter 181 (DC Brake Level).	0.0 s	Drive Advanced Setup

Table 27 - Bulletin 284E Advance Setup Parameter Descriptions

Parameter Number	Parameter Name	Description	Factory Default	Group
181	DC Brake Level	Defines the maximum DC brake current, in amps, applied to the motor when Parameter 137 (Stop Mode) is set to either Ramp or DC Brake.	Drive Rated amps x 0.05	Drive Advanced Setup
182	DB Resistor Sel	Used to set percent duty cycle for external dynamic braking.	0 = Disabled	Drive Advanced Setup
183	S Curve %	Sets the percentage of acceleration or deceleration time that is applied to ramp as S Curve. Time is added, half at the beginning and half at the end of the ramp.	0% (Disabled)	Drive Advanced Setup
184	Boost Select	Sets the boost voltage (% of Parameter 131 (Motor NP Volts)) and redefines the Volts per Hz curve. Active when Parameter 225 (Torque Perf Mode) = 0 (V/Hz). Drive may add additional voltage unless Option 5 is selected.	8 = 5.0 (2.5 for 5 Hp drives)	Drive Advanced Setup
185	Start Boost	Sets the boost voltage (% of Parameter 131 (Motor NP Volts)) and redefines the Volts per Hz curve when Parameter 184 (Boost Select) = 0 (Custom V/Hz) and Parameter 225 (Torque Perf Mode) = 0 (V/Hz).	2.5%	Drive Advanced Setup
186	Brake Voltage	Sets the frequency where brake voltage is applied when Parameter 184 (Boost Select) = 0 (Custom V/Hz) and Parameter 225 (Torque Perf Mode) = 0 (V/Hz).	25.0%	Drive Advanced Setup
187	Brake Frequency	Sets the frequency where brake frequency is applied when Parameter 184 (Boost Select) = 0 (Custom V/Hz) and Parameter 225 (Torque Perf Mode) = 0 (V/Hz).	15.0 Hz	Drive Advanced Setup
188	Maximum Voltage	Sets the highest voltage that the drive will output.	Drive Rated Volts	Drive Advanced Setup
189	Current Limit 1	Maximum output current that is allowed before current limiting occurs.	Drive Rated amps x 1.5	Drive Advanced Setup
190	Motor OL Select	Drive provides Class 10 motor overload protection. Setting 0...2 select the derating factor for I^2t overload function.	0 = No Derate	Drive Advanced Setup
191	PWM Frequency	Sets the carrier frequency for the PWM output waveform. Figure 67 provides derating guidelines that are based on the PWM frequency setting.	4.0 Hz	Drive Advanced Setup
192	Auto Rstrt Tries	Set the maximum number of times the drive attempts to reset a fault and restart.	0	Drive Advanced Setup
193	Auto Rstrt Delay	Sets time between restart attempts when Parameter 192 (Auto Rstrt Tries) is set to a value other than zero.	1.0 s	Drive Advanced Setup
194	Start At PowerUp	Enables/disables a feature that lets a Start or Run command automatically cause the drive to resume running at command speed after the drive input is restored.	0 = Disabled	Drive Advanced Setup
195	Reverse Disable	Enables/disables the function that lets the direction of the motor rotation be changed.	0 = Disabled	Drive Advanced Setup
196	Flying Start En	Sets the condition that lets the drive reconnect to a spinning motor at actual RPM.	0 = Disabled	Drive Advanced Setup
197	Compensation	Enables/disables correction options that may improve problems with motor instability.	1 = Electrical	Drive Advanced Setup
198	SW Current Trip	Enables/disables a software instantaneous (within 100 ms) current trip.	0.0 (Disabled)	Drive Advanced Setup
199	Process Factor	Scales the output frequency value that is displayed by Parameter 110 (Process Display).	30.0	Drive Advanced Setup
200	Fault Clear	Resets a fault and clears the fault queue.	0 = Ready/Idle	Drive Advanced Setup
201	Program Lock	Protects parameters against change by unauthorized personnel.	0 = Unlocked	Drive Advanced Setup
205	Comm Loss Action	Selects the drive's response to a loss of the communication connection or excessive communication errors.	0 = Fault	Drive Advanced Setup
206	Comm Loss Time	Sets the time that the drive remains in communication loss before implanting the option selected in Parameter 205 (Comm Loss Action).	15.0 s	Drive Advanced Setup

Table 27 - Bulletin 284E Advance Setup Parameter Descriptions

Parameter Number	Parameter Name	Description	Factory Default	Group
214	Slip Hertz @ FLA	Compensates for the inherent slip in an induction motor. This frequency is added to the commanded output frequency based on motor current.	2.0 Hz	Drive Advanced Setup
215	Process Time Lo	Scales the time value when the drive is running at Parameter 134 (Minimum Freq). When set to a value other than zero, Parameter 110 (Process Display) indicates the duration of the process.	0.00	Drive Advanced Setup
216	Process Time Hi	Scales the time value when the drive is running at Parameter 135 (Maximum Freq). When set to a value other than zero, Parameter 110 (Process Display) indicates the duration of the process.	0.00	Drive Advanced Setup
217	Bus Reg Mode	Enables the bus regulator.	1 = Enabled	Drive Advanced Setup
218	Current Limit 2	Maximum output current that is allowed before current limiting occurs.	Drive Rated Amps x 1.5	Drive Advanced Setup
219	Skip Frequency	Sets the frequency at which the drive will not operate.	0.0 Hz	Drive Advanced Setup
220	Skip Freq Band	Determines the brand width around Parameter 219 (Skip Frequency). Parameter 220 (Skip Freq Band) is split applying 1/2 above and 1/2 below the actual skip frequency.	0.0 Hz	Drive Advanced Setup
221	Stall Fault Time	Sets for the fault time that the drive will remain in stall mode before a fault is issued.	0 = 60 Seconds	Drive Advanced Setup
224	Var PWM Disable	Enables/disables a feature that varies the carrier frequency for the PWM output waveform that is defined by Parameter 191 (PWM Frequency).	0 = Enabled	Drive Advanced Setup
225	Torque Perf Mode	Enables/disables sensorless vector control operation.	1 = Sensrls Vect	Drive Advanced Setup
226	Motor NP FLA	Set to the motor nameplate full load amps.	Drive Rated Amps	Drive Advanced Setup
227	Autotune	Provides an automatic method for setting Parameter 228 (IR Voltage Drop) and Parameter 229 (Flux Current Ref), that affect sensorless vector performance.	0 = Ready/Idle	Drive Advanced Setup
228	IR Voltage Drop	Value of volts dropped across the resistance of the motor stator.	Based on Drive Rating	Drive Advanced Setup
229	Flux Current Ref	Value of amps for full motor flux.	Based on Drive Rating	Drive Advanced Setup
260	EM Brk OFF Delay	Sets the time that the drive will remain at minimum frequency before ramping to the commanded frequency and energizing the brake coil relay when Parameter 137 (Stop Mode) is set to Option 8 or 9.	0.0 s	Drive Advanced Setup
261	EM Brk On Delay	Sets the time that the drive will remain at minimum frequency before stopping and de-energizing the brake coil relay when Parameter 137 (Stop Mode) is set to Option 8 or 9.	0.0 s	Drive Advanced Setup
262	MOP Reset Sel	Sets the drive to save the current MOP Reference command.	1 = Save MOP Ref	Drive Advanced Setup
263	DB Threshold	Sets the DC bus Voltage Threshold for Dynamic Brake operation.	100%	Drive Advanced Setup
264	Comm Write Mode	Determines whether parameter changes made over the communication port are saved and stored in Non-Volatile Storage (NVS) or RAM only.	0 = Save	Drive Advanced Setup

How to Configure an Explicit Message

Programming ControlLogix Explicit Message


Explicit Messaging with ControlLogix

In the ControlLogix platform, explicit messaging can be done easily from within a logic program. The request and response is configured within the MSG function. The MSG function can be found in the Input/Output tab of Studio 5000.

Configuring the MSG Instruction

A tag name must be given to the MSG function before the rest of the information can be defined. In this example, a tag was created with the name `explicit_mes`. After the instruction has been named, click the gray box to define the rest of the instruction.


Figure 70 - MSG Function Found in the Input/Output Tab



Formatting an Explicit Message

ControlLogix scanners and bridges accommodate both downloading Explicit Message Requests and uploading Explicit Message Responses. The message format is shown in Figure 71.

Figure 71 - ControlLogix Message Format in Studio 5000




Box	Description
1	Message Type The message type is usually CIP Generic.
2	Service Type The service type indicates the service (for example, Get Attribute Single or Set Attribute Single) that you want to perform.
3	Service Code The service code is the code for the requested EtherNet/IP service. This value changes based on the Service Type that has been selected. In most cases, this is a read-only box. If you select "Custom" in the Service Type box, then you must specify a service code in this box (for example, 4B for a Get Attributes Scattered service or 4C for a Set Attributes Scattered service).
4	Class The class is an EtherNet/IP class.
5	Instance The instance is an instance (or object) of an EtherNet/IP class.
6	Attribute The attribute is a class or instance attribute.
7	Source Element This box contains the name of the tag for any service data to be sent from the scanner or bridge to the module and drive.
8	Source Length This box contains the number of bytes of service data to be sent in the message.

Box	Description
9	Destination This box contains the name of the tag that receives service response data from the module and drive.
10	Path The path is the route that the message follows. Note: Click Browse to find the path or type in the name of a module that you previously mapped.
11	Name The name for the message.

Performing Explicit Messages

IMPORTANT There are five basic events in the Explicit Messaging process that are defined next. The details of each step vary depending on the controller. See the documentation for your controller.

Figure 72 - Explicit Message Process




Box	Description
1	Format the required data and set up the ladder logic program to send an Explicit Message Request to the scanner or bridge module (download).
2	The scanner or bridge module transmits the Explicit Message Request to the slave device over the EtherNet/IP network.
3	The slave device transmits the Explicit Message Response back to the scanner. The data is stored in the scanner buffer.
4	The controller retrieves the Explicit Message Response from the buffer of the scanner (upload).
5	The Explicit Message is complete.

The MSG (message) instruction handles all explicit messaging that is initiated by a Logix Controller program.

It automatically creates and manages TCP connections and CIP encapsulation sessions. You have no direct influence on this process.

Figure 73 - Example — Message Configuration Tab



The Class, Instance, and Attribute define the actual information being requested. Additional configurations of these parameters can be found in [Appendix B](#).

Diagnostics

Overview

This chapter describes the fault diagnostics of the ArmorStart distributed motor controller and the conditions that cause various faults to occur.

Protection Programming

Many of the protective features available with the ArmorStart distributed motor controller can be enabled and adjusted through the programming parameters provided. For further details on programming, see [Chapter 7](#), Bulletin 281E/284E Programmable Parameters.

Fault Display

The ArmorStart distributed motor controller comes equipped with a built-in Light-emitting Diode (LED) status indication that provides four status LEDs and a Reset button.

Figure 74 - LED Status Indication and Reset



Clear Fault

You can clear a fault by using the following methods:

- Remotely via network communications

A remote reset is attempted upon detection of a rising edge (0 to 1 transition) of the “Fault Reset” bit in the various I/O assemblies. A remote reset is also attempted upon detection of the rising edge of the “Fault Reset” parameter.

- Locally via the “Reset” button on the LED Status indication keypad.

Fault Codes

[Table 28](#) provides a reference of the Fault LED status indications for Bulletin 281E and Bulletin 284E distributed motor controllers.

Table 28 - Fault Indication

Blink Pattern	Fault Types	
	Bulletin 281E Controller	Bulletin 284E Controller
1	Short Circuit	Short Circuit
2	Overload Trip	Overload Trip
3	Phase Loss	Phase Short
4	Reserved	Ground Fault
5	Reserved	Stall
6	Control Power	Control Power
7	I/O Fault	I/O Fault
8	Over Temperature	Over Temperature
9	Phase Imbalance	Over Current
10	A3 Power Loss	A3 Power Loss
11	Reserved	Internal Communications
12	Reserved	DC Bus Fault
13	EEPROM Fault	EEPROM Fault
14	Hardware Fault	Hardware Fault
15	Reserved	Restart Retries
16	Reserved	Misc. Fault

Fault Definitions

Short Circuit

Short Circuit indicates that the Bulletin 140M motor protector has tripped, or that the internal wiring protection algorithm has detected an unsafe current surge. This fault cannot be disabled.

Overload Trip

The load has drawn excessive current and based on the overload trip class that is selected, the device has tripped. This fault cannot be disabled.

A Bulletin 281 controller with a mechanical motor brake actuator that is connected to motor out leads, can cause nuisance phase imbalance or overload faults when used on 1 Hp (0.73 kW) or smaller loads. Current is elevated in the legs that influence the electronic overload on 1 Hp (0.73 kW) or smaller loads. Adjust the Full Load Amps (FLA) setting to offset this additional current, if necessary.

Phase Loss

Indicates a missing supply phase. This fault can be disabled and is disabled by default.

Phase Short

Indicates that the drive has detected a phase short. This fault cannot be disabled.

Ground Fault

Indicates that the drive has detected a ground fault. This fault cannot be disabled.

Stall

Indicates that the drive has detected a stall condition, which indicates the motor, has not reached full speed. This fault cannot be disabled.

Control Power

Indicates a loss of control power voltage or a blown control power circuit. This fault can be disabled and *is* disabled by default.

I/O Fault

This error can indicate a shorted sensor, shorted input device, or input wiring mistakes. It can also indicate a blown output fuse. This fault can be disabled and *is* disabled by default.

Over Temperature

Indicates that the operating temperature has been exceeded. This fault cannot be disabled.

Phase Imbalance

Indicates an imbalance supply voltage. This fault can be disabled and *is* disabled by default.

Over Current

Indicates that the drive has detected an overcurrent fault. This fault cannot be disabled.

A3 Power Loss

Power has been lost or has dropped below the 12V threshold. This fault can be disabled and *is* disabled by default.

Internal Communication Fault

Indicates that an internal communication fault has been detected. This fault cannot be disabled.

DC Bus Fault

Indicates that the drive has detected a DC Bus Fault. This fault cannot be disabled.

Electrically Erasable Programmable Read-only Memory (EEPROM) Fault

A major fault that renders the ArmorStart controller inoperable. This fault cannot be disabled.

Hardware Fault

Indicates an Internal FAN RPM is low, Internal temperature monitor failure, Internal Brake fuse opened, or incorrect base or control module. This fault cannot be disabled.

Restart Retries

This fault is generated when the drive detects that the auto retries count has been exceeded. This fault cannot be disabled.

Miscellaneous Faults

For Bulletin 284E units, this fault is actually the logical of several drive faults that are not specifically enumerated. The faults include DB1 Brake fault, Heatsink Over Temperature (fault code F8), Params Defaulted fault (fault code F48), and SVC Autotune fault (fault code F80).

This fault cannot be disabled.

EtherNet/IP LED Status Indication

Figure 75 - EtherNet/IP LED



EtherNet/IP LED status and diagnostics consist of four LEDs.

- Link Activity/Status LEDs
 - Link1 Activity/Status (Port 1) – LED Color: Bicolor (Green/Yellow), see [Table 29](#)
 - Link2 Activity/Status (Port 2) – LED Color: Bicolor (Green/Yellow), see [Table 29](#)
- “MOD” LED – Bicolor Red/Green represents the Ethernet Module status, see [Table 30](#)
- “NET” LED – Bicolor Red/Green represents the Ethernet Network status, see [Table 32](#)

Table 29 - Link 1 or Link 2 Port Activity/Status

Link 1 or 2 Status LED	Description	Recommended Action
OFF	No link established	Verify network cabling, and correct, as needed.
Green	Link established at 100 Mbps	None
Flashing green	Transmit or receive activity present at 100 Mbps	None
Yellow	Link established at 10 Mbps	None
Flashing yellow	Transmit or receive activity present at 10 Mbps	None

Table 30 - Module Status Indicator

MOD Status LED	Summary	Requirement
Steady OFF	No power	If no power is supplied to the device, the module status indicator is steady OFF.
Steady Green	Device operational	If the device is operating correctly and the PLC is in Run mode, the module status indicator is steady green.
Flashing Green	Standby	If the device has not been configured or the PLC is not in Run mode, the module status indicator is flashing green.
Flashing Red	Minor fault	If the device has detected a recoverable minor fault, the module status indicator is flashing red. Note: An incorrect or inconsistent configuration would be considered a minor fault.
Steady Red	Major fault	If the device has detected a non-recoverable major fault, see Table 31 .
Flashing Green/Red	Self-test	While the device is performing its power-up test, the module status indicator is flashing green/red.

See Parameter 63 “Base Trip” for the Base Module Trip Status.

Table 31 - “Steady Red” MOD LED Status (See [Table 30](#).)

	Fault Type	Description
0	EEPROM Fault	Nonvolatile memory value out of range for a local parameter, or a write failure is detected. A solid red MOD status LED also shows this fault.
1	Internal Comm2	The Internal communication connection has timed out. A flashing red MOD status LED also shows this fault.
2	Hardware Fault	Internal diagnostics checks failed. A solid red MOD status LED also shows this fault.
3	Control Module	An illegal or unsupported Control Module product code or revision has been detected. Also reported if no Control Module is detected on power-up. A solid red MOD status LED also shows this fault.
4...15	Reserved	Reserved

Table 32 - Network Status Indicator

Indicator State	Summary	Requirement
Steady OFF	Not powered, no IP address	If the device does not have an IP address (or is powered OFF), the network status indicator is steady OFF.
Flashing Green	No connections	If the device has no established connections, but has obtained an IP address, the network status indicator is flashing green.
Steady Green	Connected	If the device has at least one established connection (even to the Message Router), the network status indicator is steady green.
Flashing Red	Connection timeout	If one or more of the connections in which this device is the target has timed out, the network status indicator is flashing red. This indicator is left if only all timed out connections are re-established or if the device is reset.
Steady Red	Duplicate IP	If the device has detected that the IP address is already in use, the network status indicator is steady red.
Flashing Red/Green	Self-test	While the device is performing its power-up test, the network status indicator is flashing green/red.

Control Module LED Status and Reset

Figure 76 - LED Status Indication and Reset



The Control Module LED status and diagnostics consist of four status LEDs and a Reset button. The following is a brief explanation of the operation of each LED found on the Control Module.

Table 33 - Control Module LED Status Indication

LED	Definition	Recommended Action
Power	This LED is illuminated solid green when switched control power is present and with the proper polarity.	Verify that 24V DC is present on A1 and A2. Check if the local disconnect is in the OFF position.
Run	This LED is illuminated solid green when a start command and control power is present.	Verify that 24V DC is present on A1 and A3. Check if you are properly commanding to RUN via Instance 162 or 166. Verify that the safety function is satisfied for the safety version controller. Check that the safety I/O module output for SO (P/M) is on.
Network	This bicolor LED is used to indicate the status of the internal network connection.	See Table 32, Network Status Indicator for additional information.
Fault	This LED is used to indicate the fault status of the ArmorStart controller. When the unit is faulted, the unit responds with a specific blink pattern to identify the fault.	See Table 34 and Table 35 for additional information.

The “Reset Button” is a local trip reset.

Control Module Fault LED Indications

The PrFlt Reset Mode (Parameter 23) determines how a fault is reset. When this parameter is set to the value 0 = manual mode, a local or remote fault reset is required to reset the fault. When this parameter is set to the value 1 = auto reset, faults are cleared automatically when the fault condition goes away. See [Table 35](#) for the Bulletin 284 controller, in addition to the “Pr FltReset Mode”, the Auto Rstrt Tries (Parameter 192) must be set greater than 0.

NOTE: The “Pr FltReset Mode” parameter takes precedence. Therefore if P23 is set to manual, there is no effect when you change P192 to a value greater than 0.

Table 34 - Fault LED Indicators for Bulletin 281E Controllers

Blink Pattern	Auto-resettable	Bulletin 281E Trip Status	Description	Action
1	No	Short Circuit	The circuit breaker (140M) has tripped.	Determine cause of trip. Try to reset the circuit breaker by using the disconnect handle. If the conditions continue, check power wiring or replace based module. This fault cannot be disabled.
2	Yes	Overload	The load has drawn excessive current and based on the trip class that is selected, the device has tripped.	Verify that the load is operating correctly and the ArmorStart controller is properly set up. The fault cannot be disabled. If there is an EM brake on the motor, check if the brake current is a significant percentage compare to the FLA. Adjust FLA to compensate for the brake current.
3	Yes	Phase Loss	The ArmorStart controller has detected a missing phase.	Verify that 3-phase voltage is present at the line side connections. This fault can be disabled and is disabled by default.
4	—	Reserved	Not Used	—
5	—	Reserved	Not Used	—

Table 34 - Fault LED Indicators for Bulletin 281E Controllers

Blink Pattern	Auto-resettable	Bulletin 281E Trip Status	Description	Action
6	Yes	Control Pwr Loss (Switched Power)	The ArmorStart controller has detected a loss of the control power voltage.	Check control voltage, wiring, and proper polarity (A1/ A2 terminal). Also, check and replace the control voltage fuse, if necessary. This fault can be disabled and is disabled by default.
7	Yes	Input Fault	This error indicates a shorted sensor, shorted input device, wiring input mistakes, or a blown output fuse.	Correct, isolate, or remove wiring error before restarting the system. This fault can be disabled and is disabled by default.
8	Yes	Over Temperature	This fault is generated when the operating temperature has been exceeded. This fault cannot be disabled.	Check for blocked or dirty heat sink fins. Verify that ambient temperature has not exceeded 40 °C (104 °F). 1. Clear the fault or cycle power to the drive.
9	Yes	Phase Imbalance	The ArmorStart controller has detected a voltage imbalance.	Check the power system and correct if necessary. This fault can be disabled and is disabled by default.
10	Yes	Control Power (24V DC) Lost (Unswitched Power)	The 24V DC power supply is below tolerance threshold.	Check the state of the network power supply (A3/A1 terminal) and look for media problems. This fault can be disabled and is disabled by default.
11	—	Reserved	Not Used	—
12	—	Reserved	Not Used	—
13	No	EEProm	This is a major fault that renders the ArmorStart controller inoperable. Possible causes of this fault are transients that are induced during EEPROM storage routines.	If a transient initiated the fault, cycle the power to clear the problem, otherwise replace the ArmorStart controller, if needed. This fault cannot be disabled.
14	No	Hdw Flt	This fault indicates that a serious hardware problem exists.	Check for a base/starter module mismatch. If no mismatch exists, see parameter 61 for additional fault detail. Replace the ArmorStart controller, if the fault persists.(Hdw Flt is the factory-enabled default setting.) This fault cannot be disabled.
15	—	Reserved	Not Used	—
16	—	Reserved	Not Used	—

Table 35 - Fault LED Indicators for 284E Controller

Bit/Blink Pattern	Auto-resettable ⁽¹⁾	284E Trip Status	Description	Action
1	No	Short Circuit	The circuit breaker (140M) has tripped.	Determine cause of trip. Try to reset the circuit breaker by using the disconnect handle. If the conditions continue, check power wiring or replace based module. This fault cannot be disabled.
2	Drive Controlled	Overload (Drive Codes 7 and 64)	An excessive motor load exists	1. Reduce load so drive output current does not exceed the current set by Parameter 133 (Motor OL Current). 2. Verify Parameter 184 (Boost Select) setting. 3. Drive rating of 150% for 1 minute. 4. Reduce load or extend Accel Time 200% or when 3 seconds has been exceeded.
3	Drive Controlled	Phase Short (Drive Codes 38 . . . 43)	1. Phase U, V, or W to Gnd. A phase to ground fault has been detected between the drive and motor in this phase. 2. Phase UV, UW, or VW Short. Excessive current has been detected between these two output terminals.	Check the wires between the drive and motor. Check the motor for grounded phase. Check the motor and drive output terminal wires for a shorted condition. Replace drive if fault cannot be cleared.
4	Drive Controlled	Ground Fault (Drive Code 13)	A current path to earth ground has been detected at one or more of the drive output terminals.	Check the motor and external wiring to the drive output terminals for a grounded condition.
5	Drive Controlled	Stall (Drive Code 6)	Drive is unable to accelerate motor.	Increase Parameters 139 . . . 167 (Accel Time x) or reduce load so drive output current does not exceed the current set by Parameter 189 (Current Limit 1).

Table 35 - Fault LED Indicators for 284E Controller

Bit/Blink Pattern	Auto-resettable ⁽¹⁾	284E Trip Status	Description	Action
6	Parameter 23 (PrFlt Reset Mode)	Control Pwr Loss (Switched Power)	The ArmorStart controller has detected a loss of the control power voltage.	Check control voltage, wiring, and proper polarity (A1/A2 terminal). Also, check and replace the control voltage fuse, if necessary. This fault can be disabled and is disabled by default.
7	Parameter 23 (PrFlt Reset Mode)	Input Fault	This error indicates a shorted sensor, shorted input device, wiring input mistakes, or a blown output fuse.	If this fault occurs, the offending problem must be isolated or removed before restarting the system. This fault can be disabled and is disabled by default.
8	Parameter 23 (PrFlt Reset Mode)	Over Temperature	This fault is generated when the operating temperature has been exceeded. This fault cannot be disabled.	Check for blocked or dirty heat sink fins. Verify that ambient temperature has not exceeded 40 °C (104 °F). 1. Clear the fault or cycle power to the drive.
9	Drive Controlled	Over Current (Drive Codes 12 and 63)	The drive output current has exceeded the hardware current limit.	Check programming. Check for excess load, improper Parameter 184 (Boost Select) setting. DC brake volts set too high or other causes of excess current. Parameter 198 (SW Current Trip) has been exceeded, check load requirements and Parameter 198 setting.
10	Parameter 23 (PrFlt Reset Mode)	Control Power (24V DC) Lost (Unswitched Power)	The 24V DC power supply is below tolerance threshold.	Check the state of the network power supply (A3/A1 terminal) and look for media problems. This fault can be disabled and is disabled by default.
11	No	Internal Comm (See Parameter 61 for details on this fault. F81 is a VFD fault. This fault can also happen if control power is lost.)	Communication with either the control module (VFD) or Control module has stopped.	See section Fault 11 Detail. If the problem persists replace the unit.
12	Drive Controlled	DC Bus Fault (Drive Codes Reference 3, 4 and 5)	Power Loss - DC bus voltage remained below 85% of nominal. Undervoltage - DC bus voltage fell below the minimum value. Overvoltage - DC bus voltage exceeded maximum value.	Monitor the incoming AC line for low voltage or line power interruption. Check the input fuses. Monitor the AC line for high line voltage or transient conditions. Motor regeneration can also cause bus overvoltage. Extend the decel time or install dynamic brake option.
13	No	EEPROM (PF Drive Code Reference 100)	The checksum read from the board does not match the checksum that is calculated.	Set Parameter 141 (Reset to Defaults) to Option 1 "Reset Defaults".
14	No	Hdw Flt (PF Drive Codes Reference 70 and 122)	Failure has been detected in the drive power section or drive control and I/O section. See Last Protection Fault parameter 61 for details.	1. Cycle power. 2. If Fan RPM fault, replace the fan. 3. Replace drive if fault cannot be cleared.
15	Drive Controlled	Restart Retries (PF Drive Code Reference 33)	Drive unsuccessfully attempted to reset a fault and resume running for the programmed number of Parameter 192 (Auto Rstrt Tries).	Correct the cause of the fault and manually clear.
16	Drive Controlled	Misc. Fault (PF Drive Code Reference 2, 8, 29, 48 and 80)	Heatsink temperature exceeds a predefined value. The drive was commanded to write default values to EEPROM. Either you canceled the autotune function or it failed. If DB1 option is installed, see P61 for additional diagnostics.	Check for blocked or dirty heat sink fins. Verify that ambient temperature has not exceeded 40 °C (104 °F) and mounted properly. 1. Clear the fault or cycle power to the drive. 2. Program the drive parameters as needed. Restart procedure. 3. Check for DB1 fault and see DB1 diagnostics.

(1) When "Drive Controlled", see Internal Drive Faults in [Table 37](#) for details about which drive faults can be auto reset.

Fault 11 Detail

Parameter 61 provides a more granular description of the faults that occur.

- An F11 protection fault indicates that the internal communication has stopped
- There is a 10 second delay before an F11 Internal Comm. fault is present
- Common causes of an Internal Comm. fault:
 - The local ArmorStart Disconnect switch is in the OFF position.

- 3-Phase line power that feeds the ArmorStart controller is not connected or is turned OFF.
- Switched Control Power is not connected or is turned OFF.
- Poor power quality (Brown Out)
- First things to check:
 - Verify that the local disconnect is in the ON position.
 - Verify that the unit has 3-Phase Line Voltage present and it is within specified tolerances.
 - Verify that the ArmorStart unit has Control Voltage present and it is within specified tolerances.
 - Press the local reset to attempt to clear the fault or send the ArmorStart controller a network reset.
 - Cycle power to the ArmorStart unit and try to clear the fault again.
- If an Internal Comm. fault persists, see Parameter 61 – LastPR Fault for additional details on the last protection fault. See the next table for troubleshooting information that is based on what Parameter 61 returns. Also see Parameters 107...109 to get the VFD fault code.

Parameter 61 Fault Code	Description	Recommended Action
13 = Control Power Loss	Control power was lost or dipped below the lower threshold long enough to cause the Internal Comm. fault.	<ul style="list-style-type: none"> • Check that control power is turned on and within specified tolerances. • Check the Control Power fuse, replace if necessary. • Press the local reset or send the unit a network reset once control power is restored.
14 = Control Power Fuse	The control power fuse has blown and the control power circuit no longer is a closed circuit.	<ul style="list-style-type: none"> • Additional investigation as to why the fuse blew is needed. Take corrective action accordingly. • Replace the fuse and reset the ArmorStart unit either locally or over the network.
21 = A3 Power Loss	Unswitched (A3/A2) control power was lost or dipped below the lower threshold long enough to cause the Internal Comm. fault. <ul style="list-style-type: none"> • DeviceNet power loss 	<ul style="list-style-type: none"> • Check that the A3 or DeviceNet power terminal does not have any loose connections. • Press the local reset or send the unit a network reset once the unswitched control power is restored
22 = Internal Comm 24 = Power Loss (3-Phase) 25 = Under Voltage (3-Phase)	<ul style="list-style-type: none"> • The MCB of the ArmorStart unit lost communication with the VFD. This communication loss is most likely due to a loss of 3-phase power. • PF Fault Code 3 or 4 	<ul style="list-style-type: none"> • Check that the local disconnect is in the ON position. • Check for a power quality issue, take appropriate corrective actions. • Check that 3-phase power is present. • Press the local reset or send the unit a network reset
23 = Drive Comm Loss (PF Fault Code 81)	The PowerFlex VFD lost communications with the MCB. This communication loss is most likely due to a loss of control power or network power.	<ul style="list-style-type: none"> • Check that control power and the network power are both present. • Press the local reset or send the unit a network reset.
28 = Base EEPROM	The MCB cannot read the EEPROM of the base module or is not communicating correctly with the base module. In the EtherNet/IP units, Parameter 63 – Base Trip provides more detail as to why the base module is not communicating properly with the control module	<ul style="list-style-type: none"> • Cycle power to the ArmorStart unit. • Verify that the control module is seated correctly in the base module • Check the connector on the control module for bent or broken pins
41 = DB1 Comm	The MCB has lost communications with the Dynamic Brake (DB1) board or the EEPROM on the DB1 board is corrupt.	<ul style="list-style-type: none"> • Press the local reset or send the unit a network reset • Cycle power to the ArmorStart unit.

Resetting Device to Factory Defaults

The switch value of 888 lets you reset to the factory default configuration, including configuration parameters. This setting is useful in situations where you wish to decommission a module or when you wish to commission a previously used module that has an unknown configuration. When the switches are set to 888, upon the next power cycle the ArmorStart controller will return to factory default settings and cease all communications. The Module Status LED transitions to blinking red and the Network Status LED transitions to OFF.

After reset, change the IP address to a valid setting and cycle power. The purpose of this step is to help stop you from module reset without a change to the 888 switch setting.

IMPORTANT If you set the IP address to “888” followed by a power cycle, the device resets to its factory default configuration. To resume network communication, the address **MUST** be set to DHCP or a valid IP address and power cycled again.

Notes:

Troubleshooting

Introduction

The purpose of this chapter is to help with troubleshooting the ArmorStart distributed motor controller by using the LED status display and diagnostic parameters.



ATTENTION: The service of energized industrial control equipment can be hazardous. Electrical shock, burns, or unintentional actuation of controlled industrial equipment can cause death or serious injury. For safety of maintenance personnel and others who can be exposed to electrical hazards associated with maintenance activities, follow the local safety-related work practices (for example, the NFPA 70E, Part II in the United States). Maintenance personnel must be trained in the safety practices, procedures, and requirements that pertain to their respective job assignments.



ATTENTION: Do not attempt to defeat or override fault circuits. Determine the cause of the fault indication and correct it before an operation attempt. Failure to correct a control system of mechanical malfunction can result in personal injury and /or equipment damage due to uncontrolled machine system operation.



ATTENTION: The drive contains high-voltage capacitors that take time to discharge after removal of mains supply. Before working on the drive, verify the isolation of mains supply from line inputs (R, S, T, [L1, L2, L3]). Wait 3 minutes for capacitors to discharge to reasonable voltage levels. Failure to do so can result in personal injury or death. Darkened display LEDs is not an indication that capacitors have discharged to reasonable voltage levels.



ATTENTION: Only qualified personnel familiar with adjustable frequency AC drives and associated machinery must plan or implement the installation, startup, and subsequent maintenance of the system. Failure to comply can result in personal injury and/or equipment damage.



ATTENTION: This drive contains electrostatic discharge (ESD) – sensitive parts and assemblies. Static control precautions are required during installation, test, service, or repair of this assembly. Component damage can result if ESD control procedures are not followed. If you are not familiar with static control procedures, see Guarding against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD protection handbook.




ATTENTION: An incorrectly applied or installed drive can result in component damage or a reduction in product life. Wiring or application errors, such as motor undersize, incorrect or inadequate AC supply, or excessive ambient temperatures can result in malfunction of the system.

Bulletin 281E Troubleshooting

The next flowchart for Bulletin 281E units is provided to aid in quick troubleshooting.

Figure 77 - Bulletin 281E Control Module LED Status




Bulletin 284E Troubleshooting

Fault Definitions

The internal hardware of the Bulletin 284E ArmorStart controller detects some of the controller faults, while the internal drive detects other faults. For internal drive faults, the internal hardware of the ArmorStart controller simply polls the drive for the existence of faults and reports the fault state. The internal hardware of the ArmorStart controller does not do fault latching for these faults. The PrFlt ResetMode parameter (Parameter 23) determines the Auto Resettability of only the faults that are detected on the main control board. Internal drive parameters, see [Table 36](#), control the Auto Resettability of the faults that are detected in the internal drive. The next flowchart for Bulletin 284E units is provided to aid in quick troubleshooting.

Figure 78 - Bulletin 284E Control Module LED Status



IP67 Dynamic Brake Diagnostic (DB1)

The ArmorStart controller includes a specialized function that helps protect the DB from current faults. This capability is located in the control module of the 284 that is included when the DB1 option is selection.

A DB1 fault is not annunciated until the DB switch in the drive is activated and conducts current.

The following conditions are monitored:

- DB Overcurrent resistor value too small (current is too high)
- DB Undercurrent resistor value is too high (current is too low)
- DB Open drive bus voltage is above DB level, but no resistor current was measured

The following conditions cause a fault anytime the DB1 active:

- DB Shorted Switch - detected current when Drive bus voltage is below the DB threshold
- DB Overtemp - DB resistor is too hot
- DB Bus Voltage Link Open - Bus voltage from the drive is not measured for 2 seconds. Occurs if the internal connection between the main control and the DB1 module has an issue

DB1 Faults

Operation and Troubleshooting of the DB1 - Dynamic Brake

Eight types of DB1 faults are detected and reported in Parameter 61 as either a “DB1 Flt”, “DB1 Comm Fault” or DB1 Switch Short”. DB1 faults are also reported in Attribute 158 “DB1 Fault” of the Control Supervisor Object (Class Code: 29 Hex). See [Appendix B](#) for Control Supervisor information.

If the ArmorStart Fault LED blinks 11x's check parameter 61. If value is 41, check the following:

- DB1 Comm Fault - Communication loss exists between the Dynamic Brake board and the main control board.

This condition is also enunciated in the Trip Status parameter 4 bit 10 called Internal Comm fault.

If the ArmorStart Fault LED blinks 16x's check parameter 61. If value is 42 (DB1 Fault), check the following:

- DB1 Resistor Overtemperature Fault
- DB1 Overcurrent Fault
- DB1 Undercurrent Fault
- DB1 Open Fault
- DB1 VBus Link Fault

This condition is also enunciated in the Trip Status parameter 4-bit 15 called Miscellaneous Fault.

If the ArmorStart Fault LED blinks 16x's check parameter 61. If value is 43, check the following:

- DB1 Switch Fault

The DB1 option provides the following warning:

- DB1 Thermal Warning - occurs once the resistor reaches 75% of maximum thermal capacity. Once at 100% a DB1 over temperature occurs resulting in a DB1 over temperature fault.

DB1 Resistor Overtemperature Fault

Control Supervisor Object "DB1 Fault" Attribute Bit 0.

The DB1 measures current continuously, and models resistor body temperature that is based on measured current and resistor model parameters. The DB1 not only calculates the present resistor body temperature, but also predicts the future resistor body temperature. The resistor overtemperature level is based on the predicted future resistor body temperature, not on the present resistor body temperature. This fault is disabled when Parameter 182 (DB1 Resistor Sel) is "Disabled".

Troubleshooting – DB1 Resistor body temperature is too hot. Allow the resistor to cool.

DB1 Overcurrent Fault

Control Supervisor Object "DB1 Fault" Attribute Bit 1.

The DB1 compares each current measurement against the Max Current Level. If five consecutive samples are above the Max Current Level, then a fault is recorded. This fault is intended to notify you if the DB1 resistance is lower than expected. This fault is disabled when Parameter 182 (DB1 Resistor Sel) is "Disabled".

Troubleshooting – DB1 monitor has measured a DB1 current higher than expected. Turn off all power to unit. Allow at least 3 minutes for capacitors to discharge.



BURN HAZARD: DB1 resistor can still be hot.

Disconnect DB1 resistor from ArmorStart control module. Measure DB1 resistor value at the connector with an ohmmeter. See the specification for minimum DB1 resistor values. If DB1 resistance value is within limits, replace control module. If not, replace DB1 resistor.

DB1 Undercurrent Fault

Control Supervisor Object "DB1 Fault" Attribute Bit 2.

The DB1 compares each current measurement against the Min Current Level. The Min Current Level = Min DB1 Voltage Level/Max DB1 Resistance. If five consecutive samples are below the Min Current Level and the DB1 is ON, then a fault is recorded. This fault is intended to notify you if the DB1 resistance is higher than expected. This fault is disabled when Parameter 182 (DB1 Resistor Sel) is "Disabled".

Troubleshooting – DB1 monitor has measured a DB1 current lower than expected. Turn off all power to unit. Allow at least 3 minutes for capacitors to discharge.



BURN HAZARD: DB1 resistor can still be hot.

Disconnect DB1 resistor from ArmorStart control module. Measure DB1 resistor value at the connector with an ohmmeter. See the specification for minimum DB1 resistor values. If DB1 resistance value is within limits, replace control module. If not, replace DB1 resistor.

DB1 Switch Fault

Control Supervisor Object "DB1 Fault" Attribute Bit 3.

A DB1 Switch fault is issued when continuous DB1 resistor current is detected when the Drive Bus Voltage level is less than the DB1 Voltage Level. If five consecutive samples of Drive Bus Voltage less than DB1 Level is detected along with continuous DB1 resistor current flow, then a shorted DB1 IGBT fault (DB1 Switch) is recorded.

It is your responsibility to provide an input power contactor to each ArmorStart controller with a drive. You must write logic to control (open) the input contactor to the ArmorStart controller if a DB1 Switch Fault occurs. The Instruction Literature provides information on how to connect the input contactor, and how to implement the logic.

Troubleshooting – Remove all power to the unit and restart it to attempt to reset the fault. If the fault persists, replace control module.

DB1 Open Fault

Control Supervisor Object "DB1 Fault" Attribute Bit 4.

A DB1 Open fault is issued when Bus Voltage is greater than the DB1 Voltage Level, and no DB1 resistor current has been detected. If five consecutive samples of Drive Bus Voltage greater than the DB1 Level is detected along with no DB1 resistor current flow, then an open DB1 fault is recorded. This fault is intended to notify the customer of an open DB1 resistor, or open wire. The fault is disabled when the DB1 Resistor Sel, Parameter (182) is "Disabled".

Troubleshooting – DB1 monitor expected to see current flow and measured none. Likely cause is an open DB1 resistor, loose DB1 resistor connector, or open wire in DB1 cable. Check DB1 cable connector for tightness. If problem persists, remove DB1 resistor cable connector from unit and check DB1 resistance. If DB1 resistor is open, replace DB1 resistor. Otherwise replace control module.

DB1 VBus Link Fault

Control Supervisor Object "DB1 Fault" Attribute Bit 6.

For proper operation, the DB1 monitors parameters from the Drive internally inside the ArmorStart controller. If the internal communications to the drive is lost, then this fault is issued. Since the DB1 can no longer provide resistor protection, you must implement logic to open the input contactor.

Troubleshooting – Verify that 3-phase line power and control power are applied to unit. Attempt to reset fault. If fault persists, replace control module.

DB1 Comm Fault

Control Supervisor Object "DB1 Fault" Attribute Bit 8.

The communications link is monitored continuously. If the DB1 stops responding, then the MCB issues this fault. Since the DB1 can no longer provide resistor protection, you must implement logic to open the input contactor.

Troubleshooting – Replace control module.

DB1 Thermal Warning

Control Supervisor Object "DB1 Status" Attribute Bit 1.

A DB1 Thermal Warning is issued if the predicted future resistor body temperature is greater than the Max DB1 resistor temperature x DB1 Thermal Warning Percent.

Troubleshooting – None. DB1 resistor thermal value has exceeded the preset threshold of 90% of thermal value.

Reading the Control Supervisor Object

If a DB1 fault occurs, the Control Supervisor Object provides the detailed information specific to the fault. Create an Explicit Message Instruction such as Class = 0029hex, Instance = 0001hex, Attribute = 158. A bit enumerated WORD of information is returned. See the CIP section for details.

Hardware Fault - Fan RPM Warning

FAN Fault Handling with Firmware 66.21 of 284

The Fan Fault handler was modified in firmware 66.21 of the 284.

Operation

If the RPM of the internal fan drops below the minimum threshold, a Warning bit in Stater Status, Parameter 5 is set and the Warning Status, Parameter 62 Bit 13 hardware warning is set. A 24-hour count down timer begins. If the warning flag is set continuously for the 24-hour period and time expires, a F14 (LED Flashes 14 times) Hardware fault occurs. Also Last Pr Fault, Parameter 61 shows Fan RPM fault. If within the 24-hour period the fan rpm climbs above the minimum threshold, the warning flags are removed and timer reset and turned off.

Starter Status, Warning Bit 5:

When set to "1" indicates a Warning if a Fan RPM issue occurs. Other warning type faults that are found in parameter 62, can also trigger the warning bit.

Warning Status, Parameter 62:

Bit 13 turns to a "1" indicating a Hardware warning. Hardware warning is an OR of two warnings.

Annunciation with PLC Logic

To determine when only a Fan RPM warning occurs, logic must be written that triggers a CIP message. The DPI Alarm Object Class Code 0x0098 provides a structure of data that includes the fault code of Fan RPM (31). Create a program that monitors the Starter Status Warning bit and Warning Status Hardware bit. When they are both set to "1" the PLC code generates a Get Single explicit message of Class 0x0098, Instance 1, and Attribute 1.

This message returns a structure of the following data:

- — Alarm Code UINT <-----
- — Alarm Source Struct of:
- — — DPI Port Number USINT
- — — Device Object Instance USINT
- — Alarm Time Stamp Struct of:
- — — Timer Value ULINT
- — — Timer Descriptor WORD

When Alarm Code UINT = 31 (decimal), it is a FAN RPM warning. For a full list of fault code references, see parameter 61.

When the fault occurs, the following Trip bits are activated:

- Parameter 4, Trip Status, bit 13 turns to a "1" indicating a hardware trip has occurred
- Parameter 5, Starter Status, bit 0 turns to a "1" indicating a TripPresent
- Parameter 61 displays "Fan RPM" Fault 31 as the last protection fault.

Internal Drive Faults

The 284E controller details the specific VFD fault in parameters 107, 108, and 109 (Fault 1, 2, or 3). A fault is a condition that stops the drive. There are two fault types.

Table 36 - Internal Drive Faults

Type	Name	Description
1	Auto-Reset/Run	When this type of fault occurs, Parameter 192 (Auto Rstrt Tries) and related Parameters: 155 (Relay Out Sel), 193 (Auto Rstrt Delay) are set to a value greater than 0, a user-configurable timer, Parameter 193 (Auto Rstrt Delay) and related Parameter: 192 (Auto Rstrt Tries), begins. When the timer reaches zero, the drive automatically attempts to reset the fault. If the condition that caused the fault is no longer present, the fault is reset and the drive is restarted
2	Non-Resettable	This type of fault can require drive or motor repair, or is caused by wiring or programming errors. The cause of the fault must be corrected before the fault can be cleared.

Automatically Clearing Faults (Option/Step)

Clear a Type 1 Fault and Restart the Drive:

1. Set Parameter 192 (Auto Rstrt Tries) to a value other than 0.
2. Set Parameter 193 (Auto Rstrt Delay) to a value other than 0.

Clear an Overvoltage, Undervoltage, or Heatsink OvrTmp Fault without Restarting the Drive:

1. Set Parameter 192 (Auto Rstrt Tries) to a value other than 0.
2. Set Parameter 193 (Auto Rstrt Delay) to 0.

Auto Restart (Reset/Run)

The Auto Restart feature provides the ability for the drive to perform a fault reset automatically, followed by a start attempt without user or application intervention. This feature allows remote or unattended operation. Only certain faults can be reset. Certain faults (Type 2) that indicate possible drive component malfunction cannot be reset. Use caution to enable this feature, since the drive attempts to issue its own start command that is based on user-selected programming.

The next table describes Bulletin 284E Faults as seen in Parameters 107, 108, and 109 (Fault 1, 2, or 3).

Table 37 - Bulletin 284E Faults – Parameters 107, 108, and 109 (Fault 1, 2 or 3)

PF40 Fault No. ⁽¹⁾	Fault	Type ⁽²⁾	Description	Action
F2	Auxiliary Input	1	Auxiliary input interlock is open.	1. Check remote wiring. 2. Check communications.
F3	Power Loss	2	DC bus voltage remained below 85% of nominal.	1. Monitor the incoming AC line for low voltage or line power interruption. 2. Check input fuses.
F4	UnderVoltage	1	DC bus voltage fell below the minimum value.	1. Monitor the incoming AC line for low voltage or line power interruption.
F5	OverVoltage	1	DC bus voltage exceeded maximum value.	1. Monitor the AC line for high line voltage or transient conditions. Motor regeneration can also be the cause of bus overvoltage. Extend the decel time or install dynamic brake option.
F6	Motor Stalled	1	Drive is unable to accelerate motor.	1. Increase Parameters 139 or 167 (Accel Time x) or reduce load so drive output current does not exceed the current set by Parameter 189 (Current Limit 1).
F7	Motor Overload	1	Internal electronic overload trip	1. An excessive motor load exists. Reduce load so drive output current does not exceed the current set by Parameter 133 (Motor OL Current). 2. Verify Parameter 184 (Boost Select) setting
F8	Heatsink OvrTmp	1	Heatsink temperature exceeds a predefined value.	1. Check for blocked or dirty heat sink fins. Verify that ambient temperature has not exceeded 40 °C (104 °F). 2. Replace internal fan.
F12	HW OverCurrent	2	The drive output current has exceeded the hardware current limit.	1. Check programming. Check for excess load, improper programming of Parameter 184 (Boost Select), DC brake volts set too high, or other causes of excess current.
F13	Ground Fault	2	A current path to earth ground has been detected at one or more of the drive output terminals.	1. Check the motor and external wiring to the drive output terminals for a grounded condition.
F33	Auto Rstrt Tries		Drive unsuccessfully attempted to reset a fault and resume running for the programmed number of Parameter 192 (Auto Rstrt Tries).	1. Correct the cause of the fault and manually clear.

Table 37 - Bulletin 284E Faults – Parameters 107, 108, and 109 (Fault 1, 2 or 3)

PF40 Fault No. ⁽¹⁾	Fault	Type ⁽²⁾	Description	Action
F38 F39 F40	Phase U to Gnd Phase V to Gnd Phase W to Gnd	2	A phase to ground fault has been detected between the drive and motor in this phase.	1. Check the wiring between the drive and motor. 2. Check motor for grounded phase. 3. Replace starter module if fault cannot be cleared.
F41 F42 F43	Phase UV Short Phase UW Short Phase VW Short	2	Excessive current has been detected between these two output terminals.	1. Check the motor and drive output terminal wiring for a shorted condition. 2. Replace starter module if fault cannot be cleared.
F48	Params Defaulted	2	The drive was commanded to write default values to EEPROM.	1. Clear the fault or cycle power to the drive. 2. Program the drive parameters as needed.
F63	SW OverCurrent	2	Programmed Parameter 198 (SW Current Trip) has been exceeded.	1. Check load requirements and Parameter 198 (SW Current Trip) setting.
F64	Drive Overload	2	Drive rating of 150% for 1 min or 200% for 3 s has been exceeded.	1. Reduce load or extend Accel Time.
F70	Power Unit	2	Failure has been detected in the drive power section.	1. Cycle power. 2. Replace starter module if fault cannot be cleared.
F80	SVC Autotune		Either you canceled the autotune function or it failed.	1. Restart procedure.
F81	Comm Loss	2	RS485 (DSI) port stopped communicating.	1. Turn off by using Parameter 205 (Comm Loss Action). 2. Replace starter module if fault cannot be cleared.
F100	Parameter Checksum	2	The checksum read from the board does not match the checksum that is calculated.	1. Set Parameter 141 (Reset To Defaults) to Option 1 (Reset Defaults).
F122	I/O Board Fail	2	Failure has been detected in the drive control and I/O section.	1. Cycle power. 2. Replace starter module if fault cannot be cleared.

(1) PowerFlex 40 drive fault ID. See the PowerFlex User Manual, 22B-UM001*.

(2) See [Table 36](#) for Type description.

Table 38 - Motor Does Not Start

Causes	Indication	Corrective Action
No output voltage to the motor.	None	<p>Check the power circuit.</p> <ul style="list-style-type: none"> • Check the supply voltage. • Check all fuses and disconnects <p>Check the motor.</p> <ul style="list-style-type: none"> • Check that the motor is connected properly. • Check that I/O Terminal 01 is active. • Check that Parameter 136 (Start Source) matches your configuration. • Check that Parameter 195 (Reverse Disable) is not prohibiting movement. • Run Autotune parameter 227 <p>Check the safety system.</p> <ul style="list-style-type: none"> • Check the status of S1 from the Safety I/O block. • Check the status of S0 from the Safety I/O block. When S0 is restored (ON), there is a 50 ms delay before a run command is allowed.
Drive is Faulted	Flashing red status light	<p>Clear fault.</p> <ul style="list-style-type: none"> • Press Stop • Cycle power • Set Parameter 200 (Fault Clear) to Option 1 (Clear Faults). • Cycle digital input is Parameters 151 . . . 154 (Digital In x Sel) is set to Option 7, (Clear Faults).

Table 39 - Drive Does Not Respond to Changes in Speed Command

Causes	Indication	Corrective Action
No value is coming from the source of the command.	The drive Run indicator is lit and output is 0 Hz.	<ul style="list-style-type: none"> Check Parameter 112 (Control Source) for correct source. If the source is an analog input, check wiring and use a meter to check for presence of signal. Check Parameter 102 (Commanded Freq) to verify correct command.
Incorrect reference source is being selected via remote device or digital inputs.	None	<ul style="list-style-type: none"> Check Parameter 112 (Control Source) for correct source. Check Parameter 114 (Dig In Status) to see if inputs are selecting an alternate source. Verify settings for Parameters 151...154 (Digital In x Sel). Check Parameter 138 (Speed Reference) for the source of the speed reference. Reprogram as necessary.
Some applications create an intermittent voltage regeneration condition and the bus regulator tries to compensate.	None	<ul style="list-style-type: none"> Disable parameter 217 Bus Regulation. The drive reacts faster to changes in speed. This condition can also cause DC bus voltage faults if an external resistor is not attached.

Table 40 - Motor and/or Drive Does Not Accelerate to Commanded Speed

Causes	Indication	Corrective Action
Acceleration time is excessive.	None	<ul style="list-style-type: none"> Reprogram Parameter 139 (Accel Time 1) or Parameter 167 (Accel Time 2). Try to change parameter 184 Boost selection to a value of 5 to 14. Start with 5.
Excess load or short acceleration times force the drive into current limit, slowing, or stop of acceleration.	None	<ul style="list-style-type: none"> Compare Parameter 103 (Output Current) with Parameter 189 (Current Limit1). Remove excess load or reprogram Parameter 139 (Accel Time 1) or Parameter 167 (Accel Time 2). Check for improper setting of Parameter 184 (Boost Select).
Speed command source or value is not as expected.	None	<ul style="list-style-type: none"> Verify Parameter 102 (Commanded Freq). Check Parameter 112 (Control Source) for the proper Speed Command.
Programming is stopping the drive output so it does not exceed limit values.	None	Check Parameter 135 (Maximum Freq) to verify that speed is not limited by programming.
Torque performance does not match motor characteristics.	None	<ul style="list-style-type: none"> Set motor nameplate full load amps in Parameter 226 (Motor NP FLA). Use Parameter 227 (Autotune) to perform Static Tune or Rotate Tune procedure. Set Parameter 225 (Torque Perf Mode) to Option 0 (V/Hz).

Table 41 - Motor Operation Is Unstable

Causes	Indication	Corrective Action
Motor data was incorrectly entered.	None	<ol style="list-style-type: none"> Correctly enter motor nameplate data into Parameters 131, 132, and 133. Enable Parameter 197 (Compensation). Use Parameter 184 (Boost Select) to reduce boost level.

Table 42 - Drive Does Not Reverse Motor Direction

Causes	Indication	Corrective Action
Digital input is not selected for reverse control.	None	Check Parameters 151...154 (Digital In x Sel). Choose correct input and program for reverse mode.
Motor wiring is improperly phased for reverse.	None	Switch two motor leads.
Reverse is disabled.	None	Check Parameter 195 (Reverse Disable).

Table 43 - Drive Does Not Power Up

Causes	Indication	Corrective Action
No input power to drive.	None	<p>Check the power circuit.</p> <ul style="list-style-type: none"> Check the supply voltage. Check all fuses and disconnects.
Jumper between I/O Terminals P2 and P1 not installed and/or DC Bus Inductor not connected.	None	Install jumper or connect DC Bus Inductor.

Ethernet Statistics

The EtherNet/IP communication module can experience intermittent network connectivity due to these conditions:

- Duplex mismatch
- Electrical noise that is induced into a cable or results from a Logix/switch ground potential difference
- Bad hardware, such as a cable or switch part

Troubleshoot and General Solutions for Linear or DLR Networks

Before attempting to correct specific faults on the linear or DLR network, we recommend to first take the following actions when a fault appears.

- For a DLR network check that:
 - At least one node is configured as a supervisor on the network and that Network Topology = Ring.
 - All cables on the network are securely connected to each device.
 - All devices that require an IP address have one assigned correctly.
 - The Network Status field on the status page of the active supervisor node to determine the fault type.
- For a linear network check that:
 - None of the nodes are configured as a supervisor on the network and that Network Topology = Linear.

If any nodes on a linear network are configured as a supervisor, it can impact communication to other devices connected to the network.

- All cables on the network are securely connected to each device.
- All devices that require an IP address have one assigned correctly.

If the fault is not cleared after completing the actions listed, use the tables in the rest of this chapter to troubleshoot issues specific to a DLR network or a linear network.

Specific Issues on Your DLR or Linear Network

Use the following table to troubleshoot possible specific issues on your DLR or linear network, where the actions that were described previously did not solve them.

Table 44 - Troubleshoot DLR or Linear Network


Issue	Description	Solution
<p>Supervisor Reports a Ring Fault</p>	<p>A link on the DLR network can be broken:</p> <ul style="list-style-type: none"> Intentionally, for example, because you added or deleted nodes but did not make all physical connections to restore the setup of the network with/without the node. Unintentionally, for example, because a cable is broken or a device malfunctions. <p>When this fault occurs, the adjacent nodes to the faulted part of the network are displayed in the Ring Fault group and the Network Status field = Ring Fault.</p> <p>The screen shot shows the Ring Fault section with IP addresses appearing for the last active nodes. The faulted node is between nodes 10.88.80.115 and 10.88.80.208. If the IP address of either node is not available, the software displays the MAC ID. of the node</p> <p>Figure 79 - Ring Fault Section</p>  <p>Once the fault is corrected, the ring is automatically restored, and the Network Status field returns to Normal.</p>	<p>Determine where the fault condition exists and correct it.</p> <p>It can be necessary to click the Refresh Communication link to update the Ring Fault information to determine where the fault condition exists.</p>

Table 44 - Troubleshoot DLR or Linear Network


Issue	Description	Solution
<p>Rapid Ring Fault</p>	<p>When a Rapid Ring Fault occurs, the following events occur:</p> <ul style="list-style-type: none"> • The active supervisor blocks traffic on port 2, which results in possible network segmentation, that is, some nodes can become unreachable. • The Link 2 status indicator on the active supervisor is off. • As soon as the fault occurs, for both RSLogix 5000 programming software and RSLinx communication software, the Status field = Rapid Fault/Restore Cycles. <p>Figure 80 - Rapid Fault/Restore Cycles Status</p>  <p>Any of the following can cause a Rapid Ring Fault:</p> <ul style="list-style-type: none"> • Five intentional disconnections/reconnections of a node from the network within 30 s • A duplex mismatch between two connected devices • Electromagnetic noise on the network • Unstable physical connections, such as intermittent connectors <p>Given the nature of a Rapid Ring Fault, the Last Active Node information cannot be accurate when a Rapid Ring Fault condition is present</p>	<p>Multiple possible solutions exist.</p> <ul style="list-style-type: none"> • For the disconnections and reconnections issue, no solution is required. Clear the fault when you have reconnected the device to the network permanently. • For the duplex mismatch issue, reconfigure the duplex parameters to verify that they match between the devices. • For the electromagnetic noise issue, determine where the noise exists and remove it or use a protective shield in that location. • For the unstable connections issue, determine where they exist on the network and correct them. • Check the media counters for all devices on the network. The device with the highest media counter count is most likely causing the Rapid Ring Fault. • Remove devices from the network one by one. When you see that the Rapid Ring Fault disappears after a device is removed, it indicates that specific device is causing the fault. • Finally, your Beacon Interval or Timeout configuration cannot be appropriate for your network. However, if you think it is necessary to change these values, we recommend that you call Rockwell Automation technical support. Once the fault is fixed, click Clear Fault.
<p>Partial Fault Condition</p>	<p>A partial network fault occurs when traffic is lost in only one direction on the network because a ring member is not forwarding beacons in both directions for some reason, such as a component failure. The active ring supervisor detects a partial fault by monitoring the loss of Beacon frames on one port and the fault location appears in the Ring Fault section of the Network tab.</p> <p>When a partial fault is detected, the active ring supervisor blocks traffic on one port. At this point, the ring is segmented due to the partial fault condition. The nodes that are next to the faulted part of the network are displayed in the Ring Fault group with either IP addresses or MAC IDs for each node displayed.</p> <p>When this fault occurs, the Network Status field = Partial Fault Condition.</p> <p>Once the fault is corrected, it automatically clears, and the Network Status field returns to Normal.</p>	<p>Determine where the fault condition exists and correct it.</p>

Table 44 - Troubleshoot DLR or Linear Network


Issue	Description	Solution
<p>Media Counter Errors or Collisions</p>	<p>The media counters screen displays the number of physical layer errors or collisions. The screen indicates where to check for errors that are encountered. Error levels are displayed depending on what caused the error. For example, an Alignment Error is displayed in the Alignment Error field.</p> <p>Figure 81 - Media Counter Screen</p>  <p>On a DLR network, it is not uncommon to see low levels of media counter errors. For example, if the network breaks, a low level of media counter errors appear. With a low level of media counter errors, the value typically does not continuously increase and often clears.</p> <p>A high level of media counter errors typically continues to increase and does not clear. For example, there is a mismatch of speed between two linked nodes, a high level of media counter errors appear that steadily increase and do not clear.</p> <p>To access the RSLogix screen that is shown, browse the network, right-click the device, select Module Properties, and click Port Diagnostics.</p>	<p>Some example solutions include:</p> <ul style="list-style-type: none"> • Check for a mismatch of speed and/or duplex between two linked nodes. • Check that all cables on the network are securely connected to each device. • Check for electromagnetic noise on the network. If you find it, remove it or use a protective shield in that location.

Table 45 - Media Counter Errors

Media Counter	Definition
Alignment Errors	<p>A frame that contains bits that do not total an integral multiple of eight.</p> <p>Alignment errors often result from:</p> <ul style="list-style-type: none"> • Starting or stopping of a module. • MAC-layer packet formation problems. • Cable problems that corrupt or delete data. • Packets that pass through more than two cascaded multi-port transceivers.
FCS Errors	<p>A frame that contains 8 bits, at least one of which has been corrupted.</p> <p>Frame Check Sequence (FCS) errors often result from:</p> <ul style="list-style-type: none"> • Starting or stopping of a module. • Cable problems that corrupt or delete data. <p>Important: Even though the acceptable Ethernet bit-error rate is 1 in 108, the typical rate is 1 in 1012 or better.</p>
Single Collisions	<p>The number of outgoing packets that encountered only one collision during transmission.</p>
Multiple Collisions	<p>The number of outgoing packets that encountered 2...15 collisions during transmission.</p>
SQE Test Errors	<p>A test to detect the collision-present circuit between a transceiver and a network interface card (NIC).</p> <p>Important: Because most NICs now have an integrated transceiver, the SQE test is unnecessary. Ignore this media counter.</p>
Deferred Transmissions	<p>The number of outgoing packets whose transmission is deferred because the network is busy when the first attempt is made to send them.</p> <p>Important: The module only defers the first attempt to transmit a packet. After the first attempt, the module transmits the packet without checking. However, if the network is still busy, a collision is recorded.</p>


Media Counter	Definition
Late Collisions	<p>The number of times two devices transmit data simultaneously.</p> <p>Neither device detects a collision because the time it takes to send the signal from one end of the network to the other exceeds the time that is required to put the entire packet on the network. Consequently, neither device senses the transmission of the other until the entire packet is out on the network.</p> <p>Late collisions often result from these conditions:</p> <ul style="list-style-type: none"> • Excessive network segment length • Repeaters between devices <p>Important: Late collisions can affect large and small packets. However, the transmitter cannot detect late collisions between small packets. Consequently, a network that experiences measurable late collisions between large packets also loses small packets.</p>
Excessive Collisions	<p>The number of frames that experience 16 consecutive collisions.</p>
MAC Transmit Errors	<p>The number of frames for which transmission via a particular interface fails due to an internal MAC sublayer transmission error.</p> <p>Important: MAC transmit errors are only counted if either late collisions, excessive collisions, or carrier sense errors are not counted.</p>
MAC Receive Errors	<p>The number of frames for which reception via a particular interface fails due to an internal MAC sublayer transmission error.</p> <p>Important: MAC receive errors are only counted if the frame too long count, alignment errors, or FCS errors are not counted.</p>
Carrier Sense Errors	<p>Carrier sense errors fall into these categories:</p> <ul style="list-style-type: none"> • No Carrier Sense Present - The number of times the carrier is not present when a transmission starts. • Carrier Sense Lost - The number of times the carrier is lost during a transmission. <p>Carrier sense errors usually indicate a problem with a cable on the Ethernet infrastructure.</p>
Frame Too Long	<p>The number of incoming packets that exceed the maximum Ethernet packet size.</p>

Troubleshoot Intermittent Ethernet Connectivity

To troubleshoot intermittent Ethernet connectivity, follow these steps.

1. From the ArmorStart EtherNet/IP and/or the ControlLogix EtherNet/IP bridge, click Ethernet Statistics.

Figure 82 - Ethernet Statistics



2. Review the values in the Media Counters table.

If	Then
Any media counters are greater than zero	You must investigate further.
These errors are counted: <ul style="list-style-type: none"> • Alignment • FCS • Carrier Sense 	A duplex mismatch exists between your EtherNet/IP communication module and the switch port. To clear the duplex mismatch: <ol style="list-style-type: none"> 1. Configure the EtherNet/IP communication module and the corresponding Ethernet switch port for a forced operation, not auto-negotiation. 2. Verify that the firmware revision of your Logix controller and switch, or converter are identical. 3. If the revisions are not identical, replace the controller, switch, or converter so that they match.
Single Collisions or Multiple Collisions are greater than zero	No action is required. Important: If two stations attempt to transmit data simultaneously, the packets collide with each other. However, collisions are not errors and do not indicate a network problem. The number of network collisions can vary greatly due to traffic patterns or CPU utilization. Consequently, there is no set range of acceptable collisions for each outgoing packet. Collisions are a normal aspect of Ethernet networking.
Late Collisions are greater than zero	<ol style="list-style-type: none"> 1. Check to see if a network segment is too long. 2. Remove repeaters from between devices.
Excessive Collisions are greater than zero	Calculate the typical rate of excessive collisions on your network and decide whether the rate of packet loss affects the performance of your network. Important: Excessive collisions indicate that your network has become congested. For each collision after the 16th, your network drops a packet.
MAC Transit Errors are greater than zero	No action is required.
Frame Too Long is greater than zero	Limit the size of your tags to ≤ 500 bytes.

Ethernet Statistics

The Ethernet Statistics web page presents the current configuration of an EtherNet/IP communication module and any errors that have occurred on the module.

1. Review the values in the Ethernet Port 1 table.

Ethernet Port 1	
Interface State	Enabled
Link Status	Active
Speed	100 Mbps
Duplex	Full Duplex
Autonegotiate Status	Autonegotiate Speed and Duplex

If		And you	Then
Link Status is	Active	Do not want to change the status	No action is required
	Inactive	Want to establish communication on the network	Reconfigure the module or port that is inactive.
Speed is	100 Mbps or 1000 Mbps	Do not want to change your port speed	No action is required. Important: 100 Mbps is the default port speed.
		Want to reduce your port speed to 10 Mbps	You must manually configure your module and reset your module.
	10 Mbps	Want to increase your port speed to 100 Mbps	Reset your module
		Do not want to change your port speed	No action is required.
Duplex is	Full	Are sending large amounts of data	No action is required. Important: Full Duplex is the default port setting. Full-duplex ports reduce the risk of collisions because each device has separate channels for the transmission and receipt of large amounts of data.
		Are not sending large amounts of data	No action is required. Important: Delays due to collisions or switch traffic are usually negligible, but can become a problem if you send a large amount of data.
	Half	Are sending large amounts of data	Change the Duplex setting of your module to Full.
Autonegotiate Status ⁽¹⁾ is	Speed and/or Duplex	Are using a fiber converter	Change the Autonegotiate status of your module to None. Important: Fiber links do not support autonegotiation.
		Are not using a fiber converter	No action is required. Important: Speed and/or Duplex is the default setting. Autonegotiation enables devices to select the best way to communicate without any configuration. All devices with an Ethernet speed rating of 100 Mbps are required to support autonegotiation.
	None	Are not using a fiber converter	Change the Autonegotiate status of your module to Speed and/or Duplex.

(1) When you use an EtherNet/IP communication module with multiple ports, make sure that you use the same Autonegotiate Status configuration for both ports.

2. Review the values in the Media Counters Port 1 table.

Media Counters Port 1	
Alignment Errors	0
FCS Errors	0
Single Collisions	0
Multiple Collisions	0
SQE Test Errors	0
Deferred Transmissions	0
Late Collisions	0
Excessive Collisions	0
MAC Transmit Errors	0
Carrier Sense Errors	0
Frame Too Long	0
MAC Receive Errors	0

If	Then
Any media counters are greater than zero	You must investigate further.
These errors are counted: • Alignment • FCS • Carrier Sense	A duplex mismatch exists between your EtherNet/IP communication module and the switch port. To clear the duplex mismatch: 1. Configure the EtherNet/IP communication module and the corresponding Ethernet switch port for a forced operation, not autonegotiation. 2. Verify that the firmware revision of your Logix controller and switch, or converter are identical. 3. If the revisions are not identical, replace the controller, switch, or converter so that they match.
Single Collisions or Multiple Collisions are greater than zero	No action is required. Important: If two stations attempt to transmit data simultaneously, the packets collide with each other. However, collisions are not errors and do not indicate a network problem. The number of network collisions can vary greatly due to traffic patterns or CPU utilization. Consequently, there is no set range of acceptable collisions for each outgoing packet. Collisions are a normal aspect of Ethernet networking.
Late Collisions are greater than zero	1. Check to see if a network segment is too long. 2. Remove repeaters from between devices.
Excessive Collisions are greater than zero	Calculate the typical rate of excessive collisions on your network and decide whether the rate of packet loss affects the performance of your network. Important: Excessive collisions indicate that your network has become congested. For each collision after the 16th, your network drops a packet.
MAC Transit Errors are greater than zero	No action is required.
Frame Too Long is greater than zero	Limit the size of your tags to ≤ 500 bytes.

Ethernet Managed Switch Considerations

To help troubleshoot the EtherNet/IP network, a managed switch must be used.

Here are the important features in a managed switch:

- Internet Group Multicast Protocol (IGMP) snooping
- Support for Virtual Local Area Networks (VLAN)
- Port mirroring

IMPORTANT Use a switch that is equipped with wire-speed switching fabric. The switch fabric is a measure of the maximum traffic that a switch can handle without dropping a packet and without storing a packet in memory. Wire-speed switching fabric refers to a switch that can handle the maximum data rate of the network on each of its ports. Switches are typically rated in Gbps. For a 10-port switch connected to EtherNet/IP products, the maximum data rate that is needed, is typically 100...200 MB/s. Therefore, a 10-port-switch that is rated at least 1 GB/s is adequate for an EtherNet/IP application.

Internet Group Multicast Protocol

EtherNet/IP implicit (I/O) messaging mostly uses IP multicasting to distribute I/O control data that is consistent with the CIP produced/consumer model. Most switches retransmit multicast packets and broadcast packets to all ports.

IGMP snooping constrains the flooding of multicast traffic by dynamically configuring switch ports so that multicast traffic is forwarded only to ports associated with a particular IP multicast group. This constraint also helps minimize the CPU utilization rate.

Switches that support IGMP snooping learn which ports have devices that are part of a particular multicast group and only forward the multicast packets to the ports that are part of the multicast group.

IMPORTANT Not all switches support the IGMP snooping querier function, that is, snooping. Those switches that do not support IGMP snooping querier require a router. For switches that do support IGMP snooping, you can configure them to conduct the polling.

IGMP snooping cannot control unicast or broadcast traffic. To learn how to control unicast or broadcast traffic, see [Virtual Local Area Networks on page 240](#).


Virtual Local Area Networks

With a managed switch, virtual local area networks (VLAN) can be established to segregate various kinds of network traffic and also increase security between the networks. Multiple isolated networks can be created so that the traffic from one network does not burden the other network.

As with IGMP snooping, VLAN can control multicast traffic. However, unlike IGMP snooping, VLAN can also control and block this traffic:

- Unicast traffic
- Broadcast traffic

Figure 83 - Virtual Local Area Networks (VLAN)



Port Mirroring

Select a managed switch that supports port mirroring. With port mirroring, frames being transmitted on one port to another port, can be directed for analysis by a traffic analyzer. Besides monitoring the Ethernet media counters, port mirroring lets anomalies in traffic flow be spotted immediately. A traffic analyzer can monitor the traffic on a given port and troubleshoot a problem. Without port mirroring, frames on other ports cannot be seen. The effective support and maintenance of Ethernet networks is often reliant on dependable traffic analysis.

Here are some benefits of port mirroring:

- Monitoring explicit messages between controllers
- Monitoring implicit or I/O traffic

Control Module Removal and Installation




ATTENTION: To avoid shock hazard, disconnect main power before working on the controller, motor, or control devices.

1. Disconnect power by going to the control module and turning OFF the At-Motor disconnect and performing lockout/tagout per your company policy.
2. Remove motor cable.
3. Loosen the four mounting screws.
4. Unplug the Control module from the base by pulling forward.

Installation of Control Module

5. Install control module.
6. Tighten four mounting screws.
7. Install motor cable.

Figure 84 - Control Module Replacement



Note: DeviceNet™ base module is shown.

Fuse Replacement



ATTENTION: To avoid shock hazard, disconnect main power before working on the controller, motor, or control devices.

Table 46 - Control Voltage and Output Fuse Replacement

Specification	Output Fuse	Control Power Fuse
Cat. No.	25176-155-03	25172-260-17
Description	Fast-acting, high-interrupting capacity tubular fuse	UL Listed Class CC, CSA HRC-1, Interrupting, Rejection Feature
Current	2.5 A	7 A
Interrupting Capacity	1500 A	200 ka
Voltage Rating	250V	600V (Maximum)
Manufacturer	Littlefuse PN 021602.5	Cooper Bussman PN KTK-R-7 or Littlefuse PN KLKR007.T
Dimension mm (in.):	20 (0.8) x 5 (0.2)	38.1 (1.5) x 10.2 (0.4)

Figure 85 - Control Voltage and Output Fuse Replacement




Table 47 - Source Brake Fuse Replacement (Bulletin 284E Controller Only)

Specification	Source Control Brake Fuse
Cat. No.	W25172-260-12
Description	3.0 A UL Listed Class CC, CSA HRC-1, Rejection Feature
Current	3.0 A
Interrupting Capacity	200ka
Voltage Rating	600V (Maximum)
Manufacturer	Cooper Bussman PN KTK-R-3 or Littlefuse PN KLKR003.T
Dimension mm (in.):	38.1 (1.5) x 10.2 (0.4)

Figure 86 - Source Brake Fuse Replacement (Bulletin 284E Controller Only)



Source Control Brake Fuses

Cat. No. W25172-260-12

Source Brake Fuse Faults Reset

Replace the fuse and cycled unswitched power to reset the fault.

Notes:

Specifications for ArmorStart Controllers with EtherNet/IP

Bulletin 281E Controller

Electrical Ratings		UL/NEMA		IEC
Power Circuit	Rated Operation Voltage	200...575V		200...575V
	Rate Insulation Voltage	600V		600V
	Rated Impulse Voltage	6 kV		6 kV
	Dielectric Withstand	2200V AC		2500V AC
	Operating Frequency	50/60 Hz		50/60 Hz
	Utilization Category	Not applicable		AC-3
	Protection Against Shock	Not applicable		IP2X
	Rated Operating Current Max.	281E_ - ____ -10A- ^{*(1)}	1.2 A	
	281E_ - ____ -10B- ^{*(1)}	2.5 A		
	281E_ - ____ -10C- ^{*(1)}	5.5 A		
	281E_ - ____ -25D- ^{*(1)}	16 A		
Control Circuit	Rated Operation Voltage	24V DC (+10%, -15%), SELV or PELV, (A2 must be grounded at voltage source)		
	Rate Insulation Voltage	30V		30V
	Rated Impulse Voltage	—		1.5 kV
	Dielectric Withstand	1500V AC		2000V AC
	Overtoltage Category	—		III
	Operating Frequency	DC		DC
Short Circuit Protection	Short Circuit Protection Device (SCPD) Performance Type 1	Short Circuit Protection		480Y/277V
		10A, 10B, 10C, and 10D	Sym. Amps rms	65 kA
			Max. Fuse⁽²⁾	30 A
		10A, 10B, 10C, and 10D	Sym. Amps rms	30 kA
Max. Circuit Breaker⁽³⁾	60 A			

(1) See [Contactor Life Load Curves](#).

(2) Class J, CC, and T fuses only.

(3) Only when used with Cat. No. 140G-H6C3-C60.

		UL/NEMA	IEC	
Environmental	Operating Temperature Range	-20...+40 °C (-4...+104 °F)		
	Storage and Transportation Temperature Range	-25...+85 °C (-13...+185 °F)		
	Altitude ⁽¹⁾	2000 m		
	Humidity	5...95% (on-condensing)		
	Pollution Degree	3		
	Enclosure Ratings	NEMA Type 4/12	IP67	
	Approximate Shipping Weight	10.4 kg (23 lbs)		
Mechanical	Resistance to Shock			
	Operational	15 G		
	Non-Operational	30 G		
	Resistance to Vibration			
	Operational	1 G, 0.15 mm (0.006 in.) Displacement		
	Non-Operational	2.5 G, 0.38 mm (0.015 in.) Displacement		
	Power and Ground Terminals			
	Wire Size	Primary/Secondary Terminal: #16...#10 AWG	Primary/Secondary Terminal: 1.0...4.0 mm ²	
	Tightening Torque	Primary Terminal: 10.8 lb-in. Secondary Terminal: 4.5 lb-in.	Primary Terminal: 1.2 N-m Secondary Terminal: 0.5 N-m	
	Wire Strip Length	0.35 in. (9 mm)		
	Control Terminals			
	Wire Size	#18...#10 AWG	1.0...4.0 mm ²	
	Tightening Torque	6.2 lb-in.	0.7 N-m	
	Wire Strip Length	0.35 in. (9 mm)		
	Disconnect Lock Out	Recommend 8 mm (5/16 in.) lock shackle or hasp. The hasp must not exceed 8 mm (5/16 in.) when closed.		
	Contactor Mechanical Life	Cat. No. 100-	Ops	C12 (AC3)
280/1__-12*		Mil	13	
280/1__-23*		Mil	—	
Other Rating	EMC Emission Levels			
	Conducted Radio Frequency Emissions	10V rms Communications Cables 10V rms (PE) 150 kHz...80 MHz		
	Radiated Emissions	Class A, Group 1, Equivalent to C2 emissions		
	EMC Immunity Levels			
	Electrostatic Discharge	4 kV contact and 8 kV Air		
	Radio Frequency Electromagnetic Field	10V/m, 80 MHz...1 GHz 3V/m, 1.4 GHz...2 GHz 1V/m, 2.0 GHz...2.7 GHz		
	Fast Transient	2 kV (Power) 2 kV (PE) 1 kV (Communications and Control)		
	Surge Transient	1 kV (12) L-L, 2 kV (2) L-N (Earth)		
	Overload Current Range	280__-___-10A-*	0.24...1.2 A	
		280__-___-10B-*	0.5...2.5 A	
		280__-___-10C-*	1.1...5.5 A	
		280__-___-25D-*	3.2...16 A	
	Trip Classes ⁽²⁾	10, 15, 20		
	Trip Rating	120% of Full Load current (FLC) setting		
	Number of poles	3		

(1) See [Altitude Derating on page 259](#) for derating guide

(2) Refer to [Motor Overload Trip Curves on page 249](#)

	UL/NEMA	IEC
Standards Compliance	UL 508 CSA C22.2, No. 14 EN/IEC 60947-4 EN/IEC 60947-4-1 CE Marked per Low Voltage 2006/95/EC EMC Directive 2004/108/EC CCC ODVA for EtherNet/IP	
Certifications	UL, TÜV	

Control and I/O Power Requirements						
	Units	A1/A2 ⁽¹⁾	A3/A2 ⁽²⁾	A1/A2 ⁽¹⁾	A3/A2 ⁽²⁾	A3/A2 ⁽³⁾
		W/O HOA		W/ HOA		
Control Voltage	Volts	24V DC				
Module Inrush ⁽⁴⁾	Amps	0.92	0.30	1.09	0.125	0.295
Module Steady	Amps	0.06	0.30	0.23	0.125	0.295
Total Control Power (Pick Up)	Watts	22.08	7.20	26.16	3.00	7.08
Total Control Power (Running)	Watts	1.44	7.20	5.52	3.00	7.08

- (1) Add power requirements for outputs (1 A max.) to A1/A2.
- (2) Add power requirements for inputs (200 mA max.) to A3/A2.
- (3) If A1 power is disconnected.
- (4) Instantaneous capacitive inrush exists for less than 10 ms, which can exceed 20 A. The power supply must have sufficient capacity to support this amount of instant power demand when multiple units are turned ON simultaneously. If supplies are weaker, we recommend applying unswitched power (A3-A2) first and after a 2...4 second delay, apply switched power.

	UL/NEMA	IEC	
Input Ratings – Sourced from Control Circuit (A3/A2)	Rated Operation Voltage	24V DC	
	Input On-State Voltage Range	10...26V DC	
	Input On-State Current	3.0 mA @ 10V DC	
		7.2 mA @ 24V DC	
	Input Off-State Voltage Range	0...5V DC	
	Input Off-State Current	<1.5 mA	
	Maximum Input Frequency Response	200 Hz (DeviceLogix response is greater than 200 Hz. Network response depends on control system network performance.)	
	Input Filter – Software Selectable		
	Off to On	Settable from 0...64 ms in 1 ms increments	
	On to Off	Settable from 0...64 ms in 1 ms increments	
	Input Compatibility	—	IEC 1133 Type 1+
	Number of Inputs	4	
	Sensor Source		
	Voltage Status Only	11...26.4V DC from unswitched power (A3-A2)	
Current Available	50 mA max. per input, 200 mA for any single point		
SI - SM1 and SM2 (24V DC)	Contact Rating	DC-12 L/R, 1 ms resistive, 6 A	
	Contact Type	IEC 60947-5-1 Annex L - mechanically	
S0 - P/M	3 W/0.125 A per contactor (Two safety contactors)		




		UL/NEMA	IEC
Output Ratings – Sourced from Control Circuit (A1/A2) (Do not use as a power supply source to other devices)	Rated Operation Voltage	26.4V DC	
	Rate Insulation Voltage	250V	
	Dielectric Withstand	1500V AC (UL)	2000V AC (IEC)
	Operating Frequency	Solid-state sourcing output	
	Type of Current	24V DC	
	Conventional Thermal Current Ith	0.5 A each, 1 A, max combined	
	Peak Output Current	Current limited 2...8 amps (5 amps, nom) @ 24V DC	
	Type of Contacts	Normally open (N.O.)	
	Number of Contacts	2	
	Load Types	Resistive or light inductive	
	Surge Suppression	Integrated diode, clamps @ 35V DC	
	Thermo-Protection	Integrated short circuit and over current protection	
	Maximum Cycle Rate	30 operations/minute capacitive and inductive loads	
	Maximum Blocking Voltage	35V DC	
	Maximum On-State Voltage @ Maximum Output	1.5V DC	
Maximum Off-State Leakage Current	10 µA		
Device Level Ring (DLR)		Beacon-based performance including IEEE 1588 end to end transparent clock	
	Fault Recovery	Ring recovery time is less than 3 ms for a 50 node network	
Ethernet Port	Ethernet Receptacles	2 D-coded, 4-pin female M12 connectors	
	Ports	Embedded switch with 2 ports	
	IP Address	DHCP enabled by default	
	DHCP Timeout	30 s	
	Communication Rate	10/100 Mbps with auto negotiate half duplex and full duplex	
	Data	<ul style="list-style-type: none"> Transported over both TCP and UDP Min. of 500 I/O packets/second (pps) Supports up to 150 concurrent TCP sockets 	
Web Server		Embedded web server	
	Security	Login and password configurable	
	Email	Support Simple Mail Transfer Protocol (SMTP)	
	Configuration	Status, diagnostics, and configuration tabs	
Device Connections		Supports scheduled (Class 1) and unscheduled (Class 3 and UCMM) connections	
		6 - Class 3 connections are supported simultaneously	
		Supports up to 2 Class 1 CIP connections [Exclusive owner (data) or listen-only]. One connection per PLC. Listen-only connection requires a data connection to be established.	
		Class 1 Connection API: 2...3200 ms, Class 3 Connection API: 100...10 000 ms	
		20 ms Request Packet Interval (RPI) default	
		3 concurrent Encapsulation sessions	
		TCP port supports 5 concurrent incoming connections	
Component Response Time	1732ES-IB12X0BV2 or 1732ES-IB8X0BV4	See ArmorBlock Guard I/O DeviceNet Installation Instructions, publication 1732DS-IN001	
	Bulletin 281	20...40 ms	
Probability of Dangerous Failure per hour and MTTF_d for Uncontrolled Stop⁽¹⁾_p	MTTF _d	100 years	
	Average probability of dangerous failure per hour	6.0E-9 (1/h)	

(1) ArmorStart safety controller used in combination with ArmorStart safety-related parts.

Motor Overload Trip Curves

Motor overload current parameter provides class 10, 15, and 20 overload protection. Ambient insensitivity is inherent in the electronic design of the overload.

Figure 87 - Bulletin 281E Overload Trip Curves



Note: If an overload fault occurs, it can require 60 s or more before a fault reset is allowed. See Overload Class Parameter 107, Thermo-Utilization parameter 105, and OL Reset Level parameter 108 to adjust the reset time.

Note: When the mechanical motor brake voltage is applied by using power from the load side of the ArmorStart controller, the added load current can result in a phase imbalance or overload, if the FLA of the motor and the brake current are similar in scale.

Contactor Life Load Curves


$$280/1_12^* = 100\text{-C12}^*$$

$$280/1_23^* = 100\text{-C23}^*$$


Life Load Curves:

AC-3 Switching of squirrel-cage motors while starting

$$U_e = 230 \dots 400 \dots 460\text{V}$$




AC-3 & AC-4 10% AC-4 Mixed operation of squirrel-cage motors
 $U_e = 400 \dots 460V$




Maximum Operating Rates:

AC-3 Switching of squirrel-cage motors while starting
 $U_e = 230 \dots 460V$, Relative operating time 40%, Starting time $t_A = 0.25 s$



AC-4 Inching of squirrel-cage motors
 $U_e = 230 \dots 460V$, Starting time $t_A = 0.25 s$



Bulletin 284E Controller

Electrical Ratings		UL/NEMA	IEC	
Power Circuit	Rated Operation Voltage	380/220...480/277V AC	380/220...480/277V AC	
	Rate Insulation Voltage	600V	600V	
	Rated Impulse Voltage	6 kV	6 kV	
	Dielectric Withstand	2200V AC	2500V AC	
	Operating Frequency	50/60 Hz	50/60 Hz	
	Utilization Category	—	AC-3	
	Protection Against Shock	—	IPO	
	Rated Max. Output Operating Current	SVC - Performance		
			3-phase Hp Rating	Output Current [A]
		284E-FVD1P4Z*	0.5	1.4
284E-FVD2P3Z*		1	2.3	
284E-FVD4P0Z*		2	4	
284E-FVD6P0Z*		3	6	
284E-FVD7P6Z*	5	7.6		
Control Circuit	Rated Operation Voltage	24V DC (+10%, -15%), SELV or PELV, (A2 must be grounded at voltage source)		
	Rate Insulation Voltage	30V	30V	
	Rated Impulse Voltage	—	1.5 kV	
	Dielectric Withstand	1500V AC	2000V AC	
	Overvoltage Category	—	III	
	Operating Frequency	DC	DC	
Short Circuit Protection	Short Circuit Protection Device (SCPD) Performance Type 1	Short Circuit Protection	480Y/277V	
		-10 or -25	Sym. Amps rms	65 kA
			Max. Fuse⁽¹⁾	30 A
		-10 or -25	Sym. Amps rms	30 kA
Max. Circuit Breaker⁽²⁾	60 A			

(1) Class J, CC, and T fuses only.

(2) Only when used with Cat. No. 140G-H6C3-C60.

		UL/NEMA	IEC
Environmental	Operating Temperature Range	-20...+40 °C (-4...+104 °F)	
	Storage and Transportation Temperature Range	-25...+85 °C (-13...+185 °F)	
	Altitude ⁽¹⁾	1000 m	
	Humidity	5...95% (on-condensing)	
	Pollution Degree	3	
	Enclosure Ratings	NEMA Type 4/12	IP67
	Approximate Shipping Weight	13.6 kg (30 lb)	
Mechanical	Resistance to Shock		
	Operational	15 G	
	Non-Operational	30 G	
	Resistance to Vibration		
	Operational	1 G, 0.15 mm (0.006 in.) Displacement	
	Non-Operational	2.5 G, 0.38 mm (0.015 in.) Displacement	
	Power and Ground Terminals		
	Wire Size	Primary/Secondary Terminal: #16...#10 AWG	Primary/Secondary Terminal: 1.0...4.0 mm ²
	Tightening Torque	Primary Terminal: 10.8 lb-in. Secondary Terminal: 4.5 lb-in.	Primary Terminal: 1.2 N-m Secondary Terminal: 0.5 N-m
	Wire Strip Length	9 mm (0.35 in.)	
	Control		
	Terminal Wire Size	#18...#10 AWG	1.0...4.0 mm ²
	Tightening Torque	6.2 lb-in.	0.7 N-m
	Wire Strip Length	9 mm (0.35 in.)	
	Disconnect Lock Out	Recommend 8 mm (5/16 in.) lock shackle or hasp. The hasp must not exceed 8 mm (5/16 in.) when closed.	
Other Rating	EMC Emission Levels		
	Conducted Radio Frequency Emissions	10V rms Communications Cables 10V rms (PE) 150 kHz...80 MHz	
	Radiated Emissions	Class A, Group 1, equivalent to C2 emissions	
	EMC Immunity Levels		
	Electrostatic Discharge	4 kV contact and 8 kV Air	
	Radio Frequency Electromagnetic Field	10V/m, 80 KHz...1 GHz 3V/m, 1.4 GHz...2 GHz 1V/m, 2.0 GHz...2.7 GHz	
	Fast Transient	2 kV (Power) 2 kV (PE) 1 kV (Communications and Control)	
	Surge Transient	1 kV (12) L-L, 2 kV (2) L-N (Earth)	
	Internal Fan for 284	Fan L10 Operation data: 80K hr at 40 °C (104 °F)	
	SI - SM1 and SM2 (24V DC)	Contact Rating	DC-12 L/R, 1 ms resistive, 6 A
	Contact Type	IEC 60947-5-1 Annex L - mechanically	
SO - P/M		3 W/0.125 A per contactor (Two safety contactors)	

(1) See [Altitude Derating on page 259](#) for derating guide.

	UL/NEMA	IEC
Standards Compliance	UL 508C CSA C22.2, No. 14 EN50178 EN61800-3 EN/IEC 60947-4-2 CE Marked per Low Voltage 2006/95/EC EMC Directive 2004/108/EC ODVA for EtherNet/IP	
Certifications	UL, TÜV	

Control and I/O Power Requirements						
	Units	A1/A2 ⁽²⁾	A3/A2 ⁽³⁾	A1/A2 ⁽²⁾	A3/A2 ⁽³⁾	A3/A2 ⁽⁴⁾
		W/O HOA		W/ HOA		
Control Voltage	Volts	24V DC				
Module Inrush ⁽¹⁾	Amps	0.92	0.30	1.09	0.125	0.295
Module Steady	Amps	0.06	0.30	0.23	0.125	0.295
Total Control Power (Pick Up)	Watts	22.08	7.20	26.16	3.00	7.08
Total Control Power (Running)	Watts	1.44	7.20	5.52	3.00	7.08
Total Control Power (with Dynamic Brake or Output Contactor option)	Watts	—	—	12	3	8.4
Total Control Power (with Dynamic Brake and Output Contactor option)	Watts	—	—	15	3	8.4

- (1) Instantaneous capacitive inrush exists for less than 10 ms, which can exceed 20 A. The power supply must have sufficient capacity to support this amount of instant power demand when multiple units are turned ON simultaneously. If supplies are weaker, we recommend applying unswitched power (A3-A2) first and after a 2...4 second delay, apply switched power.
- (2) Add power requirements for outputs (1 A max.) to A1/A2.
- (3) Add power requirements for inputs (200 mA max.) to A3/A2.
- (4) If A1 power is disconnected.

Drive Ratings – VFD Output Current vs. Input Current					
Line Voltage [V]	Frequency [Hz]	3-Phase kW Rating	3-Phase Hp Rating	Output Current [A]	Input Current [A]
				Sensorless Vector Control	Sensorless Vector Control
380	50	0.4	—	1.4	2.15
		0.75	—	2.3	3.80
		1.5	—	4.0	6.40
		2.2	—	6.0	9.00
		3.0	—	7.6	12.40
460	60	—	0.5	1.4	1.85
		—	1	2.3	3.45
		—	2	4.0	5.57
		—	3	6.0	8.20
		—	5	7.6	12.5

Drive Characteristics	
Output Frequency	0 . . 400 Hz (Programmable)
Efficiency	97.5% (Typical)
Sensorless Vector Control	
Maximum (kW) Hp Rating/Input Voltage	5 Hp (3.3 kW)/480V AC
Preset Speeds	8
Skip Frequency	✓
StepLogic® Functionality	✓
Timer/Counter Functions	✓

Sensorless Vector Control (SVC)


Protective Specifications – Sensorless Vector Control	
Motor Overload Protection	I^2t overload protection – 150% for 60 seconds, 200% for 3 seconds (provides Class 10 protection)
Overcurrent	200% hardware limit, 300% instantaneous fault
Over Voltage	380 . . 460V AC Input – Trip occurs @ 810V DC bus voltage (equivalent to 575V AC incoming line)
Under Voltage	380 . . 480V AC Input – Trip occurs @ 390V DC bus voltage (equivalent to 275V AC incoming line)
Faultless Power Ride Through	100 milliseconds

Control Specifications – Sensorless Vector Control	
Carrier Frequency	2 . . 16 kHz. Drive rating is based on 4 kHz.
Frequency Accuracy – Digital Input	Within $\pm 0.05\%$ of set output frequency.
Speed Regulation – Open Loop with Slip Compensation	$\pm 1\%$ of base speed across a 60:1 speed range
Stop Modes	Multiple programmable stop modes including – Ramp, Coast, DC-Brake, Ramp-to-Hold, and S Curve.
Accel/Decel	Two independently programmable accel and decel times. Each time can be programmed from 0 . . 600 s in 0.1 s increments.
Electronic Motor Overload Protection	Class 10 protection with speed sensitive response

Motor Overload Trip Curves

Motor OL Current parameter provides Class 10 overload protection. Ambient insensitivity is inherent in the electronic design of the overload.

Figure 88 - 284E Overload Trip Curves



		UL/NEMA	IEC	
Input Ratings – Sourced from Control Circuit (A3/A2)	Rated Operation Voltage	24V DC		
	Input On-State Voltage Range	10...26V DC		
	Input On-State Current	3.0 mA @ 10V DC		
		7.2 mA @ 24V DC		
	Input Off-State Voltage Range	0...5V DC		
	Input Off-State Current	<1.5 mA		
	Maximum Input Frequency Response	200 Hz (DeviceLogix response is greater than 200 Hz. Network response depends on control system network performance.)		
	Input Filter – Software Selectable			
	Off to On	Settable from 0...64 ms in 1 ms increments		
	On to Off	Settable from 0...64 ms in 1 ms increments		
	Input Compatibility	—	IEC 1+	
	Number of Inputs	4		
	Sensor Source			
	Voltage Status Only	11...26.4V DC from unswitched power		
Current Available	50 mA, max per input, 200 mA, any single point			
Output Ratings – Sourced from Control Circuit (A1/A2)	Rated Operation Voltage	26.4V DC		
	Rate Insulation Voltage	250V		
	Dielectric Withstand	1500V AC (UL)	2000V AC (IEC)	
	Type of Control Circuit	Solid-state sourcing output		
	Type of Current	24V DC		
	Conventional Thermal Current Ith	0.5 A each, 1 A, max combined		
	Peak Output Current	Current limited 2...8 amps (5 amps, nom) @ 24V DC		
	Type of Contacts	Normally open (N.O.)		
	Number of Contacts	2		
	Load Types	Resistive or light inductive		
	Surge Suppression	Integrated diode, clamps @ 35V DC		
	Thermo-Protection	Integrated short circuit and over current protection		
	Maximum Cycle Rate	30 operations/minute capacitive and inductive loads		
	Maximum Blocking Voltage	35V DC		
	Maximum On-State Voltage @ Maximum Output	1.5V DC		
	Maximum Off-State Leakage Current	10 µA		
	Device Level Ring (DLR)	—	Beacon-based performance including IEEE 1588 end to end transparent clock	
		Fault Recovery	Ring recovery time is less than 3 ms for a 50 node network	
Ethernet Port	—	2 D-coded, 4-pin female M12 connectors		
	Ports	Embedded switch with 2 ports		
	IP Address	DHCP enabled by default		
	DHCP Timeout	30 s		
	Communication Rate	10/100 Mbps with auto negotiate half duplex and full duplex		
	Data	<ul style="list-style-type: none"> • Transported over both TCP and UDP • Min. of 500 I/O packets/second (pps) • Supports up to 150 concurrent TCP sockets 		
Web Server	—	Embedded web server		
	Security	Login and password configurable		
	Email	Support Simple Mail Transfer Protocol (SMTP)		
	Configuration	Status, diagnostics, and configuration tabs		

	UL/NEMA	IEC
Device Connections	Supports scheduled (Class 1) and unscheduled (Class 3 and UCMM) connections 6 - Class 3 connections are supported simultaneously Supports up to 2 Class 1 CIP connections [Exclusive owner (data) or listen-only]. One connection per PLC. Listen only connection requires a data connection to be established.	
	Class 1 Connection API: 2...3200 ms Class 3 Connection API: 100...10 000 ms	
	20 ms Request Packet Interval (RPI) default	
	3 concurrent Encapsulation sessions	
	TCP port supports 5 concurrent incoming connections	
Component Response Time	1732ES-IB12X0BV2 or 1732ES-IB8X0BV4	See ArmorBlock Guard I/O DeviceNet Installation Instructions, publication 1732DS-IN001
	Bulletin 284	8...12 ms
Probability of Dangerous Failure per hour and MTTF_d for Uncontrolled Stop⁽¹⁾	MTTF _d	100 years
	Average probability of dangerous failure per hour	6.0E-9 (1/h)

(1) ArmorStart safety controller used in combination with ArmorStart safety-related parts.

Altitude Derating

Altitude Rating for Bulletin 281

- No altitude derating up to 2000 m (6562 ft)

Altitude Rating for Bulletin 284

- **0.5 Hp:** No Derating up to 3000 m (9843 ft)
- **1 Hp:** No Derating up to 3000 m (9843 ft)
- **2 Hp:** Derate 1% per 100 m (328 ft) above 1000 m (3281 ft)
- **3 Hp:** No Derating up to 3000 m (9843 ft)
- **5 Hp:** Derate 1% per 100 m (328 ft) above 1000 m

Example: Application requires 2600 m for a 5 Hp ArmorStart controller

- 2600 m-1000 m= 1600 m
- 1600/100 = 16
- 16 * 1%= 16%. Derate output amps by 16%
- (1-.16)*7.6 amp = 6.4 amp

It is possible to extend the operational range of the units if the ambient temperature is lower than 40 °C (104 °F), or if line reactors are used.

Notes:

Accessories

Industrial Ethernet Media

D Code Connectivity (M12) – 1585D

Patchcords and Cordsets IP67		
M12 D Code	Connector Type	Cat. No. Unshielded
	Male Straight to Male Straight	1585D-M4TBDM ⁽¹⁾
	Male Straight to Male Right Angle	1585D-M4TBDE ⁽¹⁾
	Male Right Angle to Male Right Angle	1585D-E4TBDE ⁽¹⁾
	Male Straight to Female Straight	1585D-M4TBDF ⁽¹⁾

(1) Available in 0.3, 0.6, 1, 2, 5, 10, 15, and increments of 5 meters up to 75 meters.


Note: See www.ab.com/networks/media/ethernet to learn more about Industrial Ethernet Media.

Sensor Media

Description	Description	I/O Connection	Pin Count	Connector	Cat. No.
	DC Micro Patchcord	Input/Output	4-Pin	Straight Female Straight Male	889D-F4ACDM- ⁽¹⁾
				Straight Female Right Angle Male	889D-F4ACDE- ⁽¹⁾
	DC Micro V-Cable	Input		Straight Female	879D-F4ACDM- ⁽¹⁾
				Right Angle Female	879D-R4ACM- ⁽¹⁾

(1) Replace symbol with desired length in meters (for example, **Cat. No. 889D-F4ACDM-1** for a 1 m cable). Standard cable lengths: 1 m, 2 m, 5 m, and 10 m.


Sensor Wiring



Motor and Brake Cables

Description	Rating	Length m (ft)	Cat. No.
Single-ended, Non-shielded Motor Cable			
			
Non-shielded cordset cable assembly with straight male / flying leads, 29 mm shell, 4 Pin, 12 AWG Conductors	IP67, NEMA 4/12, TC-ER Bend radius not to exceed 10x the cable diameter Cable diameter 0.657 in. +/- 0.12 in. (16.71 mm +/- 0.5 mm) with four 12 AWG conductors	0.5	280-PWRM29G-M05
		1	280-PWRM29G-M1
		1.5	280-PWRM29G-M015
		2	280-PWRM29G-M2
		3	280-PWRM29G-M3
		4	280-PWRM29G-M4
		6	280-PWRM29G-M6
		8	280-PWRM29G-M8
		10	280-PWRM29G-M10
		12	280-PWRM29G-M12
Non-shielded cordset cable assembly with 90 deg male / Flying leads, 29 mm shell, 4 Pin, 12 AWG Conductors ⁽¹⁾	IP67, NEMA 4/12, TC-ER Bend radius not to exceed 10x the cable diameter Cable diameter 0.657 in. +/- 0.12 in. (16.71 mm +/- 0.5 mm) with four 12 AWG conductors	0.5	280-PWRM29H-M05
		1	280-PWRM29H-M1
		1.5	280-PWRM29H-M015
		2	280-PWRM29H-M2
		3	280-PWRM29H-M3
		4	280-PWRM29H-M4
		6	280-PWRM29H-M6
		8	280-PWRM29H-M8
		10	280-PWRM29H-M10
		12	280-PWRM29H-M12
		14	280-PWRM29H-M14

(1) Check for product availability. Contact your local Rockwell Automation sales office or Allen-Bradley distributor.

Description	Rating	Length m (ft)	Cat. No.
			
Non-shielded patch cable assembly with straight male / female receptacle, 29 mm shell, 4 Pin, 12 AWG Conductors	IP67, NEMA 4/12, TC-ER Bend radius not to exceed 10x the cable diameter Cable diameter 0.657 in. +/- 0.12 in. (16.71 mm +/- 0.5 mm) with four 12 AWG conductors	0.5	280-PWRM29A-M05
		1	280-PWRM29A-M1
		1.5	280-PWRM29A-M015
		2	280-PWRM29A-M2
		3	280-PWRM29A-M3
		4	280-PWRM29A-M4
		6	280-PWRM29A-M6
		8	280-PWRM29A-M8
		10	280-PWRM29A-M10
		12	280-PWRM29A-M12
		14	280-PWRM29A-M14
Non-shielded patch cable assembly with 90 deg male / 90 deg female receptacle, 29 mm shell, 4 Pin, 12 AWG Conductors ⁽¹⁾	IP67, NEMA 4/12, TC-ER Bend radius not to exceed 10x the cable diameter Cable diameter 0.657 in. +/- 0.12 in. (16.71 mm +/- 0.5 mm) with four 12 AWG conductors	0.5	280-PWRM29D-M05
		1	280-PWRM29D-M1
		1.5	280-PWRM29D-M015
		2	280-PWRM29D-M2
		3	280-PWRM29D-M3
		4	280-PWRM29D-M4
		6	280-PWRM29D-M6
		8	280-PWRM29D-M8
		10	280-PWRM29D-M10
		12	280-PWRM29D-M12
		14	280-PWRM29D-M14


(1) Check for product availability. Contact your local Rockwell Automation sales office or Allen-Bradley distributor.

Description	Rating	Length m (ft)	Cat. No.
Single-ended, Shielded Motor Cable			



Shielded cordset cable assembly with straight male / flying leads, 29 mm shell, 4 Pin, 12 AWG Conductors	IP67, NEMA 4/12, TC-ER Bend radius not to exceed 10x the cable diameter Cable diameter 0.657 in. +/- 0.12 in. (16.71 mm +/- 0.5 mm) with four 12 AWG conductors	0.5	284-PWRM29G-M05
		1	284-PWRM29G-M1
		1.5	284-PWRM29G-M015
		2	284-PWRM29G-M2
		3	284-PWRM29G-M3
		4	284-PWRM29G-M4
		6	284-PWRM29G-M6
		8	284-PWRM29G-M8
		10	284-PWRM29G-M10
		12	284-PWRM29G-M12
14	284-PWRM29G-M14		


Double-ended, Shielded Motor Cable




Shielded patch cable assembly with straight male / female receptacle with leads, 29 mm shell, 4 Pin, 12 AWG Conductors	IP67, NEMA 4/12, TC-ER Bend radius not to exceed 10x the cable diameter Cable diameter 0.657 in. +/- 0.12 in. (16.71 mm +/- 0.5 mm) with four 12 AWG conductors	0.5	284-PWRM29A-M05
		1	284-PWRM29A-M1
		1.5	284-PWRM29A-M015
		2	284-PWRM29A-M2
		3	284-PWRM29A-M3
		4	284-PWRM29A-M4
		6	284-PWRM29A-M6
		8	284-PWRM29A-M8
		10	284-PWRM29A-M10
		12	284-PWRM29A-M12
14	284-PWRM29A-M14		

Receptacles

Shielded straight male receptacle with 4 wires, 29 mm shell, 4 Pin, 12 AWG Conductors		0.3	284-M29M-M03
Shielded straight female receptacle with 4 wires, 29 mm shell, 4 Pin, 12 AWG Conductors		0.3	284-M29F-M03

Description	Rating	Length m (ft)	Cat. No.
Single-ended, Non-shielded, Source Brake Cable			
			
Non-shielded cord assembly with straight male receptacle with leads, 22 mm shell, 3 Pin, 16 AWG Conductors		0.5	285-BRC22-M05
		1	285-BRC22-M1
		1.5	285-BRC22-M015
		2	285-BRC22-M2
		3	285-BRC22-M3
		4	285-BRC22-M4
		6	285-BRC22-M6
		8	285-BRC22-M8
		10	285-BRC22-M10
		12	285-BRC22-M12
		14	285-BRC22-M14
Non-shielded cordset cable assembly with 90° male/ Flying leads 22 mm shell, 3 Pin, 16 AWG Conductors ⁽¹⁾		0.5	285-BRC22H-M05
		1	285-BRC22H-M1
		1.5	285-BRC22H-M015
		2	285-BRC22H-M2
		3	285-BRC22H-M3
		4	285-BRC22H-M4
		6	285-BRC22H-M6
		8	285-BRC22H-M8
		10	285-BRC22H-M10
		12	285-BRC22H-M12
		14	285-BRC22H-M14

(1) Check for product availability. Contact your local Rockwell Automation sales office or Allen-Bradley distributor.

Description	Rating	Length m (ft)	Cat. No.
Double-ended, Non-shielded, Source Brake Cable			
			
Non-shielded patch cable assembly with straight male / straight female receptacle with leads, 22 mm shell, 3 Pin, 16 AWG Conductors		0.5	285-BRC22-M05D
		1	285-BRC22-M1D
		1.5	285-BRC22-M015D
		2	285-BRC22-M2D
		3	285-BRC22-M3D
		4	285-BRC22-M4D
		6	285-BRC22-M6D
		8	285-BRC22-M8D
		10	285-BRC22-M10D
		12	285-BRC22-M12D
		14	285-BRC22-M14D
Non-shielded patch cable assembly with 90° male / 90° female receptacle with leads, 22 mm shell, 3 Pin, 16 AWG Conductors		0.5	285-BRC22D-M05
		1	285-BRC22D-M1
		1.5	285-BRC22D-M015
		2	285-BRC22D-M2
		3	285-BRC22D-M3
		4	285-BRC22D-M4
		6	285-BRC22D-M6
		8	285-BRC22D-M8
		10	285-BRC22D-M10
		12	285-BRC22D-M12
		14	285-BRC22D-M14
Receptacle			
Non-shielded receptacle straight male with flying leads 22 mm shell, 3 Pin, 14 AWG Conductors	IP67/NEMA Type 4 /12	0.5 (1.6)	285-M24M-M05
Non-shielded receptacle straight female with flying leads 22 mm shell, 3 Pin, 14 AWG Conductors	IP67/NEMA Type 4 /12	0.25 (0.8)	285-M24F-M025

Three-phase Power

Description ⁽¹⁾	Cat. No.	
Power cable - straight female to straight male	280-PWRM35A-M ⁽²⁾	
Power tee - 3-phase, 4-pole	280-T35	
Power tee - 3-phase, 4-pole, reducing drop (when using ArmorStart EtherNet/IP version 0.5...2 Hp)	280-RT35	
Field-attachable M35 connector - 10 AWG, 600V, 32 A	280-FAM35F (female)	280-FAM35M (male)

(1) UL Listed - UL 2237 (File No. E318496, Guide PVVA)

(2) See ArmorConnect Power and Control Media Selection Guide, publication [280PWR-SG001](#), for available lengths.

Note: See ArmorConnect Power and Control Media Selection Guide, publication [280PWR-SG001](#), for additional 3-phase media options.

24V DC Auxiliary Power

Description	Cat. No.
Cordset - mini straight female to flying leads	889N-F4AFC- ⁽¹⁾
Cordset - mini straight male to flying leads	889N-M4AFC- ⁽¹⁾
Patchcord - mini straight male to straight female	889N-F4AFNM- ⁽²⁾
Control power tee - 24V DC, 4-pole	898N-43PB-N-4KF
Auxiliary device T-port	898N-43PB-N4KT
ArmorStart auxiliary T-port (ArmorStart adapter tee when using ArmorStart EtherNet/IP version with quick disconnects)	898N-543ES-NKF
Patchcord - 5/6 pin mini (for use with ArmorStart auxiliary T-port drop) (ArmorStart drop from Tee when using ArmorStart EtherNet/IP version with quick disconnects)	889N-F65 ⁽¹⁾

(1) Replace symbol with 6F (1.8 m [6 ft]), 5 (5 m [16.4 ft]), or 10 (10 m [32.8 ft]) for standard cable length.

(2) Replace symbol with 2 (2 m [6.6 ft]), 5 (5 m [16.4 ft]), or 10 (10 m [32.8 ft]) for standard cable length.

Note: See <http://ab.rockwellautomation.com/connection-devices/cables-and-cordsets> for additional auxiliary power cable options.

Control Power Tee

Pin Count	Assembly Rating	Wiring Diagram	Cat. No.
4-pin	250V, 4 A, 4-pole		898N-43PB-N4KF

Sealing Caps



Description	EtherNet/IP	
	Input	Output
Plastic Sealing Cap (M12) ⁽¹⁾	1485A-M12	1485A-M12
Connector Aluminum Sealing Cap (M22)*	—	1485A-C1
Motor Connector Aluminum Sealing Cap (M35) for 25 A protection	—	889A-QMCAP
Dynamic Brake and Source Brake Connector (M22)	—	1485A-C1

(1) To achieve IP67 rating, sealing caps must be installed on all unused connections.

Handle Accessory

Description		Cat. No.
	Locking Tag Padlock attachment to the lockable handles Up to three padlocks 4...8 mm (5/16 in. diameter) shackle	140M-C-M3

Dynamic Brake Resistors Recommended Dynamic Brake Modules for Option DB1 (IP67 Resistor)

Drive and Motor Size kW	Cat. No. ⁽¹⁾	Resistance Ohms ± 5%	Continuous Power kW	Max Energy kJ	Max Braking Torque % of Motor	Application Type 1		Application Type 2	
						Braking Torque % of Motor	Duty Cycle %	Braking Torque % of Motor	Duty Cycle %
380...480 Volt AC Input Drives									
0.37 (0.5)	284R-360P500-M ⁽²⁾	360	0.086	17	305%	100%	47%	150%	31%
0.75 (1)	284R-360P500-M ⁽²⁾	360	0.086	17	220%	100%	23%	150%	15%
1.5 (2)	284R-360P500-M ⁽²⁾	360	0.086	17	110%	100%	12%	110%	11%
2.2 (3)	284R-120P1K2-M ⁽²⁾	120	0.26	52	197%	100%	24%	150%	16%
4 (5)	284R-120P1K2-M ⁽²⁾	120	0.26	52	124%	100%	13%	124%	10%

(1) Drive rating and DB part numbers are not interchangeable. Only use specified resistor. Customer is responsible to evaluate if performance meets application requirement.

(2) Length is user-selectable based on a suffix added to the catalog number. For a length of 500±10 mm, add **-M05** to the end of the catalog number. For a length of 1000±10 mm, add **-M1** to the end of the catalog number.


Note: Duty Cycle that is listed, is based on full speed to zero speed deceleration. For constant regen at full speed, duty cycle capability is half of what is listed.

Application Type 1 represents maximum capability up to 100% braking torque where possible.

Application Type 2 represents more than 100% braking torque where possible, up to a maximum of 150%.

Figure 89 - Bulletin 284 Dynamic Brake Resistor Approximate Dimensions

Dimensions are not intended to be used for manufacturing purposes.



Cat. No.	A mm (in.)	B mm (in.)	C mm (in.)	D mm (in.)	E mm (in.)	F mm (in.)	G mm (in.)	H mm (in.)	J mm (in.)	K mm (in.)
284R-091P500	89 ± 3 (3.5 ± 0.12)	215 ± 5 (8.46 ± 0.2)	M05 = 0.5 m M1 = 1 m ⁽¹⁾	235 ± 5 (9.25 ± 0.2)	60 ± 2 (2.36 ± 0.08)	127 (5)	12.54 (0.49)	60 ± 2 (2.36 ± 0.08)	50 ± 1.5 (1.97 ± 0.06)	106 ± 3 (4.17 ± 0.12)
284R-120P1K2		420 ± 5 (16.54 ± 0.2)		440 ± 5 (17.32 ± 0.2)						

(1) Length is user-selectable based on the suffix added to the catalog number. For a length of 500 ± 10 mm, add **-M05** to the end of the catalog number. For a length of 1000 ± 10 mm, add **-M1** to the end of the catalog number.

Note: The customer must help to protect the resistor if a shorted switch occurs in the VFD. This protection is done via PLC control. An example ControlLogix program can be downloaded from <http://samplecode.rockwellautomation.com>.

Applying More Than One ArmorStart Motor Controller in a Single Branch Circuit on Industrial Machinery

Introduction

In the general multiple-motor branch circuit case, installation of a motor controller that is not listed for group installation, violates the NEC® and NFPA® 79.

Each ArmorStart motor controller is listed for group installation. This appendix explains how to use this listing to apply ArmorStart motor controllers in multiple-motor branch circuits.

Background

The NEC® (*National Electrical Code*®) is NFPA® 70. NFPA 79 is the *Electrical Standard for Industrial Machinery*®. The 2014 version of the NEC refers to NFPA 79 in the first informational note of Article 670.

Group installation means that a single set of fuses or a single circuit breaker protects a branch circuit that supplies two or more motors and their controllers. Both the NEC and NFPA 79 have rules for installation of controllers in these multiple-motor branch circuits. Both also have special rules for controllers that are not Listed for group installation and general rules for controllers that are.

The special rules for controllers that are not Listed for group installation restrict some variable. These rules are found in the NEC 430.53(A), 430.53(B), and 430.53(C)(2)(b) and NFPA 79 7.2.10.2, 7.2.10.3, and the 7.2.10.4(1) condition “...does not exceed that permitted by 7.2.10.1...”. For example, for 480V motors, NEC 430.53(A) limits each rating of the motor to 1 Hp or less and the protective device rating to 15 A or less.

The following addresses this **general** case: If a motor controller is Listed for group installation, the NEC and NFPA 79 permit the following:

1. It can be installed in a branch circuit with other motors having any mix of horsepower ratings
2. Protection of all of the wiring and controllers with a single set of fuses or a single circuit breaker large enough to operate this mix of motors.

The rules for this general case are found in the NEC 430.53(C) and 450.53(D) and in NFPA 79 7.2.10.4 and 7.2.10.5.

For this general case, the following conclusions apply:

Importance of a Motor Controller Being Listed for Group Installation

- Unless a motor controller is listed for group installation, its listing covers only individual motor circuit installation, and installation of it in a general multiple-motor circuit violates the NEC and NFPA 79.
- This listing is physically important because it verifies that the short circuit current rating of the controller is valid with the larger fuses and circuit breakers necessary to operate the multiple-motor circuit.
- If a motor controller is not listed for group installation, the installer must add fuses or a circuit breaker in each input circuit of the motor controller.
- So, the group installation listing is important because it verifies that the short circuit current rating of the controller applies to the multiple-motor branch circuit and removes the requirement for the additional input circuit protective device or devices.

From the perspective of the ArmorStart product family, being listed for group installation means one set of fuses or one circuit breaker can protect a branch circuit that has two or more of these motor controllers that are connected to it. This appendix refers to this type of branch circuit as a multiple-motor branch circuit. The circuit topology that is shown in [Figure 90](#), is one configuration, but not the only possible configuration, of a multiple-motor branch circuit. In these circuits, a single set of fuses (or a single circuit breaker) protects multiple motors, their controllers, and the circuit conductors. The motors can be any mixture of power ratings and the controllers can be any mixture of motor controller technologies (magnetic motor controllers and variable-frequency AC drive controllers).

This appendix addresses only NFPA 79 applications. This limitation is not because these products are only suitable for industrial machinery, but because industrial machinery is their primary market. In fact, while all versions of the ArmorStart products can be applied on industrial machinery, the versions that have the Conduit Entrance Gland Plate Option can also be used in applications governed by NFPA 70, National Electrical Code (NEC), (see “ArmorStart Product Family”).

Listing Requirements for a “Factory Assembly” and “Separate Assemblies”

- The first sentence of NEC 430.53(C) relies on two terms that the NEC does not define: “factory assembly” and “separate assemblies”. But the text also requires both to be “listed”: “listed factory assembly” or “separate assemblies listed for such use”. 45A of UL 508C, “Power Conversion Equipment”, contains the 430.53(C) listing requirements for drives. 52A of UL 508, “Industrial Control Equipment”, contains the 430.53(C) listing requirements for contactor-based motor controllers. Neither standard contains the term “factory assembly” or the term “separate assemblies” and each requires this marking: “Suitable for motor group installation...”.
- Therefore, the terms “factory assembly” and “separate assemblies” do not change the listing requirements. All drives and contactor-based motor controllers that are listed for 430.53(C) installation are marked “Suitable for motor group installation...”.


In the 2012 Edition of NFPA 79, motor controllers that are listed for group installation can be installed in multiple-motor branch circuits according to either of two alternative sets of requirements. The first is found in 7.2.10.4(2), the second in 7.2.10.4(3). The requirements of 7.2.10.4(3) are similar to those requirements in 430.53(C) of NFPA 70, while the requirements of 7.2.10.4(2) are found only in NFPA 79. This appendix explains the requirements of 7.2.10.4(2), rather than those requirements of 7.2.10.4(3), because it is the simpler method to use for application of the ArmorStart family of motor controllers.

You must determine the requirements – NFPA 79 or NFPA 70 – to use for the application. When making this determination, it is necessary to understand the ArmorStart product characteristics and useful to understand the definition of industrial machinery. The section of this appendix, “ArmorStart Product Family”, specifies whether a motor controller is suitable for installation according to NFPA 79 or NFPA 70 (or both). The definition of industrial machinery is found in 3.3.56 of NFPA 79 and 670.2 of Article 670, Industrial Machinery, in NFPA 70.

These conventions are used throughout this appendix. First, although all equipment is connected to a three-phase electrical supply, all figures are shown as one-line diagrams. Second, although all ArmorStart motor controllers are listed for group installation with both fuses and a specific family of inverse time circuit breakers, this appendix considers only fuses. This limitation is done to avoid repetitive explanations with minor, but necessary qualifications, for circuit breakers. Generally, the principles for fuse selection also apply to inverse time circuit breaker selection. Third, all references, unless indicated otherwise, are to NFPA 79 – 2012.

Note: The following example uses an ArmorStart LT circuit. The ArmorStart LT provides a more comprehensive example,

Figure 90 - ArmorStart LT NFPA 79 Multi-motor Branch Circuit



ArmorStart Product Family

This section contains a brief description of the attributes of the ArmorStart LT motor controllers that are relevant to application of them in multiple-motor branch circuits. These same relative attributes can be assumed for ArmorStart controllers.

The term motor controller refers to the device that stops and starts the motor. The ArmorStart product family consists of two types of motor controllers. The Bulletin 290 and 291 controllers are magnetic motor controllers that use an electromechanical contactor to stop and start the motor. The Bulletin 294 motor controllers use a variable-frequency AC drive to stop, start, and vary the speed of the motor. This appendix refers to the Bulletin 290, 291 and 294 products as either motor controllers or just controllers.

Each ArmorStart motor controller uses an integrated overload relay and motor disconnecting means. The Underwriters Laboratories' (UL) listing for each motor controller confirms that the motor controller – including its integral overload relay and motor disconnecting means — is suitable for motor group installation.

The suitability of each ArmorStart LT motor controller for installation according to either NFPA 79 or NFPA 70 depends on the means of connecting the power circuit wiring. All controllers are suitable for installation in multiple-motor branch circuits on industrial machinery according to 7.2.10.4 of NFPA 79. The controllers that have the Conduit Entrance Gland Plate Option are also suitable for installation in multiple-motor branch circuits according to 430.53(C) and 430.53(D) of NFPA 70 (NEC). The controllers that have the Power Media Gland Plate Option are suitable for installation only on industrial machinery. These versions are limited to industrial machinery because the UL listing for the power media connectors themselves and their matching cable assemblies covers installation only on industrial machinery.

Multiple-motor Branch Circuits and Motor Controllers Listed for Group Installation – General

Multiple-motor branch circuits, like that shown in [Figure 90](#), have this fundamental tradeoff: protecting more than one controller with a single set of fuses requires more electrical and mechanical robustness in each controller.

In exchange for the elimination of the cost and space necessary for a dedicated set of fuses in front of each controller, the construction of each controller itself must be more robust. For the circuit configuration shown in [Figure 90](#) to be practical, the ampere rating of the fuse must be large enough to operate all motors, without opening, under normal start and run conditions. This rating of fuse must be larger than the rating permitted to protect a circuit that supplies only a single motor and its controller. In general, as the rating of the fuse increases, so does the magnitude of fault currents that flow until the fuse opens. This higher magnitude of fault current results in more damage to the controller. Therefore, the additional controller robustness is necessary to withstand these higher fault currents, without controller damage that can result in a shock or fire hazard.

Consequently to the controller, being Listed for group installation mostly means that the UL testing is performed with fuses that have this practical and higher, ampere rating. This testing verifies that it is reasonable to apply this controller in a multiple-motor branch circuit, provided the fuse is of the same class and does not have a rating that exceeds the marked rating on the controller.

The example in [Figure 91](#), illustrates this increase in the maximum ampere rating of fuse that is permitted to protect a controller. This example compares the rating of the fuse that is used in the UL testing of two variable-frequency AC drive-based motor controllers. Both controllers have a rated power of 0.5 Hp and a rated output current of 1.5 A. The controller that is shown on the left is intended for installation in individual-motor branch circuits. The controller that is shown on the right is the ArmorStart LT Bulletin 294 controller that must be listed for group installation to be installed, as intended, in multiple-motor branch circuits. For this example, assume that all testing is done with fuses of the same class.


The UL investigation of both controllers is done according to UL 508C, Power Conversion Equipment. The controllers are connected to the test supply through the three-phase conductors and equipment grounding conductor and then covered with cotton in areas that are likely to vent hot gases and sparks during the tests. During the test, electrical faults are impressed on the output of, and internal to, these variable-frequency AC drive-based controllers. An increase of the ampere rating of the fuses increases the magnitude of the fault currents that flow through, and damage, the controller before the fuses open. Afterwards, the damage to the controller is evaluated to determine whether a potential shock or fire hazard exists when protected by fuses having this ampere rating. One criterion of the evaluation is the examination of the equipment grounding conductor that must not open during the test. If the conductor opens, it can leave exposed conductive parts in an energized state (shock hazard). Another criterion is that the cotton must not ignite as this ignition indicates the expulsion from the controller of hot gases or molten metal fragments (fire hazard).

For the controller that is displayed on the left, UL 508C permits the individual-motor testing to be performed with the maximum rating of fuse that can be used to protect an individual-motor branch circuit. According to both NFPA 70 and NFPA 79, this rating is 400 percent of the full-load current rating of the largest motor that the controller can supply. In UL 508C, this rating is taken to be 400 percent of the rated output current of the controller, or 6 A.

For the controller that is displayed on the right, UL 508C permits the group installation testing to be performed with the maximum rating of fuse that can be used to protect a multiple-motor branch circuit. According to both NFPA 70 (430.53(C)) and NFPA 79 (7.2.10.4(3)), this rating is 250 amperes. The largest size of power conductor that the ArmorStart LT controller can accept, 10 AWG, determines this value, which is derived from the installation requirements of 430.53(C) and 430.53(D) of NFPA 70. Because the UL 508C test covers all possibilities in NFPA 70 and NFPA 79, it permits the maximum value of 250 amperes. This value covers 7.2.10.4(2), which permits only 100 amperes. However in this case, the manufacturer, Rockwell Automation, chose to test and mark with the lower value of 45 A. This value was chosen as the tradeoff between the maximum number and type of controllers in the branch circuit – limited by the maximum fuse rating - and the electrical and mechanical robustness that is engineered into each controller.

Therefore, to make its use in the multiple-motor branch circuit of [Figure 90](#) practical, the 0.5 Hp, Bulletin 294 controller was engineered to be robust enough to contain the damage safely, when protected by a fuse having a rating of 45 A, rather than just 6 A.

Figure 91 - UL508C Variable-frequency AC Drive Motor Controller Evaluation



Maximum Fuse Ampere Rating according to 7.2.10.4(1) and 7.2.10.4(2)

This section uses [Figure 92](#) to explain the requirements from 7.2.10.4(1) and 7.2.10.4(2) that are relevant to, and permit, the multiple-motor branch circuit of [Figure 90](#).

The following is the complete text of 7.2.10.4(1) and 7.2.10.4(2) and an abbreviated version of [Table 48](#) from the 2012 Edition of NFPA 79. The table is abbreviated to cover the size of conductors that are generally relevant to the ArmorStart LT motor controllers.

Complete Text

“7.2.10.4 Two or more motors or one or more motor(s) and other load(s), and their control equipment shall be permitted to be connected to a single branch circuit where short-circuit and ground-fault protection is provided by a single inverse time circuit breaker or a single set of fuses, provided the following conditions under (1) and either (2) or (3) are met:

- (1) Each motor controller and overload device is either listed for group installation with specified maximum branch-circuit protection or selected such that the ampere rating of the motor branch short-circuit and ground-fault protective device does not exceed that permitted by 7.2.10.1 for that individual motor controller or overload device and corresponding motor load.
- (2) The rating or setting of the branch short-circuit and ground-fault protection device does not exceed the values in [Table 48](#) for the smallest conductor in the circuit.”
- (3) ...(not considered in this appendix)

Table 48 - Abbreviated Table 7.2.10.4

Table 7.2.10.4 Relationship Between Conductor Size and Maximum Rating or Setting of Short-Circuit Protective Device for Power Circuits Group Installations

Conductor Size (AWG)	Maximum Rating Fuse or Inverse Time* Circuit Breaker (amperes)
...	...
...	...
14	60
12	80
10	100
8	150
6	200
...	...

The following text and [Figure 92](#) provide an explanation of 7.2.10.4(1) and (2). In the following, ellipsis points (...) replace the text not relevant to [Figure 90](#). Then each individual requirement is underlined and followed by an underlined letter in parentheses. This underlined letter in the following text corresponds to the letter in [Figure 92](#).


“7.2.10.4 Two or more motors (a)...and their control equipment (b) shall be permitted to be connected to a single branch circuit (c) where short-circuit and ground-fault protection is provided by a single inverse time circuit breaker or a single set of fuses (d), provided the following conditions under (1) and...(2)...are met:

(1) Each motor controller and overload device is... listed for group installation with specified maximum branch-circuit protection (e)...

(2) The rating or setting of the branch short-circuit and ground-fault protection device does not exceed the values in Table 7.2.10.4 for the smallest conductor in the circuit.” (f)

Summarizing the requirements relevant to [Figure 90](#): 7.2.10.4(1) and 7.2.10.4(2) permit two or more ArmorStart LT motor controllers to be installed in a single branch circuit provided (1) all motor controllers are listed for group installation, (2) the fuse does not exceed the maximum rating that [Table 48](#) permits to protect the smallest conductor and (3) the fuse complies with the maximum fuse ratings of all controllers.

Figure 92 - ArmorStart LT NFPA 79 Multi-motor Branch Circuit



Explanatory Example

The example addresses the overcurrent protection of the conductors, controllers, and motors. Protection for three overcurrent conditions is considered: motor running overloads, short-circuit (line-to-line) faults, and ground-faults (line-to-ground). The short-circuit fault and ground-fault protection is governed by 7.2.10.4(1) and 7.2.10.4(2) and explained in Requirements 1, 2, and 3 and [Figure 93](#). The overload protection, explained in Requirement 4, is governed by 7.3.1 and 7.3.1.1. Overload coordination depends on each conductor having the minimum ampacity that is given by 12.5.3 and 12.5.4. The method for determining this minimum ampacity is explained in Requirement 5 and [Figure 94](#).

The example branch circuit is shown in [Figure 93](#) and [Figure 94](#). The circuit topology consists of a set of 10 AWG conductors that supply multiple sets of 14 AWG conductors. Each set of 14 AWG conductors supply a controller and motor. These conductor sizes are chosen to be the smallest conductors that have sufficient ampacity, without derating, for the loads each must carry. All wiring is customer-supplied, rather than the ArmorConnect power media, because all controllers have the Conduit Entrance Gland Plate Option. Fuses protect the branch circuit.

The example addresses five basic requirements that the motor controllers, fuses, and conductors must satisfy. The letters in the circles on [Figure 93](#) and [Figure 94](#) are referenced in the explanations as letters in parentheses. Ellipses points (...) are used to replace NFPA 79 text that is not applicable to the multiple-motor branch circuit that is shown in [Figure 93](#) and [Figure 94](#). Unless indicated, all text is from NFPA 79.

Figure 93 - ArmorStart LT NFPA 79 Multi-motor Branch Circuit — Conductor and Controller Protection





Figure 94 - ArmorStart LT NFPA 79 Multi-motor Branch Circuit Minimum Conductor Ampacity



1. Requirement One: Controller Ratings — The motor controllers and overload relays must be listed for group installation with specified maximum branch-circuit protection.

Text: “7.2.10.4(1) Each motor controller and overload device is... listed for group installation with specified maximum branch-circuit protection...”

Analysis: To apply the ArmorStart LT motor controllers in the multiple-motor branch circuit that is shown in [Figure 93](#), 7.2.10.4(1) must be satisfied; each controller must be listed for group installation with specified maximum branch-circuit protection. The UL listing for each ArmorStart LT motor controller confirms that it – including its integral overload relay and motor disconnecting means — is suitable for motor group installation with specified fuses, satisfying 7.2.10.4(1). The Bulletin 290E and 291E controllers are listed for group installation according to UL 508, Industrial Control Equipment. The Bulletin 294E controllers are listed for group installation according to UL 508C, Power Conversion Equipment.

As shown in [Figure 94](#) (a) indicates the markings on the nameplate that satisfy 7.2.10.4(1). The marking “Suitable for Motor Group Installation” satisfies the requirement to be listed for group installation. The ratings that are located beneath the description “Max. Ratings” are the specified maximum branch circuit protection. The (a) beside the fuse or fuses indicates that the maximum protection that is specified on the nameplate applies to these fuses.

2. Requirement Two: Conductor Short-circuit and Ground-Fault Protection — The fuse must protect the conductors for short-circuit faults and ground faults.

Text: “7.2.10.4(2) The rating or setting of the branch short-circuit and ground-fault protection device does not exceed the values in [Table 48](#) for the smallest conductor in the circuit.”

Analysis: As shown in [Figure 93](#), 7.2.10.4(2) must be satisfied. The fuse, as indicated by the description in [Figure 93](#) (a), is the branch short-circuit and ground-fault protection device. The word circuit means the branch circuit. The conductors of the branch circuit start at the load side of the fuses and end at the input to the motor, including the conductors between the motor controllers and the motor. The smallest conductor in the circuit is any one of the 14 AWG conductors that supply each controller and motor. The note at (b) indicates that the conductor protection is based on the smallest conductor, 14 AWG. As shown in [Table 48](#), a 14 AWG conductor can be used in a circuit that is protected by a fuse of any class having a rating of 60 amperes or less (c). Therefore, selecting a fuse of any class with a maximum rating of 60 amperes satisfies the conductor protection requirement of 7.2.10.4(2).

Supplementary Note 1: The value that is specified in [Table 48](#) is the maximum rating of fuse that 7.2.10.4(2) permits to protect that size of conductor. The rating of the fuse can be set to the maximum value given by [Table 48](#) for the smallest conductor without further justification. However, if any controller, or other component, has a maximum rating of fuse that is less than the [Table 48](#) value, the maximum rating of the fuse protecting the branch circuit must be reduced to the lower value so that all components are applied according to their ratings. For example, as shown in Requirement Three, a lower value can be necessary to protect the motor controller within its ratings because its specified maximum protection is less than the rating that [Table 48](#) permits for the smallest circuit conductor. Another reason to use a lower rating of fuse is to provide more conservative conductor and controller protection. However, in all cases it is important to make sure that the ampere rating is sufficient to start and operate the motors without nuisance opening of the fuses.

Supplementary Note 2: The note at (b) points to the conductor on the output of the 0.5 Hp Bulletin 294E controller to emphasize that the smallest conductor in the circuit includes the conductors between each controller and motor. This includes the output of the variable-frequency AC drive-based Bulletin 294E controllers; even though these drives have electronic short-circuit protection. According to NFPA 79, the fuse, and not the drive's electronic short-circuit protection, provides the short-circuit fault and ground-fault protection for these output conductors.

Supplementary Note 3: Generally, connecting a smaller conductor to a larger conductor requires the installation of fuses at the connection. This connection can be made without this fuse, in some cases, by using a tap rule that indirectly protects the smaller conductor by limiting two things: the ratio of the ampacity of the larger conductor to the ampacity of the smaller conductor and the maximum length of the smaller conductor (see, for example, 7.2.8.2). When applying 7.2.10.4(2), such a tap rule is not applicable or necessary. In [Figure 93](#), the smaller 14 AWG conductors can be connected to combined load conductors of any size because 7.2.10.4 does not indirectly protect the smaller conductor by limiting the ratio of the larger to smaller conductor ampacities and the conductor length. Instead, [Table 48](#) protects the smallest conductor directly by specifying the maximum rating of fuse that can protect a branch circuit that contains a conductor of that size.

3. Requirement Three: Controller Short-Circuit and Ground-Fault Protection — Each motor controller must be protected according to its own ratings, that is, applied in accordance with its listing.

Text: “(1) Each motor controller and overload device is... listed for group installation with specified maximum branch-circuit protection...”

Analysis: See (d) in [Figure 93](#). The characteristics of the fuse or fuses permitted to protect the conductors (see Requirement 2) must now be compared to those in the ratings of the controller. To comply with the listing of each motor controller and overload relay, the fuse or fuses must comply with the maximum branch-circuit protection that is specified in the controller markings. Therefore, the fuse or fuses must be of a class that is marked on all controllers and the rating of the fuse or fuses must not exceed the rating that is marked on any of the controllers. The markings of each controller specify that a fuse having a maximum rating of 45 A can protect the motor controller. When connecting to an electrical supply having an available fault current of 5000 A or less, the class of the fuse is not specified and can be any class. When connecting to an electrical supply having an available fault current from 5000 to 10000 A, the class of the fuse must be CC, J, or T. Since the electrical supply has an available fault current of 9000 A, selecting a Class CC, J, or T fuse with a rating of 45 A or less, verifies that each motor controller is applied within its own ratings.

Supplementary Note 1: The rating of the fuse must not exceed the rating that is permitted by 7.2.10.4(2) to protect the smallest conductor in the circuit. Selecting a Class CC, J or T fuse with a rating of 45 A, being less than 60 A, also protects the conductors (see Requirement 2). Although the ArmorStart LT products presently have a maximum fuse rating of 45 A, future controllers can have maximum fuse ratings that exceed 60 A. In this case, the maximum rating of fuse is limited by the rating to protect the 14 AWG conductors, 60 A. The maximum rating that is permitted for the controller, 45 A, is a maximum rating and can be reduced, for more conservative protection, provided nuisance opening of the fuses do not occur.

Supplementary Note 2: In this appendix, a fuse having a rating of any class means a fuse having the let-through characteristics of a Class RK-5 fuse. Class RK-5 fuses are assumed to have the maximum let-through of any class of fuse. For this reason, the ArmorStart LT motor controllers that are marked for use with fuses, without a restriction to a particular class, have been tested with and are intended to be used with fuses having a class of RK-5. Of course, fuses of a class that have lower let-throughs than Class RK-5, such as Class CC, J, or T, are also acceptable. A fuse having a rating of any class also restricts the fuse to those that have been evaluated for use as branch-circuit protection devices. This means that semiconductor fuses, used to protect power electronic equipment, or supplemental fuses cannot be used to protect the multiple-motor branch circuit.

Supplementary Note 3: There are four complementary ratings relevant to the “specified maximum branch-circuit protection” of 7.2.10.4(1). They are: the fuse class, the maximum fuse rating, the voltage rating and connection of the source (480Y/277 V), and the available fault current of the source. Applying the controllers according to these four ratings means that a fault on the output of all controllers, and internal faults for Bulletin 294 controllers, will not result in a shock or fire hazard.

Supplementary Note 4: In this example, the assumption is made that the available fault current at the controller is that of the source on the line side of the fuses. Although it is true that the wiring impedance between the fuses and the first controller, reduces the fault current available at the controllers, this reduction is neglected by assuming the first controller, the 0.5 Hp, Bulletin 294 controller, is very close to the fuses.

4. Requirement Four: Overload Protection — The motors, conductors, and controllers must be protected against motor overload conditions.

Text:

“7.3.1 General. Overload devices shall be provided to protect each motor, motor controller, and branch-circuit conductor against excessive heating due to motor overloads or failure to start.”

“7.3.1.1 Motors. Motor overload protection shall be provided in accordance with Article 430, Part III, of NFPA 70.”

Analysis: Each ArmorStart LT motor controller incorporates an integral overload relay. This overload function must be set in accordance with Article 430, Part III of NFPA 70. Selecting the ampacity of the circuit conductors appropriately (see Requirement 5) makes sure that the overload relays, when set according to 7.3.1.1, will protect the conductors against overheating due to motor overloads.

Supplementary Note: Each individual controller overload relay directly protects the conductors that are connected to the input and output of that controller and the motor that the controller supplies. The combined load conductor is protected by the tripping of one or more of the controller overload relays, that removes the overloaded motor or motors before the combined load conductor overheats.

5. Requirement: Conductor Ampacity —The minimum ampacity of conductors.

Text:

“12.5.3 Motor circuit conductors supplying a single motor shall have an ampacity not less than 125 percent of the motor full-load current rating.”

“12.5.4 Combined load conductors shall have an ampacity not less than ... 125 percent of the full-load current rating of the highest rated motor plus the sum of the full-load current ratings of all other connected motors...”

Analysis: As shown in [Figure 94](#), (a), (b), and (c) explain the method for calculating the minimum required conductor ampacity for each of these conductors: input and output conductors of Bulletin 290E and 291E controllers (a), input and output conductors of Bulletin 294E controllers (b), and combined load conductors that supply Bulletin 290E, 291E, and 294E controllers (c). The currents I1 through I5 are the input currents to the controllers. For the Bulletin 290E and 291E controllers, these currents are the same as the output motor currents. For the Bulletin 294E controllers, these currents are the rated input currents.

The example does not address conditions of use such as an ambient temperature that exceeds 30 °C or more than three current-carrying conductors in a cable or raceway. In a particular application, these conditions of use can require derating of the ampacity that is given in Table 12.5.1. This example assumes that, under the conditions of use, both conductors have sufficient ampacity for the application. This means the 14 AWG conductors have an ampacity of no less than 9.5 A and the 10 AWG conductors have an ampacity of no less than 27.4 A.

Input and Output Conductors for Mechanical Controllers (a)

ArmorStart models that use an electromechanical contactor to control the motor, the input current like the output current, is just the current to the motor. Therefore, the minimum conductor ampacity for both input and output conductors is 125 percent of the motor full-load current rating, as specified in the text of 12.5.3 (a).

As shown in [Figure 94](#), the full-load current rating of a three-phase, 460 V, 5 Hp induction motor is 7.6 A. By using this value, both the input and output conductors must have an ampacity that is not less than 125% of 7.6 A or 9.5 A.

Input and Output Conductors for Variable Frequency Drives (b)

ArmorStart models that are a variable-frequency AC drive, are used to control the motor. These drives use a power conversion method that generates input currents that are larger than the output currents. The input currents are larger because, unlike the output currents to the motor, they are not sinusoidal. Consequently, when determining the minimum ampacity of the input conductors, the requirement of 12.5.3 must be based on the rated input current of the controller, rather than the full-load current rating of the motor. Therefore, the minimum ampacity of the input conductors must be 125% of the controller rated input current, while the ampacity of the output conductors must be 125% of the motor full-load current rating.

As shown in [Figure 94](#), the 1 Hp Bulletin 294E controller has a rated input current of 3.0 A. By using the rated input current, the conductors from the combined load conductors to the controllers must have an ampacity of 125% of 3.0 A or 3.75 A. The output conductors must have an ampacity of 125% of 2.1 A or 2.6 A.

Combined Load Conductors (c)

The requirement for the minimum ampacity of the combined load conductors is given by 12.5.4. When the combined load conductors supply one or more Bulletin 294E controllers, the minimum ampacity calculation of 12.5.4 must be made by substituting the rated input current of the Bulletin 294E controllers for the full-load current rating of the motors that these controllers supply.

In [Figure 94](#), the currents I1, I2, I3, I4, and I5 are the input currents to each controller. I3 and I4 are the full-load current ratings of the 5 Hp motors. I1, I2, and I5 are the rated input currents of the Bulletin 294E controllers. As shown in the explanatory text (c) in [Figure 94](#), the method for calculating the minimum ampacity of the combined load conductors follows: first, multiply the largest input current to any controller – Bulletin 290E, 291E, or 294E - by 125%. In this case, the input currents to the Bulletin 290E and 291E controllers, I3 and I4, are the largest, 7.6 A. Because they are the same, either can be used. Choose I3 to calculate 125% of the maximum. 125% of 7.6 A is 9.5 A. Second, sum the remaining input currents (I1, I2, I4, I5) for a total of 17.9 A. Third, add the result from the first step to the result from the second for a total of 27.4 A. Finally, the minimum ampacity of the combined load conductors is 27.4 A.

Supplementary Note 1: The input currents to the Bulletin 294E motor controllers are larger than the output currents to the motor because the input currents contain harmonics resulting from the power conversion process. This harmonic content and the magnitude of the resulting non-sinusoidal input currents depend on the impedance of the electrical supply. The value that is specified for the rated input current is the maximum value over the range of possible supply impedances. For this reason, the magnitude of current measured on a particular electrical system can be less than the specified value.

Common Industrial Protocol (CIP) Information

High-level Product Description

The ArmorStart EtherNet/IP controller is an extension of the ArmorStart DeviceNet controller. Three product types are offered:

Bulletin Number	Distributed Starter Type
281E	Reversing
284E	Inverter

Product Codes and Name Strings

The following table lists the product codes and name strings that are added to the ArmorStart product family for EtherNet/IP.

Product Code (hex)	Product Code (decimal)	Identity Object Name String
0xD1	209	ArmorStart Bulletin 281E 0.5...2.5 A 24V DC
0xD2	210	ArmorStart Bulletin 281E 1.1...5.5 A 24V DC
0xD3	211	ArmorStart Bulletin 281E 3.2...16 A 24V DC
0xDA	218	ArmorStart Bulletin 281E 0.3...1.5 A 24V DC
0x172	370	ArmorStart Bulletin 284E PF40 480V 0.5 Hp
0x174	372	ArmorStart Bulletin 284E PF40 480V 1 Hp
0x176	374	ArmorStart Bulletin 284E PF40 480V 2 Hp
0x177	375	ArmorStart Bulletin 284E PF40 480V 3 Hp
0x178	376	ArmorStart Bulletin 284E PF40 480V 5 Hp

CIP Explicit Connection Behavior

The ArmorStart controller lets run, jog, and user outputs be driven by connected explicit messages when no I/O connection exists, or when an I/O connection exists in the idle state. A single EtherNet/IP Class 3 explicit connection is allowed to send “explicit control” messages via an “Active Explicit” connection.

An EtherNet/IP Class 3 explicit connection becomes the “explicit control” connection when it becomes the first EtherNet/IP Class 3 explicit connection to send a “set” service to one of the following:

- The “value” attribute of any DOP instance (class code 0x09).

- The “data” attribute of any output (consumed) Assembly instance (class code 0x04).
- Attribute 3 or 4 of the Control Supervisor Object (class code 0x29).

EDS Files

Most of the information that is contained in the EDS (Electronic Data Sheet) files for the ArmorStart EtherNet/IP product line is able to be extracted via the network.

CIP Object Requirements

The following CIP objects are covered in the following subsections.

Class	Object
0x0001	Identity Object
0x0004	Assembly Object
0x0006	Connection Manager Object
0x0008	Discrete Input Point Object
0x0009	Discrete Output Point Object
0x000F	Parameter Object
0x0010	Parameter Group Object
0x001D	Discrete Input Group Object
0x001E	Discrete Output Group Object
0x0029	Control Supervisor Object
0x002C	Overload Object
0x0047	Device Level Ring Object
0x0048	QoS Object
0x0097	DPI Fault Object
0x0098	DPI Alarm Object
0x00B4	Interface Object
0x00F5	TCP/IP Interface Object
0x00F6	Ethernet Link Object

For convenience, all objects that are accessible via the EtherNet/IP port are included.

Identity Object

CLASS CODE 0x0001

The following class attributes are supported for the Identity Object:

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1
2	Get	Max Instance	UINT	9

Up to nine instances (Instance 1...9) of the Identity Object are supported. The following table shows what each instance represents, and what the revision attribute reports:

Instance	Name	Revision Attribute
1	EtherNet/IP Module	The firmware rev of the EtherNet/IP board main firmware.
2	EtherNet/IP Boot	The firmware rev of the EtherNet/IP board boot firmware.
3	FPGA	The rev of the FPGA program
4	Control Module	A coded revision that reflects the revision attribute of the other various identity object instances (excluding boot code). Major revisions are coded as: OSSMMMM <ul style="list-style-type: none"> • 0 = reserved by DeviceNet • SSS = Revision of Soft-start or inverter. Initial release = 0; We will be limited to support for 8 major revisions. • MMMM = Revision of Main ArmorStart board. Initial release = 1; We will be limited to support for 15 major revisions.
5	Main Control Board Operating System	The firmware rev of the Main ArmorStart board OS stored in flash memory.
6	Main Control Board Boot Code	The firmware rev of the Main ArmorStart board boot code stored in flash memory.
7	The Internal PF 40 Inverter	The firmware rev of the Inverter as read from the RS-485 connection.
8 ⁽¹⁾	MCB IIC Daughter Board	The firmware rev of the MCB IIC Daughter Board
9 ⁽¹⁾	BASE IIC Daughter Board	The firmware rev of the Base IIC Daughter Board

(1) These instance numbers assume the next available instance base on the unit configuration. (If the unit is a DOL (No Drive) and there is an MCB Daughter board present its instance number is 7.)

IMPORTANT Attempts to access Attribute 10 of all DeviceNet Main Control Board instances are blocked. If Attribute 10 (Heartbeat Interval) is accessed, an "Attribute Not Supported" error is generated.

Instance 1 of the Identity Object contains the following attributes:

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Vendor	UINT	1
2	Get	Device Type	UINT	22
3	Get	Product Code	UINT	Starter Rating specific
4	Get	Revision Major Revision Minor Revision	Structure of: USINT USINT	See table.
5	Get	Status	WORD	Bit 0...0 = Not Owned; 1 = Owned by Master Bit 2...0 = Factory Defaulted; 1 = Configured Bit 8 - Minor Recoverable fault Bit 9 - Minor Unrecoverable fault Bit 10 - Major Recoverable fault Bit 11 - Major Unrecoverable fault
6	Get	Serial Number	UDINT	Unique number for each device
7	Get	Product Name String Length ASCII String	Structure of: USINT STRING	Product Code specific
8	Get	State	USINT	Returns the value "3 = Operational"
9	Get	Configuration Consistency Value	UINT	"Module FRS"
102 ⁽¹⁾	Get	Build Number	UDINT	Build number of EtherNet/IP Module firmware.

(1) Instance 1 only.

The following common services are implemented for Instance 1. Service requests to other instances are serviced through the bridge.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	Yes	Yes	Get_Attributes_All
0x05	No	Yes	Reset
0x0E	Yes	Yes	Get_Attributes_Single

The Type 0 and 1 reset service types, reset the Control Module. The EtherNet/IP module performs the Type 0 or 1 reset on itself.

Assembly Object**CLASS CODE 0x0004**

The following class attributes are supported for the Assembly Object:

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1

The following static Assembly instance attributes are supported for each Assembly instance.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Number of Members in Member List	UINT	—
2	Get	Member List	Array of STRUCT	Array of CIP paths
		Member Data Description	UINT	Size of Member Data in bits
		Member Path Size	UINT	Size of Member EPATA in bytes
		Member Path	Packed EPATH	Logically encoded member name
3	Conditional	Data	Array of BYTE	—
4	Get	Size	UINT	Number of bytes in attribute 3
100	Get	Name String	STRING	—

The following services are implemented for the Assembly Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single
0x18	No	Yes	Get_Member

I/O Assemblies

The following table summarizes the Assembly instances that are supported in the ArmorStart EtherNet/IP product:

Instance	Type	Description
3	Consumed	Required ODVA Consumed Instance
52	Produced	Required ODVA Produced Instance
150	Produced	Default Bulletin 281E Produced Assembly
151 ⁽¹⁾	Produced	Default Bulletin 284E Produced Assembly
162	Consumed	Default Consumed Instance for DOL and Reversing Starters
166 ⁽¹⁾	Consumed	Default Consumed Instance for Inverter type Starters
191	Consumed	Empty assembly for Input Only I/O Connection
192	Consumed	Empty assembly for Listen Only I/O Connection

(1) These assemblies are selectable on Inverter Type ArmorStart units only.

Instances 3 and 52 are required by the ODVA Motor Starter Profile. When used as an EtherNet/IP Class 1 connection point, the I/O data attribute is simply passed through the bridge.

Instance 3

Here is the required output (consumed) assembly.

Instance 3 ODVA Starter								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	—	—	—	—	—	—	—	Run Fwd

Instance 52

Here is the required input (produced) assembly.

Instance 52 ODVA Starter								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
—	—	—	—	—	—	Running	—	Fault

Instance 150

Here is the default input (produced) assembly for Bulletin 281E starters.

Instance 150 "Starter Stat" - Default Status Assembly for Bulletin 281E Starters								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved (AOP Tag name: {name}:I.Fault)							
1	Reserved (AOP Tag name: {name}:I.Fault)							
2	Reserved (AOP Tag name: {name}:I.Fault)							
3	Reserved (AOP Tag name: {name}:I.Fault)							
4	—	—	—	Ready	RunningReverse	RunningForward	WarningPresent	TripPresent
5	—	—	DisconnectClosed	Hand	In3	In2	In1	In0
6	Pt07DeviceOut	Pt06DeviceOut	Pt05DeviceOut	Pt04DeviceOut	Pt03DeviceOut	Pt02DeviceOut	Pt01DeviceOut	Pt00DeviceOut
7	Logic Enable	Pt14DeviceOut	Pt13DeviceOut	Pt12DeviceOut	Pt11DeviceOut	Pt10DeviceOut	Pt09DeviceOut	Pt08DeviceOut
8	Value of the parameter pointed to by "Parameter Int00DeviceOut Cfg" (low byte) - ProducedWord0Param							
9	Value of the parameter pointed to by "Parameter Int00DeviceOut Cfg" (high byte) - ProducedWord0Param							
10	Value of the parameter pointed to by "Parameter Int01DeviceOut Cfg" (low byte) - ProducedWord1Param							
11	Value of the parameter pointed to by "Parameter Int01DeviceOut Cfg" (high byte) - ProducedWord1Param							
12	Value of the parameter pointed to by "Parameter Int02DeviceOut Cfg" (low byte) - ProducedWord2Param							
13	Value of the parameter pointed to by "Parameter Int02DeviceOut Cfg" (high byte) - ProducedWord2Param							
14	Value of the parameter pointed to by "Parameter Int03DeviceOut Cfg" (low byte) - ProducedWord3Param							
15	Value of the parameter pointed to by "Parameter Int03DeviceOut Cfg" (high byte) - ProducedWord3Param							

Note: Byte 0 - 3 refers to PLC communication status. All 1s (bit high) indicates a connection fault (communication fault) exists or all 0s (bit low) connection is normal.

Instance 151

Here is the default input (produced) assembly for Inverter Type Distributed Starters.

Produce Assembly - Instance 151 "Drive Status" - 284E Starters								
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved - {name}:I.Fault							
1	Reserved - {name}:I.Fault							
2	Reserved - {name}:I.Fault							
3	Reserved - {name}:I.Fault							
4	AtReference	Network ReferenceStatus	NetControlStatus	Ready	RunningReverse	RunningForward	WarningPresent	TripPresent
5	OutputContactor Status	BrakeContactor Status	DisconnectClosed	Hand	In3	In2	In1	In0
6	OutputFrequency (Low) (xxx.x Hz)							
7	OutputFrequency (High) (xxx.x Hz)							
8	Pt07DeviceOut	Pt06DeviceOut	Pt05DeviceOut	Pt04DeviceOut	Pt03DeviceOut	Pt02DeviceOut	Pt01DeviceOut	Pt00DeviceOut
9	LogicEnable	Pt14DeviceOut	Pt14DeviceOut	Pt13DeviceOut	Pt11DeviceOut	P10DeviceOut	Pt09DeviceOut	Pt08DeviceOut
10	Value of the parameter pointed to by "Parameter 13 Prod Assy Word 0" (low byte)" - Int00DeviceOut							
11	Value of the parameter pointed to by "Parameter 13 Prod Assy Word 0" (high byte)" - Int00DeviceOut							
12	Value of the parameter pointed to by "Parameter 14 Prod Assy Word 1" (low byte)" - Int01DeviceOut							
13	Value of the parameter pointed to by "Parameter 14 Prod Assy Word 1" (high byte)" - Int01DeviceOut							
14	Value of the parameter pointed to by "Parameter 15 Prod Assy Word 2" (low byte)" - Int02DeviceOut							
15	Value of the parameter pointed to by "Parameter 15 Prod Assy Word 2" (high byte)" - Int02DeviceOut							
16	Value of the parameter pointed to by "Parameter 16 Prod Assy Word 3" (low byte)" - Int03DeviceOut							
17	Value of the parameter pointed to by "Parameter 16 Prod Assy Word 3" (high byte)" - Int03DeviceOut							

Note: Byte 0 - 3 refers to PLC communication status. All 1s (bit high) indicates a connection fault (communication fault) exists or all 0s (bit low) connection is normal.

** Contactor	Reference
Contactor 1	Source Brake Contactor status
Contactor 2	Output Contactor status

Instance 162

Here is the standard output (consumed) assembly with Network Inputs.

Instance 162 Default Consumed DOL and Reversing Starter

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	OutB	OutA	—	—	—	ResetFault	RunReverse	RunForward
1	Pt07Deviceln	Pt06Deviceln	Pt05Deviceln	Pt04Deviceln	Pt03Deviceln	Pt02Deviceln	Pt01Deviceln	Pt00Deviceln
2	Pt15Deviceln	Pt14Deviceln	Pt13Deviceln	Pt12Deviceln	Pt11Deviceln	Pt10Deviceln	Pt09Deviceln	Pt08Deviceln

Instance 166

Here is the standard output (consumed) assembly for Inverter Type Distributed Starters with network inputs.

Instance 166 Consumed Inverter Type Starter with Network Inputs

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Out B	Out A	—	JogReverse	JogForward	ResetFault	RunReverse	RunForward
1	DriveInput4	DriveInput3	DriveInput2	DriveInput1	DecelCtrl_1	DecelCtrl_0	AccelCtrl_1	AccelCtrl_0
2	FreqCommand (Low) (xxx.x Hz)							
3	FreqCommand (High) (xxx.x Hz)							
4	Pt07Deviceln	Pt06Deviceln	Pt05Deviceln	Pt04Deviceln	Pt03Deviceln	Pt02Deviceln	Pt01Deviceln	Pt00Deviceln
5	Pt15Deviceln	Pt14Deviceln	Pt13Deviceln	Pt12Deviceln	Pt11Deviceln	Pt10Deviceln	Pt9Deviceln	Pt8Deviceln

Connection Manager Object CLASS CODE 0x0006

The following class attributes are supported for the Connection Manager Object.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1
2	Get	Max Instance	UINT	—
3	Get	Number of Instances	UINT	—
4	Get	Optional Attribute List	Array of UINT	—
6	Get	Max Number Class Attribs	UINT	—

Two Class 1 connections for I/O transfer are supported.

Six Class 3 explicit connections are supported.

The following instance attributes are supported:

Attribute ID	Access Rule	Name	Data Type	Value
1	Get/Set	Open Requests	UINT	Number of Forward Open service requests received.
2	Get/Set	Open Format Rejects	UINT	Number of Forward Open service requests that were rejected due to bad format.
3	Get/Set	Open Resource Rejects	UINT	Number of Forward Open service requests that were rejected due to lack of resources.
4	Get/Set	Open Other Rejects	UINT	Number of Forward Open service requests that were rejected for reasons other than bad format or lack of resources.
5	Get/Set	Close Requests	UINT	Number of Forward Close service requests received.
6	Get/Set	Close Format Requests	UINT	Number of Forward Close service requests that were rejected due to bad format.
7	Get/Set	Close Other Requests	UINT	Number of Forward Close service requests that were rejected for reasons other than bad format.
8	Get/Set	Connection Timeouts	UINT	Total number of connection timeouts that have occurred in connections that are controlled by this Connection Manager

The following services are implemented for the Connection Manager Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0E hex	Yes	Yes	Get_Attribute_Single
4E hex	No	Yes	Forward_Close
54 hex	No	Yes	Forward_Open

Class 1 Connections

Class 1 connections are used to transfer I/O data, and can be established to the assembly object instances. Each Class 1 connection establishes two data transports, one consuming and one producing. The heartbeat instances are used for connections that only access inputs. Class 1 uses UDP transport.

- Total numbers of supported Class 1 connections equals 2 (total for: exclusive owner + input only + listen only)
- Supported Actual Packet Interval (API): 2...3200 ms (Note: The minimum API can be higher if processor resources become a problem.)
- T->O (Target to Originator) Connection type: point-to-point, multicast
- O->T (Originator to Target) Connection type: point-to-point
- Supported trigger type: cyclic, change of state

The producing instance can be assigned to multiple transports, by using any combination of multicast and point-to-point connection types.

Only one Exclusive-owner connection is supported at each time. If there is already an Exclusive-owner connection that is established and an originator tries to establish a new Exclusive-owner connection an “Ownership conflict” (general status = 0x01, extended status = 0x0106) error code is returned.

For a connection to be established, the requested data sizes must be an exact match of the connections points that the connection tries to connect to. If the requested and actual sizes do not match, an “Invalid connection size” (general status = 0x01, extended status = 0x0109) error code is returned.

Exclusive Owner Connection

This connection type is used for controlling the outputs of the module and shall not be dependent on any other condition. Only one exclusive owner connection can be opened against the module.

If an exclusive owner connection is already opened “Connection in use” (general status = 0x01, extend status = 0x0100) error code is returned.

- Connection point O -> T shall be Assembly object, Instance 3, 162 or 166 (162 for product codes <= 0x100 only, 166 for product codes > 0x100 only).
- Connection point T -> O shall be Assembly object, Instance 52, 150 or 151 (150 for product codes <= 0x100 only, 151 for product codes > 0x100 only).

Listen Only Connection

This connection is dependent on another connection to exist. If that connection (exclusive owner or input only) is closed, the listen-only connection is also closed.

We recommend that the originator sets the data size in the Forward_Open be zero.

- Number of supported listen only connections equals two (shared with exclusive owner and listen only connection).
- Connection point O -> T shall be Assembly object, Instance 192 (Listen only heartbeat)
- Connection point T -> O shall be Assembly object, Instance 52, 150 or 151 (150 for product codes $\leq 0x100$ only, 151 for product codes $> 0x100$ only)

Class 3 CIP Connections

Class 3 CIP connections are used to establish connections to the message router. The connection is used for explicit messaging. Class 3 CIP connections use TCP connections.

- Three concurrent encapsulation sessions are supported
- Six concurrent Class 3 CIP connections are supported
- More than one Class 3 CIP connection per encapsulation session is supported
- Supported Actual Packet Interval (API): 100...10000 ms
- T->O Connection type: point-to-point
- O->T Connection type: point-to-point
- Supported trigger type: application

Discrete Input Point Object CLASS CODE 0x0008

The following class attributes are currently supported for the Discrete Input Point Object:

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	2
2	Get	Max Instance	UINT	4

Four instances of the Discrete Input Point Object are supported. All instances contain the following attributes.

Attribute ID	Access Rule	Name	Data Type	Value
3	Get	Value	BOOL	0 = OFF, 1 = ON
115	Get/Set	Force Enable	BOOL	0 = Disable, 1 = Enable
116	Get/Set	Force Value	BOOL	0 = OFF, 1 = ON

The following common services are implemented for the Discrete Input Point Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Discrete Output Point Object CLASS CODE 0x0009

The following class attributes are supported.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1
2	Get	Max Instance	UINT	4 or 10

Four instances of the Discrete Output Point Object are supported for DOL/ Reverser units. Ten instances are supported for Drive units. The following table summarizes the DOP instances.

Instance	Name	Alternate Mapping	Description
1	Run Fwd Output	0029-01-03	Run Forward output. For all starter types, this output is hard wired from the ArmorStart CPU to the actuator.
2	Run Rev Output	0029-01-04	Run Reverse output. For all starter types, this output is hard wired from the ArmorStart CPU to the actuator.
3	User Output 1	None	These are the two ArmorStart user outputs for all starter types.
4	User Output 2	None	
5	Drive Input 1	None	These four instances exist for Inverter units only. They are drive the outputs on the main control board that are connected to Drive Inputs 1 . . . 4.
6	Drive Input 2	None	
7	Drive Input 3	None	
8	Drive Input 4	None	
9	Drive Jog Fwd	None	This instance exists for Inverter units only.
10	Drive Jog Rev	None	

All instances contain the following attributes.

Attribute ID	Access Rule	Name	Data Type	Value
3	Get	Value	BOOL	0 = OFF, 1 = ON
5	Get/Set	Fault Action	BOOL	0 = Fault Value attribute, 1 = Hold Last State
6	Get/Set	Fault Value	BOOL	0 = OFF, 1 = ON
7	Get/Set	Idle Action	BOOL	0 = Fault Value attribute, 1 = Hold Last State
8	Get/Set	Idle Value	BOOL	0 = OFF, 1 = ON
113	Get/Set ⁽¹⁾	Pr Fault Action	BOOL	0 = Pr Fault Value attribute, 1 = Ignore
114	Get/Set ⁽¹⁾	Pr Fault Value	BOOL	0 = OFF, 1 = ON
115	Get/Set	Force Enable	BOOL	0 = Disable, 1 = Enable
116	Get/Set	Force Value	BOOL	0 = OFF, 1 = ON
117	Get/Set	Input Binding	STRUCT: USINT Array of USINT	Size of Appendix I encoded path Appendix I encoded path NULL path means Attribute 3 drives the output. Otherwise, this is a path to a bit in the Bit Table.

(1) For DOP Instances 1, 2, 9 and 10, Attributes 113 and 114 have "Get" only access, and their values are always 0.

The following common services are implemented for the Discrete Output Point Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Parameter Object

CLASS CODE 0x000F

The following class attributes are supported for the Parameter Object.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	—
2	Get	Max Instance	UINT	—
8	Get	Parameter Class Descriptor	WORD	—

The number of instances of the parameter object depend upon the type of Control Module that the EtherNet/IP board is connected to.

The following instance attributes are implemented for all parameter attributes.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get/Set	Value	Specified in Descriptor	—
2	Get	Link Path Size	USINT	—
3	Get	Link Path	Array of: BYTE EPATH	—
4	Get	Descriptor	WORD	—
5	Get	Data Type	EPATH	—
6	Get	Data Size	USINT	—
7	Get	Parameter Name String	SHORT_STRING	—
8	Get	Units String	SHORT_STRING	—
9	Get	Help String	SHORT_STRING	—
10	Get	Minimum Value	Specified in Descriptor	—
11	Get	Maximum Value	Specified in Descriptor	—
12	Get	Default Value	Specified in Descriptor	—
13	Get	Scaling Multiplier	UINT	—
14	Get	Scaling Divisor	UINT	—
15	Get	Scaling Base	UINT	—
16	Get	Scaling Offset	INT	—
17	Get	Multiplier Link	UINT	—
18	Get	Divisor Link	UINT	—
19	Get	Base Link	UINT	—
20	Get	Offset Link	UINT	—
21	Get	Decimal Precision	USINT	—

The following services are implemented for the Parameter Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	No	Yes	Get_Attribute_All
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single
0x4b	No	Yes	Get_Enum_String

Parameter Group Object **CLASS CODE 0x0010**

The following class attributes are supported for the Parameter Object.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	—
2	Get	Max Instance	UINT	—

The following instance attributes are supported for all parameter group instances.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Group Name String	SHORT_STRING	—
2	Get	Number of Members	UINT	—
3	Get	1st Parameter	UINT	—
4	Get	2nd Parameter	UINT	—
n	Get	Nth Parameter	UINT	—

The following common services are implemented for the Parameter Group Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	Yes	Yes	Get_Attribute_All
0x0E	Yes	Yes	Get_Attribute_Single

Discrete Input Group Object CLASS CODE 0x001D

No class attributes are supported for the Discrete Input Group Object.

A single instance of the Discrete Input Group Object is supported and contains the following instance attributes.

Attribute ID	Access Rule	Name	Data Type	Value
3	Get	Number of Instances	USINT	4
4	Get	Binding	Array of UINT	List of DIP Instances
6	Get/Set	Off_On_Delay	UINT	—
7	Get/Set	Off_On_Delay	UINT	—

The following common services are implemented for the Discrete Input Group Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	No	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Discrete Output Group Object CLASS CODE 0x001E

No class attributes are supported for the Discrete Output Group Object.

Instance 1 exists for all ArmorStart units. Instance 2 exists for drive units only.

Instance 1 contains the following instance attributes.

Attribute ID	Access Rule	Name	Data Type	Value
3	Get	Number of Instances	USINT	4 for DOL/Soft Starter 10 for Inverters
4	Get	Binding	Array of UINT	List of DOP Instances
6	Get/Set	Command	BOOL	0 = Idle, 1 = Run
104	Get/Set	Network Status Override	BOOL	0 = No override (go to safe state) 1 = Override (run local logic)
105	Get/Set	Comm Status Override	BOOL	0 = No override (go to safe state) 1 = Override (run local logic)

Instance 2 contains the following instance attributes.

Attribute ID	Access Rule	Name	Data Type	Value
3	Get	Number of Instances	USINT	4
4	Get	Binding	Array of UINT	5, 6, 7, 8
7	Get/Set	Fault Action	BOOL	0 = Fault Value Attribute, 1 = Hold Last State
8	Get/Set	Fault Value	BOOL	0 = OFF, 1 = On
9	Get/Set	Idle Action	BOOL	0 = Idle Value Attribute, 1 = Hold Last State
10	Get/Set	Idle Value	BOOL	0 = OFF, 1 = On
113	Get/Set	Pr Fault Action	BOOL	0 = Pr Fault Value Attribute, 1 = Ignore
114	Get/Set	Pr Fault Value	BOOL	0 = OFF, 1 = On

The following common services are implemented for the Discrete Output Group Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	No	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Control Supervisor Object CLASS CODE 0x0029

No class attributes are supported.

A single instance (Instance 1) of the Control Supervisor Object is supported and contains the following instance attributes.

Attribute ID	Access Rule	Name	Data Type	Value
3	Get/Set	Run 1	BOOL	These Run outputs also map to DOP Instances 1 and 2
4 ⁽¹⁾	Get/Set	Run 2	BOOL	—
7	Get	Running 1	BOOL	—
8 ⁽¹⁾	Get	Running 2	BOOL	—
9	Get	Ready	BOOL	—
10	Get	Tripped	BOOL	—
12	Get/Set	Fault Reset	BOOL	0->1 = Trip Reset
100	Get/Set	Keypad Mode	BOOL	0 = Maintained, 1 = Momentary
101	Get/Set	Keypad Disable	BOOL	0 = Not Disabled, 1 = Disabled
115	Get	Warning Status	WORD	Bits 0...1 = Reserved Bit 2 = PL Warning (does not apply for Ethernet version) Bit 3 = Reserved Bit 4 = PR Warning (does not apply for Ethernet version) Bit 5 = CP Warning Bit 6 = I/O Warning Bit 7 = Reserved Bit 8 = PI Warning (does not apply for Ethernet version) Bit 9 = DN Warning Bits 10...12 = Reserved Bit 13 = HW Warning Bit 14 = Reserved Bit 15 = DB Warning
124	Get/Set	Trip Enable	WORD	Bit enumerated trip enable word
130	Get/Set	Trip Reset Mode	BOOL	0 = Manual, 1 = Auto
131	Get/Set	Trip Reset Level	USINT	0 = 100%, Default = 75
150 ⁽²⁾	Get/Set	High Speed Ena	BOOL	0 = Disable, 1 = Enable
151	Get	Base Enclosure	WORD	Bit 0 = IP67 Bit 2 = PL Cat 4 Bits 3...15 Reserved
152	Get	Base Options	WORD	Bit 0 = Output Fuse Bit 2 = CP Fuse Detect Bits 3...7 = Reserved Bit 8 = 10A Base Bit 9 = 25A Base Bit 10...15 = Reserved
153	Get	Wiring Options	WORD	Bit 0 = Conduit Bit 1 = Round Media Bit 2 = 28xG Gland Bits 3...15 = Reserved

Attribute ID	Access Rule	Name	Data Type	Value
154	Get	Starter Enclosure	WORD	Bit 0 = IP67 Bit 1 = NEMA 4x Bit 2 = 28xG Ple Cat4 Bits 3... 15 Reserved
155	Get	Starter Options	WORD	Bit 0 = Full Keypad Bit 1 = Safety Monitor Bit 2 = Source Brake Bit 3 = CP Brake Bit 4 = Dynamic Brake Bit 5 = Output Contactor Bit 6 = EMI Filter Bit 7 = 0... 10V Analog In Bit 8 = Fused Dyn Brake Bits 9... 15 = Reserved
156	Get	Last Pr Trip	UINT	—
157 ⁽²⁾	Get	DB Status	WORD	Bit 0 = DB Faulted Bit 1 = DB Overtemp Warning Bit 2 = DB On Bit 3 = DB Flt Reset Inhibit Bits 4... 15 = Reserved
158 ⁽²⁾	Get	DB Fault	WORD	Bit 0 = DB Overtemp Bit 1 = DB OverCurrent Bit 2 = DB UnderCurrent Bit 3 = DB Shorted Switch Bit 4 = DB Open Bit 5 = Reserved Bit 6 = DB Bus Voltage Link Open Bit 7 = Reserved Bit 8 = DB Comms Bits 9... 15 = Reserved

(1) Reversing Starters and Inverter Starters only.

(2) Inverter Starters only.

The following common services are implemented for the Control Supervisor Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	No	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Overload Object

CLASS CODE 0x002C

No class attributes are supported for the Overload Object.

A single instance (Instance 1) of the Overload Object is supported for DOL and Reversing Starters. Instance 1 contains the following instance attributes.

Attribute ID	Access Rule	Name	Data Type	Value
3	Get/Set	FLA Setting	BOOL	xxx.x amps
4	Get/Set	Trip Class	USINT	—
5	Get	Average Current	INT	xxx.x amps
7	Get	% Thermal Utilized	USINT	xxx% FLA
8	Get	Current L1	INT	xxx.x amps
9	Get	Current L2	INT	
10	Get	Current L3	INT	
190	Get/Set	FLA Setting Times 10	BOOL	xxx.xx amps
192	Get	Average Current Times 10	UINT	xxx.xx amps
193	Get	Current L1 Times 10	UINT	xxx.xx amps
194	Get	Current L2 Times 10	UINT	
195	Get	Current L3 Times 10	UINT	

The following common services are implemented for the Overload Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	No	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Device Level Ring (DLR) Object

CLASS CODE 0x0047

The following class attributes are supported for the DLR Object.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	2

A single instance (Instance 1) is supported with the following instance attributes.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Network Topology	USINT	0 = Linear, 1 = Ring
2	Get	Network Status	USINT	0 = Normal 1 = Ring Fault 2 = Unexpected Loop Detect 3 = Partial Network Fault 4 = Rapid Fault/Restore Cycle
10	Get	Active Supervisor Address	Struct of UDINT Array of 6 USINT	Ring Supervisor
12	Get	Capability Flags	DWORD	0x00000002

The following common services are implemented for the DLR Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	Yes	Yes	Get_Attribute_All
0x0E	Yes	Yes	Set_Attribute_Single

Qos Object

CLASS CODE 0x0048

The following class attributes are supported for the QoS Object.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1

A single instance (Instance 1) is supported and it contains the following instance attributes.

Attribute ID	Access Rule	Name	Data Type	Value
1	Set	802 1Q Tag Enable	USINT	0 = Disable (Default) 1 = Enable
4	Set	DSCP Urgent	USINT	Default = 55
5	Set	DSCP Scheduled	USINT	Default = 47
6	Set	DSCP High	USINT	Default = 43
7	Set	DSCP Low	USINT	Default = 31
8	Set	DSCP Explicit	USINT	Default = 27

The following common services are implemented for the QoS Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

DPI Fault Object**CLASS CODE 0x0097**

The DPI Fault Object is implemented in the DeviceNet Main Control Board.

The following class attributes are supported:

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Class Revision	UINT	1
2	Get	Number of Instances	UINT	4
3	Get	Fault Cmd Write	USINT	0 = NOP, 1 = Clear Fault, 2 = Clear Flt Queue
4	Get	Fault Instance Read	UINT	The instance of the Fault Queue Entry that contains information about the Fault that tripped the Device.
6	Get	Number of Recorded Faults	UINT	The number of Faults that are recorded in the Fault Queue.

Four instances of the DPI Fault Object are supported. Instance 1 is the most recent fault while 4 is the oldest. They have the following instance attributes:

Attribute ID	Access Rule	Name	Data Type	Value
0	Get	Full/All Info	Struct of:	—
—	—	Fault Code	UINT	See Table 49 .
—	—	Fault Source	Struct of:	—
—	—	DPI Port Number	USINT	0
—	—	Device Object Instance	USINT	0x2c
—	—	B Fault Text	BYTE[16]	See Table 49 .
—	—	Fault Time Stamp	Struct of:	—
—	—	Timer Value	ULDINT	—
—	—	Timer Description	WORD	—
—	—	Help Object Instance	USINT	—
—	—	Fault Data		—
1	Get	Basic Info	Struct of:	—
—	—	Fault Code	UINT	See Table 49 .
—	—	Fault Source	Struct of:	—
—	—	DPI Port Number	USINT	0
—	—	Device Object Instance	USINT	0x2C
—	—	Fault Time Stamp	Struct of:	—
—	—	Timer Value	ULINT	—
—	—	Timer Description	WORD	—
3	Get	Help Text	STRING	See Table 49 .

The following services are supported:

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	Yes	Yes	Get_Attribute_Single
0x10	Yes	No	Set_Attribute_Single

The next table lists Fault Codes, Fault Text, and Fault Help Strings for DOL and Reversers.

Table 49 - Bulletin 281E Faults

Fault Code	Fault Text	Help Text
1	Hdw Short Ckt	The built-in 140M Circuit Breaker has tripped.
2	Sfw Short Ckt	The wire protection algorithm detected an unsafe current surge.
3	Motor Overload	Load has drawn excessive current that is based on trip class selected.
4	Fault 4	—
5	Phase Loss	Indicates missing supply phase. This fault can be disabled.
6	Fault 6	—
7	Fault 7	—
8	Fault 8	—
9	Fault 9	—
10	Fault 10	—
11	Fault 11	—
12	Fault 12	—
13	Control Pwr Loss	Indicates the loss of control power. This fault can be disabled.
14	Control Pwr Fuse	The Control Power Fuse has blown. Remove power and replace fuse.
15	Input Short	Flags a shorted sensor, input device, or input wiring mistake.
16	Output Fuse	The Output Fuse has blown. Remove all power and replace the fuse.
17	Over Temp	Indicates that the operating temperature has been exceeded.
18	Fault 18	—
19	Phase Imbalance	Indicates an imbalanced supply voltage.
20	Fault 20	—
21	A3 Power Loss	Unswitched (A3) Power was lost or dipped below the 12V DC threshold.
22	Internal Comm	Communication with an internal component has been lost.
23	Fault 23	—
24	Fault 24	—
25	Fault 25	—
26	Fault 26	—
27	MCB EEPROM	This is a major fault that renders the ArmorStart controller inoperable.
28	Base EEPROM	This is a major fault that renders the ArmorStart controller inoperable.
29	Fault 29	—
30	Wrong Base	The ArmorStart controller is connected to the wrong base type.
31	Wrong CTs	This is a major fault that renders the ArmorStart controller inoperable.

Table 49 - Bulletin 281E Faults

Fault Code	Fault Text	Help Text
32	Fault 32	—
33	Fault 33	—
34	Fault 34	—
35	Fault 35	—
36	Fault 36	—
37	Fault 37	—
38	Fault 38	—
39	Fault 39	—
40	Unknown Fault	—
41	Fault 41	—
42	Fault 42	—
43	Fault 43	—
44	Fault 44	—
45	Fault 45	—

The next table lists Fault Codes, Fault Text, and Fault Help Strings for VFD units.

Table 50 Bulletin 284E

Fault Code	Fault Text	Help Text
1	Hdw Short Ckt	The built-in 140M Circuit Breaker has tripped.
2	Fault 2	—
3	Motor Overload	The Load has drawn excessive current.
4	Drive Overload	150% load for 1 min. or 200% load for 3 sec. exceeded
5	Phase U to Gnd	A Phase U to Ground fault is detected between drive and motor.
6	Phase V to Gnd	A Phase V to Ground fault is detected between drive and motor.
7	Phase W to Gnd	A Phase W to Ground fault is detected between drive and motor.
8	Phase UV Short	Excessive current is detected between phases U and V.
9	Phase UW Short	Excessive current is detected between phases U and W.
10	Phase VW Short	Excessive current is detected between phases V and W.
11	Ground Fault	A current path to earth ground at one or more output terminals.
12	Stall	The drive is unable to accelerate the motor.
13	Control Pwr Loss	Indicates the loss of control power. This fault can be disabled.
14	Control Pwr Fuse	The Control Power Fuse has blown. Remove power and replace fuse.
15	Input Short	Flags a shorted sensor, input device, or input wiring mistake.
16	Output Fuse	The Output Fuse has blown. Remove all power and replace the fuse.
17	Over Temp	Indicates that the operating temperature has been exceeded.
18	Heatsink OvrTmp	The Heatsink temperature exceeds a predefined value.
19	HW OverCurrent	The drive output current has exceeded the hardware limit.
20	SW OverCurrent	Programmed parameter 198 (SW Current Trip) has been exceeded.

Table 50 Bulletin 284E

Fault Code	Fault Text	Help Text
21	A3 Power Loss	Unswitched (A3) Power was lost or dipped below the 12V DC threshold.
22	Internal Comm	Communication with the internal Power Flex drive has been lost.
23	Drive Comm Loss	The RS-485 port on the internal Power Flex stopped communicating.
24	Power Loss	Drive DC Bus Voltage remained below 85% of nominal bus voltage.
25	Under Voltage	DC Bus Voltage fell below the minimum value.
26	Over Voltage	DC Bus Voltage exceeded the maximum value.
27	MCB EEPROM	This is a major fault that renders the ArmorStart controller inoperable.
28	Base EEPROM	This is a major fault that renders the ArmorStart controller inoperable.
29	Drive EEPROM	The drive EEPROM checksum checks have failed.
30	Wrong Base	The ArmorStart controller is connected to the wrong base type.
31	Fan RMP	The internal cooling fan is not running properly.
32	Power Unit	A major failure has been detected in the drive power section.
33	Drive I/O Brd	A failure has been detected in the drive control and I/O section.
34	Restart Retries	Automatic fault reset and run retries exceeded.
35	Drive Aux In Flt	The drive auxiliary input interlock is open inside the ArmorStart controller.
36	Analog Input	(PF Fault Code 29)
37	Drv Param Reset	Internal Drive Parameters (Parameters > 100) have been defaulted.
38	SCV Autotune	The drive automatic tuning function was either aborted or failed.
39	Source Brake	The source brake fuse has blown. Remove power and replace fuse.
40	Unknown Fault	—
41	DB1 Comm	Communication with an internal DB1 board has been lost.
42	DB1 Fault	A fault has been detected with the operation of the Dynamic Brake.
43	DB Switch Short	The Dynamic Brake switch is shorted.
44	Fault 44	—
45 ⁽¹⁾	Incompatible COMM Device	The software version of the Drive is not compatible with the ArmorStart controller.

(1) The Fault text for this error is not return by the device, and is only reported as "Fault 45".

DPI Alarm Object**CLASS CODE 0x0098**

The following class attributes are supported:

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Class Revision	UINT	1
2	Get	Number of Instances	UINT	4
3	Set	Alarm Cmd Write	USINT	0=NOP, 1=Clear Fault, 2=Clear Flt Queue
74	Get	Alarm Instance Read	UINT	The instance of the Fault Queue Entry that contains information about the Fault that tripped the Device.
6	Get	Number of Recorded Faults	UINT	The number of Faults that are recorded in the Fault Queue.

Four instances of the DPI Alarm Object are supported with the following instance attributes. Instance 1 is the most recent fault while 4 is the oldest. See [Table 49 on page 312](#) and [Table 50 on page 313](#) for fault codes.

Attribute ID	Access Rule	Name	Data Type	Value
0	Get	Full/All Info	Struct of:	—
—	—	Alarm Code	UINT	—
—	—	Alarm Source	Struct of:	—
—	—	DPI Port Number	USINT	—
—	—	Device Object Instance	USINT	—
—	—	Alarm Text	STRING	—
—	—	Alarm Time Stamp	Struct of:	—
—	—	Timer Value	ULINT	—
—	—	Timer Descriptor	WORD	—
—	—	Help Object Instance	USINT	—
—	—	Alarm Data	—	—
1	Get	Basic Info	Struct of:	—
—	—	Alarm Code	UINT	—
—	—	Alarm Source	Struct of:	—
—	—	DPI Port Number	USINT	—
—	—	Device Object Instance	USINT	—
—	—	Alarm Time Stamp	Struct of:	—
—	—	Timer Value	ULINT	—
—	—	Timer Descriptor	WORD	—
3	Get	Help Text	STRING	—

The following services are supported.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	Yes	Yes	Get_Attribute_Single
0x10	Yes	No	Set_Attribute_Single

The next table lists Warning Codes, Warning Text, and Warning Help Strings that do not match the fault text.

Fault Code	Fault Text	Help Text
101	IP67/4X Mismatch	The Base enclosure type does not match the Control Module enclosure type.
102	DB Terminal	A warning has been detected with the operation of the Dynamic Brake.

Interface Object**CLASS CODE 0x00B4**

The following class attributes are supported.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1 for DOL 2 for Inverters

A single instance (Instance 1) of the Interface Object is supported with the following instance attributes.

Attribute ID	Access Rule	Name	Data Type	Min/Max	Default	Description
7	Get/Set	Prod Assy Word 0	USINT (rev 1) UINT (rev 2)	—	1	Defines Word 0 of Assy 120
8	Get/Set	Prod Assy Word 1	USINT (rev 1) UINT (rev 2)	—	5	Defines Word 1 of Assy 120
9	Get/Set	Prod Assy Word 2	USINT (rev 1) UINT (rev 2)	—	6	Defines Word 2 of Assy 120
10	Get/Set	Prod Assy Word 3	USINT (rev 1) UINT (rev 2)	—	7	Defines Word 3 of Assy 120
13	Get/Set	Starter COS Mask	WORD	0 to 0xFFFF	0xFFFF	Change of state mask for starter bits
15	Get/Set	Autobaud Enable	BOOL	0 to 1	1	1= enabled, 0 = disabled
16	Get/Set	Consumed Assy	USINT	0 to 185	162 (VFD 166)	3, 162 (also for drives 166, 191, and 192)
17	Get/Set	Produced Assy	USINT	100 to 187	150 (VFD 151)	52, 150, 161 (also for drive 151)
19	Get/Set	Set To Defaults	BOOL	0 to 1	0	0 = No action, 1 = Reset
23	Get	I/O Produced Size	—	0 to 20	—	—
24	Get	I/O Consumed Size	USINT	0 to 16	—	—
30	Get	DNet Voltage	UINT	—	—	DeviceNet Voltage
50	Get/Set	PNB COS Mask	WORD	0 to 0x00FF	0	Change of state mask for PNBs
64	Get/Set	Unlock Identity	USINT	—	0	Multiple Identity Object instances are unlocked when this attribute is set to the value 0x99.

The following common services are implemented for the Interface Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	No	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

TCP/IP Interface Object CLASS CODE 0x00F5

The following class attributes are supported.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1

One instance of the TCP/IP Interface Object is supported with the following instance attributes.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Status	DWORD	—
2	Get	Configuration Capability	DWORD	0x00000014
3	Get/Set	Configuration Control	DWORD	0 = Configuration from NVS 2 = Configuration from DHCP
4	Get	Physical Link Object	Struct of UINT Padded EPATH	2 words NULL Enet Link Object Instance
5	Get/Set	Interface Configuration	Struct of UDINT UDINT UDINT UDINT UDINT STRING	IP Address Network Mask Gateway Address Primary DNS Secondary DNS Default Domain Name for not fully qualified host names
6	Get/Set	Host Name	STRING	—
8	Get/Set	TTL Value	USINT	Time to Live value for EtherNet/IP multicast packets
9	Get/Set	Multicast Config	Struct of USINT USINT UINT UDINT	Allocation Control Reserved Number of multicast addresses to allocate (1...4) Multicast starting address.
11	Get/Set	LastConflictedDetected	Struct of	
		AcdActivity	USINT	State of last ACD Activity when last conflicted detected. Default = 0
		RemoteMAC	Array of 6 USINT	MAC address of a remote node from the ARP DPU in which a conflict was detected. Default = 0
		ArpPdu	Array of 28 USINT	Copy of raw ARP DPU in which a conflict was detected. Default = 0

The following common services are implemented for the TCP/IP Interface Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
	No	Yes	Get_Attribute_All
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Ethernet Link Object**CLASS CODE 0x00F6**

The following class attributes are supported.

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	3
2	Get	Max Instance	UINT	2
3	Get	Number of Instances	UINT	2

One instance of the Ethernet Link Object is supported with the following instance attributes.


Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Interface Speed	UDINT	10 or 100 Mbit/Sec
2	Get	Interface Flags	DWORD	See ENet/IP Spec
3	Get	Physical Address	ARRAY of 6 USINTs	MAC Address
4	Get	Interface Counters	Struct of: In Octets In Ucast packets In NUcast packets In Discards In Errors In Unknown Protos Out Octets Out Ucast packets Out NUcast packets Out Discards Out Errors	—
5	Get	Media Counters	Struct of: Alignment Errors FCS Errors Single Collisions SQE Test Errors Deferred Transmits Late Collisions Excessive Collisions MAC Transmit Errors Carrier Sense Errors Frame Too Long MAC Receive Errors	—
6	Get/Set	Interface Control	Struct of: Control Bits Forced Interface Speed	—
7	Get	Interface Type	USINT	—
8	Get	Interface State	USINT	—
9	Get/Set	Admin State	USINT	—
10	Get	Interface Label	SHORT_STRING	Instance 1: Port 1 Instance 2: Port 2

The following common services are implemented for the Ethernet Link Object.

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	No	Yes	Get_Attribute_All
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

DeviceLogix

DeviceLogix is a standalone Boolean program that resides within the ArmorStart controller. The program is embedded in the product software so that there is no additional module that is required to use this technology. To program DeviceLogix, you need the latest AOP for ArmorStart EtherNet/IP for ControlLogix or other Logix family PLCs.



In addition to the actual programming, DeviceLogix can be configured to operate under specific situations. It is important to note that the DeviceLogix program only runs if the logic has been enabled. Configuration can be done within the “Logic Editor.” The operation configuration is accomplished by setting the “Network Override” and “Communication Override” parameters. The following information describes the varying levels of operation:

- If both overrides are disabled and the logic is enabled, the ONLY time DeviceLogix runs is if there is an active I/O connection with a master (master is in Run mode). At all other times, DeviceLogix is running the logic, but does NOT control the state of the outputs.
- If the Network Override and the logic are enabled, then DeviceLogix controls the state of the outputs when the PLC is in Run mode and if a network fault such as Duplicate MAC ID or module Bus off condition occurs.

- If the Communications Override is enabled and the logic is enabled, the device does not need any I/O connection to run the logic. As long as there is control power and a DeviceNet power source that is connected to the device, the logic controls the state of the outputs.
- DeviceLogix provides a “Motion Disable” function that is driven from the DeviceLogix program. When this function is active all motor run commands are disabled, including the HOA. The run command is disabled regardless of where the command is initiated from such as DeviceLogix or DeviceNet.

DeviceLogix Programming

DeviceLogix has many applications and the implementation is typically only limited to the imagination of the programmer. Keep in mind that the application of DeviceLogix is only designed to handle simple logic routines.

DeviceLogix is programmed by using simple Boolean math operators such as AND, OR, NOT, timers, counters, and latches. Combine these Boolean operations with any of the available I/O to make decisions. The inputs and outputs that are used to interface with the logic can come from the network or from the device hardware. Hardware I/O is the physical Inputs and Outputs that are on the device, such as push buttons and pilot lights that are connected to the ArmorStart controller.

There are many reasons to use the DeviceLogix functionality, but some of the most common are listed:

- Increased system reliability
- Fast update times (1...2 ms possible)
- Improved diagnostics and reduced troubleshooting
- Operation independent of PLC or network status
- Continue to run process if network interruptions occur
- Critical operations can be safely shut down through local logic

DeviceLogix Programming Example


The following example shows how to program a simple logic routine to interface the ArmorStart ST controller with a remote hard-wired start/stop station. In this case, the I/O is wired as shown in [Table 51](#).

Table 51 - Hardware Bit Assignments and Description for the ArmorStart

Input Table		Output Table	
Bit	Description	Bit	Description
In 0	Start Button	Run Forward	Contacteur Coil
In 1	Stop Button	—	—
In 2	—	—	—
In 3	—	—	—

IMPORTANT Before programming logic, it is important to decide on the conditions to run the logic. As defined earlier, the conditions can be defined by setting parameter 8 (Network Override) and parameter 9 (Comm. Override) to the desired value.

1. While in the AOP, click the DeviceLogix tab. Click the Launch Editor button.




2. Select Function Block or Ladder editor.


Note: Once selected, you are not able to switch back without recreating the logic.



3. Locate the tool bar at the top of the DeviceLogix editor window, click the Move/Logical group, and select the RSTD (Latch Reset). Move it to the work space and click to drop it.




- From the toolbar, Click the “**Bit Input**” button and select **In 0** from the Hardware Boolean tree. This selection is the remote start button that is based on the example I/O table.




- Place the input to the left of the reset function. To drop the input on the page, left click the desired position.
- Place the mouse cursor over the tip of In 0. The tip turns green. Click the tip when it turns green.
- Move the mouse cursor toward the Set input of the reset function. A line follows the cursor. When a connection can be made, the tip of the RSL function also turns green. Click the on Input and the line is drawn from In 0 to the Set Input of the reset function.


Note: If this connection was not valid, one of the pin tips would have turned red rather than green. Left double-clicking the unused portion of the grid or pressing the “**Esc**” key at any time cancels the connection process.




8. From the toolbar, Click the “**Bit Input**” button and select **In 1** from the pull-down menu. This selection is the remote stop button that is based on the example I/O table.
9. Place the input to the left of the reset function.
10. Connect the input to the reset input of the reset function.



- From the toolbar, Click the “**Bit Output**” button and select “**Run Forward**” from the hardware Boolean tree. Run Forward is the relay controlling the coil of the contactor.




- Move the cursor into the grid and place the Output to the right of the reset function block.
- Connect the output of the reset function block to **Run Forward**.




- Click the “**Verify**” button that is located in the toolbar or select “Logic Verify” from the “Tools” pull-down menu.

- Click file close. The program is not saved automatically. Enter the information on the following window and accept changes. This action saves the program but has not been downloaded in the product.



- The last step is to enable the logic via the pull-down menu.




- Click OK. To download the DeviceLogix program, you must go on-line with the PLC and allow the download. Verify that the PLC is in the Program position. If in any other position, the download does not occur and an error is generated.
- The ArmorStart controller is now programmed and the logic is Active.

Import and Export

The ArmorStart EtherNet/IP AOP provides you with an import or export function.

The export function lets the DeviceLogix program be saved to a file. This file can then be imported into a similar product of same function regardless of horsepower. You cannot import DeviceLogix between unlike products, for example Bulletin 284E and Bulletin 280E controllers.



The screenshot displays a configuration interface for DeviceLogix. At the top, the 'Logic' status is set to 'Enabled' with a dropdown arrow. Below this, the 'Author' field contains the text 'test' and a 'Launch Editor' button. The 'Description' field contains the text 'Example'. The 'Revision' section includes three input fields: 'Major' with the value '1', 'Minor' with the value '0', and 'Date' with the value 'Wed May 16 16:27:36 2012'. The 'Revision Note' field contains the text 'Example DeviceLogix program'. At the bottom, the 'Import/Export' section features two buttons: 'Import From File' and 'Export To File', both of which are highlighted with red rectangular boxes.

Notes:

Replacement Parts

Bulletin 281E Standard Version Controller

Table 52 - Full Voltage and Reversing Control Replacement Module

Current Rating [A]	kW		Hp			Cat. No.
	230V AC 50 Hz	400V AC 50 Hz	200V AC 60 Hz	230V AC 60 Hz	460V AC 60 Hz	24V DC
0.24...1.2	0.18	0.37	—	—	0.5	281E-F12Z-NA-RG
0.5...2.5	0.37	0.75	0.5	0.5	1	281E-F12Z-NB-RG
1.1...5.5	1.1	2.2	1	1	3	281E-F12Z-NC-RG
3.2...16	4	7.5	3	5	10	281E-F23Z-ND-RG

Table 53 - Full Voltage and Reversing Base Replacement Module

Current Rating [A]	kW		Hp			Cat. No.
	230V AC 50 Hz	400V AC 50 Hz	200V AC 60 Hz	230V AC 60 Hz	460V AC 60 Hz	
0.24...1.2	0.18	0.37	—	—	0.5	280E-FN-10-RG
0.5...2.5	0.37	0.75	0.5	0.5	1	280E-FN-10-RG
1.1...5.5	1.1	2.2	1	1	3	280E-FN-10-RG
3.2...16	4	7.5	3	5	10	280E-FN-25-RG

For Motor and Brake Cables - See [Motor and Brake Cables](#)

Bulletin 284E Standard Version Controller

Table 54 - VFD Control Replacement Module

Input Voltage	kW	Hp	24V DC Control Voltage
380...480V 50/60 Hz 3-Phase	0.75	1.0	284E-FVD2P3Z-N-RG-SBG-DB1-EMI
	1.5	2.0	284E-FVD4P0Z-N-RG-SBG-DB1-EMI
	2.2	3.0	284E-FVD6P0Z-N-RG-SBG-DB1-EMI
	3.0	5.0	284E-FVD7P6Z-N-RG-SBG-DB1-EMI

Table 55 - VFD Base Replacement Module

Input Voltage	kW	Hp	24V DC Control Voltage
380...480V 50/60 Hz 3-Phase	0.75	1.0	280E-FN-10-RG
	1.5	2.0	280E-FN-10-RG
	2.2	3.0	280E-FN-25-RG
	3.0	5.0	280E-FN-25-RG

Bulletin 281E Safety Version Controller

Table 56 - Full Voltage and Reversing Safety Control Replacement Module

Current Rating [A]	kW		Hp			Cat. No.
	230V AC 50 Hz	400V AC 50 Hz	200V AC 60 Hz	230V AC 60 Hz	460V AC 60 Hz	24V DC
0.24...1.2	0.18	0.37	—	—	0.5	281E-F12S-NA-RG
0.5...2.5	0.37	0.75	0.5	0.5	1	281E-F12S-NB-RG
1.1...5.5	1.1	2.2	1	1	3	281E-F12S-NC-RG
3.2...16	4	7.5	3	5	10	281E-F23S-ND-RG

Table 57 - Full Voltage and Reversing Safety Base Replacement Module

Current Rating [A]	kW		Hp			Cat. No.
	230V AC 50 Hz	400V AC 50 Hz	200V AC 60 Hz	230V AC 60 Hz	460V AC 60 Hz	
0.24...1.2	0.18	0.37	—	—	0.5	280E-FNS-10-RG
0.5...2.5	0.37	0.75	0.5	0.5	1	280E-FNS-10-RG
1.1...5.5	1.1	2.2	1	1	3	280E-FNS-10-RG
3.2...16	4	7.5	3	5	10	280E-FNS-25-RG

Bulletin 284E

Safety Version Controller

Table 58 - VFD Safety Control Replacement Module

Input Voltage	kW	Hp	24V DC Control Voltage
380...480V 50/60 Hz 3-Phase	0.75	1.0	284E-FVD2P3S-N-RG-SBG-DB1-EMI
	1.5	2.0	284E-FVD4P0S-N-RG-SBG-DB1-EMI
	2.2	3.0	284E-FVD6P0S-N-RG-SBG-DB1-EMI
	3.0	5.0	284E-FVD7P6S-N-RG-SBG-DB1-EMI



Table 59 - VFD Safety Base Replacement Module

Input Voltage	kW	Hp	24V DC Control Voltage
380...480V 50/60 Hz 3-Phase	0.75	1.0	280E-FNS-10-RG
	1.5	2.0	280E-FNS-10-RG
	2.2	3.0	280E-FNS-25-RG
	3.0	5.0	280E-FNS-25-RG

Replacement Fuses

Description	
Output Fuse	
Fast-acting, high-interrupting capacity, tubular fuse Rating: 2.5 A, 250V Dimension [mm (in.)]: 20 (0.787) x 5 (0.197)	Littlefuse PN 021602.5
Control Fuse	
UL Listed Class CC, CSA HRC-1 Rating: 7 A, 600V Dimensions [in.]: 1.5 x 0.405	Cooper Bussman PN KTK-R-7 or Littlefuse PN KLKR007.T
Source Brake Fuse (For use with Bulletin 284 with Brake option CB/SB)	
UL Listed Class CC, CSA HRC-1 Rating: 3 A, 600V Dimensions [in.]: 1.5 x 0.405	Cooper Bussman PN KTK-R-3 or Littlefuse PN KLKR003.T

Replacement Parts

Description		Cat. No.
	Replacement Fan for 284 Control Module	284-FAN
	Replacement Guide Pins (two pins per package) ⁽¹⁾	284-PIN

(1) These pins are replacement parts for factory-installed alignment pins. They cannot be retrofitted in the field. The base module and control module require mating features as indicated in the following diagrams.



System Design Considerations When Using a Line Reactor

General Rule

Generally a line reactor for an ArmorStart controller is not required. Customers familiar with Rockwell Automation PowerFlex® drives can ask this question when installing an ArmorStart controller.

Reasons to Use

The most common reasons to use a line reactor are to:

- Extend the working life of the DC- bus capacitors by reducing the associated heat impact that comes from ripple noise currents in these capacitors.
- Reduce the impact of line disturbances on other equipment that result VFD input switching.
- Reduce the RMS input current that is associated with peak changes in current that results from VFD input switching. This current reduction allows the use of smaller input conductors and transformers.
- Mitigate the impact of power system transients on the drive.

Repeated line disturbances in current and voltage can lead to premature input power structure failure for AC drives. One way to mitigate these types of issues is to add impedance to the incoming power line to the drive. Impedance comes in the form of transformers, line reactors, and conductors. When a large power distribution system (>100 kVA) is feeding many small VFDs, the associated input impedance can be lower than 1%. This low impedance can result in voltage and current disturbances that negatively impact performance and the overall life of an AC drive. A line reactor is one possible solution to absorb these power line disturbances, but does not mean that a reactor must be used in every situation. Conductors add impedance. On-Machine solutions are typically further away from the power distribution panel therefore the length of cable adds impedance.

ArmorStart Design

The ArmorStart design incorporates features and additional components that make for better heat transfer, which keep the internal components cooler. This cooler design assures longer life of the DC bus capacitors that extend the life of the VFD. In addition, if line disturbance mitigation is necessary, the ArmorStart controller can be equipped with an EMI filter and shielded motor cable reducing the impact of the power switching components. However, if you specify input line reactors or transformers, the recommendation is to group the ArmorStart controllers at the distribution panel under one line reactor (not individual reactors or transformers).

Lastly, when full voltage ArmorStart controllers are included with VFD ArmorStart controllers, and line reactors are used, the starting currents of the full voltage ArmorStart controllers can be significant. The current must be accounted for in the selection of the line reactor or there is a risk of nuisance faults.

Application Examples

Manual Brake Control

If you want to activate the mechanical brake (source brake option) of the ArmorStart Bulletin 284E controller, there are several parameters that need attention. The following configuration lets the brake operate normally while running and when the Bulletin 284 controller is not running, it lets a release of the brake for maintenance.

See the consume assembly (164 for DeviceNet or 166 for EtherNet/IP).

1. Select which Drive Input (1, 2, 3, 4) to trigger the release of the brake. Configure the corresponding parameter that references the Drive Input P151, P152, P153, or P154.

Table 60 - Select Drive Input

Parameter Number	Parameter Name	Description	Factory Default	Group
151...154	Digital In 1 Sel	Selects the function for the digital inputs.	See Table 22 on page 175	Drive Advanced Setup
	Digital In 2 Sel			
	Digital In 3 Sel			
	Digital In 4 Sel			

- Set the Drive In you select to "27", Em Brk Release - If EM Brake function enabled, this input releases the brake manually.

27 ⁽¹⁾	Em Brk Rls	If EM Brake function is enabled, this input releases the brake. See parameter 155 and set to EM Brk Cntrl (22).
-------------------	------------	---

(1) Provides programmable control of Em Brk via digital input (1...4).

2. Set P137, Stop Mode to one of the following:
 - 8 = Ramp + EM B, CF Ramp to Stop with EM Brake Control. Stop command clears active fault.
 - 9 = Ramp + EM Brk Ramp to Stop with EM Brake Control.


3. Set P155, Relay Out Sel, to "22" EM Brk Cntrl EM Brake is energized.

- Program Parameter 260 (EM Brk OFF Delay) for desired action.
- Sets the time that the drive remains at minimum frequency (P134) before ramping to the commanded frequency.

<p>EM Brk OFF Delay</p> <p>Sets the time that the drive remains at minimum frequency before ramping to the commanded frequency. This action energizes the brake coil relay when Parameter 137 (Stop Mode) is set to Option 8 or 9.</p>	Parameter Number	260
	Related Parameters	134, 137
	Access Rule	GET/SET
	Data Type	UNIT
	Group	Drive Advanced Setup
	Units	0.01 sec
	Minimum Value	0.01 sec
	Maximum Value	10 sec
	Default Value	0.0 sec

- Program Parameter 261 (EM Brk On Delay) for desired action.
- (P137)

<p>EM Brk On Delay</p> <p>Sets the time that the drive remains at minimum frequency before stopping and de-energizing the brake coil relay when Parameter 137 (Stop Mode) is set to Option 8 or 9.</p>	Parameter Number	261
	Related Parameters	134, 137
	Access Rule	GET/SET
	Data Type	UNIT
	Group	Drive Advanced Setup
	Units	0.01 sec
	Minimum Value	0.01 sec
	Maximum Value	10.00 sec
	Default Value	0.0 sec



4. See the consume assembly next. The Drive Input that was configured in step #1, is used to control the mechanical brake.

Default Instance 166 Consumed Inverter Type Starter with Network Inputs					ArmorStart EtherNet/IP			
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Out B	Out A	—	JogReverse	JogForward	ResetFault	RunReverse	RunForward
1	DriveInput4	DriveInput3	DriveInput2	DriveInput1	DecelCtrl_1	DecelCtrl_0	AccelCtrl_1	AccelCtrl_0
2	FreqCommand (Low) (xxx.x Hz)							
3	FreqCommand (High) (xxx.x Hz)							
4	Pt07Deviceln	Pt06Deviceln	Pt05Deviceln	Pt04Deviceln	Pt03Deviceln	Pt02Deviceln	Pt01Deviceln	Pt00Deviceln
5	Pt15Deviceln	Pt14Deviceln	Pt13Deviceln	Pt12Deviceln	Pt11Deviceln	Pt10Deviceln	Pt9Deviceln	Pt8Deviceln

Bulletin 284 - VFD Preset Speed Example

DeviceLogix can be used to select one of multiple preset frequencies cooperatively with the PLC or independently based on your input. This selection can be done by using the four digit inputs or the frequency control bits in DeviceLogix. The digital inputs provide you with the most flexibility, but can be more complex to configure. If a preset speed is needed, the simpler approach is to use frequency control that is found in the produced network bits of DeviceLogix. If you prefer not to apply DeviceLogix for preset speeds, then implement the digit inputs to select preset speed via Instance 166 found in Chapter 5. The following example demonstrates the use of frequency control bits in DeviceLogix

Frequency control (Freq Cntl) bits allow a maximum of 4 Preset Speeds, each preset has a predefined accel or decel reference. If more are required, then digital inputs must be configured and properly used. The example focuses on Frequency Control 2,1,0 in the Produced Network Bit [Table 61](#).

Note: There are other capabilities that are shown in the table that are not reviewed in this example.

[Figure 95](#) shows all available network outputs supported by Bulletin 284. Referring to [Table 61](#) the preset frequencies are defined in parameter 170,171,172 and 173 of Bulletin 284. Also note the truth table that selects each of those frequencies. For example if Freq Cntl bit 2=1, 1=1, and 0=0 then the controller frequency is based on Parameter 172 (Preset Freq 2).

Figure 95 - Bulletin 284E Produced Network Bits in DeviceLogix Output

Name	Data Type
Hardware Boolean Output	
Network Boolean Output	
Pt00DeviceOut	BOOLEAN
Pt01DeviceOut	BOOLEAN
Pt02DeviceOut	BOOLEAN
Pt03DeviceOut	BOOLEAN
Pt04DeviceOut	BOOLEAN
Pt05DeviceOut	BOOLEAN
Pt06DeviceOut	BOOLEAN
Pt07DeviceOut	BOOLEAN
Pt08DeviceOut	BOOLEAN
Pt09DeviceOut	BOOLEAN
Pt10DeviceOut	BOOLEAN
Pt11DeviceOut	BOOLEAN
Pt12DeviceOut	BOOLEAN
Pt13DeviceOut	BOOLEAN
Pt14DeviceOut	BOOLEAN
ResetFault	BOOLEAN
AccelCtrl_0	BOOLEAN
AccelCtrl_1	BOOLEAN
DecelCtrl_0	BOOLEAN
DecelCtrl_1	BOOLEAN
FreqCtrl_0	BOOLEAN
FreqCtrl_1	BOOLEAN
FreqCtrl_2	BOOLEAN
DisableMotion	BOOLEAN
DisableKeypad	BOOLEAN

Table 61 -

See table 22 - Parameters 170...177 Preset Freq Options for predefined accel and decel

Accel2	Accel1	—	Description
0	0	—	No Command
0	1	—	Accel 1 Enable
1	0	—	Accel 2 Enable
1	1	—	Hold Accel Rate Selected
Decel 2	Decel 1	—	—
0	0	—	No Command
0	1	—	Decel 1 Enable
1	0	—	Decel 2 Enable
1	1	—	Hold Decel Rate Selected
Freq Ctrl 2	Freq Ctrl 1	Freq Ctrl 0	—
0	0	0	No Command
0	0	1	Freq Source = P136 (Start Source)
0	1	0	Freq Source = P169 (Internal Freq)
0	1	1	Freq Source = Comms
1	0	0	P170 (Preset Freq 0) (Accel/Decel 1)
1	0	1	P171 (Preset Freq 1) (Accel/Decel 1)
1	1	0	P172 (Preset Freq 2) (Accel/Decel 2)
1	1	1	P173 (Preset Freq 3) (Accel/Decel 2)

Use parameters 170...173, set them to 0, 10, 30, and 60 respectively. [Figure 96](#) shows the preset frequencies 0...3.

Figure 96 - P170...173 Preset Frequency Settings


ID	Name	Value	Min	Max	
156	EM Brake Contactor Level	0	0	9999	Sets the trip p
167	Accel Time 2	20.0	0.0	600.0	When active, s
168	Decel Time 2	20.0	0.1	600.0	When active, s
169	Internal Freq	60.0	0.0	400.0	Provides the fi
170	Preset Freq 0	0.0	0.0	400.0	Provides a fix
171	Preset Freq 1	10.0	0.0	400.0	Provides a fix
172	Preset Freq 2	30.0	0.0	400.0	Provides a fix
173	Preset Freq 3	60.0	0.0	400.0	Provides a fix
174	Preset Freq 4	60.0	0.0	400.0	Provides a fix
175	Preset Freq 5	40.0	0.0	400.0	Provides a fix
176	Preset Freq 6	50.0	0.0	400.0	Provides a fix
177	Preset Freq 7	60.0	0.0	400.0	Provides a fix
178	Jog Frequency	10.0	0.0	400.0	Sets the outpu

In this example, DeviceLogix receives data from the PLC program. The communication and network overrides are disabled as shown next.

7	Starter Command	
8	Network Override	Disabled
9	Comm Override	Disabled


Figure 97 shows the DeviceLogix program. This program lets you select one of three predefined frequencies that are based on two network bits.

Figure 97 - DeviceLogix Program




Once you exit the DeviceLogix editor, verify that the logic is “Enabled” otherwise the preset frequency control does not operate. See Figure 98.


Figure 98 -



This simple PLC program is used to select one of three preset speeds, speed 1, 2, or 3. For this example speeds 1, 2, and 3 are BOOL bits but they can be any valid input. Notice that there is an interlock for speed 1 and speed 2 to verify that they do not trigger simultaneously. A simultaneous trigger causes speed 3 to run accidentally.



Download the finished program file to the PLC. In order for the parameters and DeviceLogix program to update in the device, verify that the PLC is in program mode, and open the AOP for the Bulletin 284E controller.



Select the Parameters and DeviceLogix tab. This selection forces a correlation between the program file and the device. If a difference exists either upload from the device or download from the project to the device. In this example, choose to download.

Figure 99 is an example of the parameter correlation when a difference occurs between the project and the device.

Figure 99 -






Figure 100 is an example of the DeviceLogix correlation when a difference occurs between the project and the device.


Figure 100 - DeviceLogix Correlation



Note the caution statement before download.



After the DeviceLogix correlation is successful, the following window is displayed.



After both correlations are complete place the PLC in run mode and test the program by exercising speed bits 1, 2, and 3.

IMPORTANT To download a new DeviceLogix program, connect to the PLC and stay in program mode. There can be no active I/O connections to the device or the download fails. Open the AOP and select the DeviceLogix tab to start the correlation process. If a difference exists, then an upload or download is necessary.

Operation

When bit Speed_1 is ON, then the Bulletin 284E controller accelerates to 10 Hz or decelerate by using accel/decel Time 2.

When bit Speed_2 is ON, then the Bulletin 284E controller accelerates to 30 Hz or decelerate by using accel/decel Time 2.


DeviceLogix Ladder Editor Example

ArmorStart EtherNet/IP supports DeviceLogix in a ladder programming environment. When using the ladder editor, additional explanation is needed about naming conventions. Fault bits such as “Overload Trip” are tagged FB0, FB1, FB2, and so on. Status bits such as “Running Fwd” are tagged SB0, SB1, SB2, and so on. Outputs such as “Run Reverse” are tagged DOP0, DOP1, and so on. Produced Network Bits such as “Fault Reset” are tagged PNB0, PNB1, and so on.

This document helps you interpret the naming conventions.

ArmorStart Bulletin 281 Status Bits

The screen capture shows how to choose status bits in the ladder editor.




The following table contains the status bit definitions for ArmorStart Bulletin 281 units:

Status Bit Declaration
0 = Tripped
1 = Running Fwd
2 = Running Rev
3 = Ready
4 = Net Ctl Status
5 = At Reference
6 = Keypad Hand
7 = HOA Status
8 = 140M On
9 = Explicit Msg Cnxn Exists
10 = IO Cnxn Exists
11 = Explicit Cnxn Fault
12 = IO Cnxn Fault
13 = IO Cnxn Idle
14 = Current Flowing
15 = Keypad Hand Direction

ArmorStart Bulletin 281 Fault Bits

The screen capture shows how to choose fault bits in the ladder editor.




The following table contains the fault bit definitions for ArmorStart Bulletin 281 units:

Fault Bit Declaration
0 = Short Circuit
1 = Overload
2 = Phase Loss
3 = Control Power
4 = IO Fault
5 = Over Temp
6 = Phase Imbalance
7 = DNet Power Loss
8 = EEprom
9 = HW Flt
10 = PL Warning
11 = CP Warning
12 = IO Warning
13 = Phase Imbal Warn
14 = DN Warning
15 = HW Warning

ArmorStart Bulletin 281 Outputs

The screen capture shows how to choose outputs in the ladder editor.




Bulletin 281 has the following bit definitions:

- 0 = Run Forward
- 1 = Run Reverse
- 2 = User Output A
- 3 = User Output B

ArmorStart Bulletin 281 Produced Network Bits

The screen capture shows how to choose Produced Network Bits in the ladder editor.



The following table contains the produced network bit definitions for ArmorStart Bulletin 281 units

Produce Network bit declaration	
0 = Net Output 0	
1 = Net Output 1	
2 = Net Output 2	
3 = Net Output 3	
4 = Net Output 4	
5 = Net Output 5	
6 = Net Output 6	
7 = Net Output 7	
8 = Net Output 8	
9 = Net Output 9	
10 = Net Output 10	
11 = Net Output 11	
12 = Net Output 12	
13 = Net Output 13	
14 = Net Output 14	
15 = Fault Reset	
16 = Motion Disable	
17 = Keypad Disable	

ArmorStart Bulletin 284 Status Bits

The following table contains the status bit definitions for ArmorStart 284

Status bit declaration
0 = Tripped
1 = Warning
2 = Running Fwd
3 = Running Rev
4 = Ready
5 = Net Ctl Status
6 = Net Ref Status
7 = At Reference
8 = Drive Opto 1
9 = Drive Opto 2
10 = Keypad Jog
11 = Keypad Hand
12 = HOA Status
13 = 140M On
14 = Contactor 1
15 = Contactor 2
16 = Explicit Msg Cnxn Exists
17 = IO Cnxn Exists
18 = Explicit Cnxn Fault
19 = IO Cnxn Fau
20 = IO Cnxn Idle
21 = Keypad Hand Direction

ArmorStart Bulletin 284 Fault Bits

The screen capture shows how to choose Fault Bits in the ladder editor.

Tag Name	Data Type	
DIP	INT	
CNB	INT	
FB	INT	
SB	INT	
Latch		
Counter		
Timer		


0	1	2	3	4	5	6	7
8	9	10	11	12	13	14	15
16	17	18	19				

The following table contains the fault bit definitions for Bulletin 284:

Fault bit declaration	
0	= Short Circuit
1	= Overload
2	= Phase Short
3	= Ground Fault
4	= Stall
5	= Control Power
6	= IO Fault
7	= Over Temp
8	= Phase Over Current
9	= DNet Power Loss
10	= Internal Comm
11	= DC Bus Fault
12	= EEprom
13	= HW Flt
14	= Reset Retries
15	= Misc. Fault
16	= CP Warning
17	= IO Warning
18	= DN Warning
19	= HW Warning

ArmorStart Bulletin 284 Outputs

The screen capture shows how to choose outputs in the ladder editor.




Bulletin 284 bit definitions:

- 0 = Run Forward
- 1 = Run Reverse (Reserved)
- 2 = User Output A
- 3 = User Output B
- 4 = Drive Digital In 1
- 5 = Drive Digital In 2
- 6 = Drive Digital In 3
- 7 = Drive Digital In 4
- 8 = Jog Forward
- 9 = Jog Reverse

ArmorStart Bulletin 284 Produced Network Bits

The screen capture shows how to choose Produced Network Bits in the ladder editor.



The following table contains the produced network bit definitions for ArmorStart Bulletin 284 units:

Produce network bit declaration
0 = Net Output 0
1 = Net Output 1
2 = Net Output 2
3 = Net Output 3
4 = Net Output 4
5 = Net Output 5
6 = Net Output 6
7 = Net Output 7
8 = Net Output 8
9 = Net Output 9
10 = Net Output 10
11 = Net Output 11
12 = Net Output 12
13 = Net Output 13
14 = Net Output 14
15 = Fault Reset
16 = Accel 1
17 = Accel 2
18 = Decel 1
19 = Decel 2
20 = Freq Select 1
21 = Freq Select 2
22 = Freq Select 3
23 = Motion Disable
24 = Keypad Disable

Report Examples

How to Report the RPM of the Bulletin 284 Internal Fan

To get the fan RPM of the fan, an explicit "get single" message instruction is needed by using a service of 0x000E.

The fan RPM can be read by using the following CIA Class 0x00B4, Instance 1, and Attribute 103. The nominal fan rpm value is 2800...3000 RPM. The ArmorStart controller trips once the fan speed falls below 62% (1736)

There is no FAN FAULT warning. You must develop your own warning PLC code by using the CIA message that is listed previously, for critical applications.

How to Report the Heat Sink Temperature of the Bulletin 284


To get the heat sink temperature of the Bulletin 284, an explicit "get single" message instruction is needed.

The heat sink temperature can be read by using the following CIA Class 0x000F, Instance 124, and Attribute 1.

Service: e (hex) Class: f (hex) Instance: 124 Attribute: 1 (hex)

How to Report the Last Four Faults

By default, the ArmorStart controller provides only the last fault as a parameter. To retrieve the last four faults, a PLC message instruction is required. Class 0x0097 DPI Fault Object is used to extract a structure of information that is related to the last four faults. The following example shows how to configure an explicit message to get all four fault logs. To retrieve information on all four faults, the instance value must be indexed from 1, 2, 3, and 4, where 1 is the most recent fault information. If more detailed information is needed, change the attribute to 0.



How to Report an IP Address Conflict Detection

Locate CIP Class 0x00F5 address conflict detection. This detection is stored in nonvolatile memory and can be accessed through the TCP/IP Interface Object, instance 1, attribute 11 (“LastConflictDetected”) via Message instruction.


Demand Torque Off Considerations

ArmorStart EtherNet/IP does not support “safety torque off” internally, therefore this capability must be implemented external to the ArmorStart controller within the safety circuit. To achieve a required safety performance without damage to the ArmorStart Bulletin 284 controller, some coordination between the safety circuit and the VFD enable is required. When there is a demand of the safety system, it is important that the ArmorStart VFD is disabled before any line side contactor opening. One way to accomplish this task, digitally, is to configure one of digital inputs via parameter 151...154 to option 9. Then use the consumed instance 166 and the previously defined digit input to disable the VFD before the safety contactor opens. This action disables the ArmorStart controller and lets the contactors open without damaging the VFD. Alternatively, if the safety circuit removes A1-A2 (switched control power) power before the safety contactors open, the same behavior results and helps stop damage to the VFD.

Keypad Disable with DeviceLogix

HOA operation can be stopped dynamically without parameter modification, as follows:


The DeviceLogix program that is shown, turns off the keypad if both inputs are true and the keypad is in either “OFF” or “AUTO” mode.



Note: If you are already pressing the “HAND” button, the program does not disable the keypad; if the inputs are on after the “HAND” mode is actuated.


Motion Disable

The motion disable program disables motion regardless of the HOA status, PLC control, or DeviceLogix. Once motion disable is turned off, the ArmorStart controller or PLC resumes control of the motor again. The motion disable does not disable the HOA keypad. The keypad operation appears normal but it does not control the run command until the motion disable is off.



Cable System Quick Reference Diagram

This quick reference diagram shows the cordsets and connectors and an example of the minimum cables that are required to complete a system. It also shows how to integrate ArmorStart ST devices and ArmorStart EtherNet/IP when the HOA (hand-off-auto) option is required.



- 1 CAT5e Bulkhead Connector – Cat. No. 1585A-*
- 2 CAT5e Patchcord, – Cat. No. 1585D-*
- 3 CAT5e, RJ45 to RJ45 – Cat. No. 1585J-*
- 4 Three-Phase Power Receptacles – Cat. No. 280-M35F-*
- 5 Three-Phase Power Cable (M35) – Cat. No. 280-PWRM35*
- 6 ArmorBlock Guard I/O – Cat. No. 1732ES-IB8XOBV2
- 7 Three-Phase Power Tee – Cat. No. 280-T35
- 8 Control Power Receptacles – Cat. No. 888N-*
- 9 Control/Auxiliary Power Cables – Cat. No. 889N-F4*
- 10 Control/Auxiliary Power Tees – Cat. No. 898N-43PB-N4KT
- 11 I/O Cable between Safety I/O Module and ArmorStart Controller – Cat. No. 889D-*
- 12 ArmorStart Auxiliary T-Port – Cat. No. 898N-543ES-NKF
- 13 Control Power Drop Cable – Cat. No. 889N-F65*
- 14 Three-Phase Power Cable (M22) – Cat. No. 280-PWRM22-*
- 15 Three-Phase Tee Reducing Drop – Cat. No. 280-RT35

Notes:

A**AC supply considerations, Bulletin 284E 44****accessories 261**

- 24V DC auxiliary power 268
- dynamic brake resistors 269
- handle 269
- industrial ethernet media 261
- motor and brake cables 263
- sealing caps 269
- sensor media 262
- three-phase power 268

application examples 337, 355**ArmorBlock Guard I/O modules 61****ArmorBlock Guard I/O recommended cables and connectors 62****ArmorConnect**

- cable ratings 50
- non-safety connections 49
- power media 41

ArmorConnect connections

- safety version 67

C**cable system overview**

- non-safety version 42
- safety version 59

catalog number explanation

- Bulletin 281E 19
- Bulletin 284E 20

CIP

- assembly object 291
- connection manager object 296
- control supervisor object 306
- device level ring (DLR) object 309
- discrete input group object 304
- discrete input point object 299
- discrete output group object 304
- discrete output point object 300
- DPI alarm object 315
- DPI fault object 311
- ethernet link object 319
- identity object 289
- interface object 317
- overload object 308
- parameter group object 303
- parameter object 301
- Qos object 310
- TCP/IP interface object 318

CIP information 287**CIP object requirements 288****component response time 65****connections**

- Ethernet and I/O 51
- power 51
- safety I/O 68

contactor circuit verification procedure 65**control module LED status and reset 26****control power 43****ControlLogix explicit message**

- formatting 204
- performing 205
- programming 203
- setting up the MSG instruction 203

D**demand torque off considerations 354****device level ring introduction 74****DeviceLogix 321**

- import and export 329
- programming 322
- programming example 323

DeviceLogix ladder editor example 346**diagnostics 207**

- clear fault 207
- control module fault LED indications 213
- control module LED status and reset 213
- EtherNet/IP LED status indication 211
- fault 11 detail 215
- fault codes 208
- fault definitions 208
- fault display 207
- overview 207
- protection programming 207
- resetting device to factory defaults 217

dimensions

- Bulletin 281E ArmorStart 36
- Bulletin 281E safety version 55
- Bulletin 284E ArmorStart 38
- Bulletin 284E safety version 57

DLR network

- number of nodes 76
- troubleshoot 234

E**electromagnetic compatibility (EMC)**

- general notes (Bulletin 284E only) 46
- wiring 46

electronic data sheet (EDS) 26**embedded switch technology 22****embedded web server 25****ethernet media 76****ethernet switches 76****EtherNet/IP and device level ring (DLR)****technology introduction 69****EtherNet/IP general wiring guideline 77****EtherNet/IP introduction 70****EtherNet/IP LED status indication 25****EtherNet/IP ports 25****Explicit Message configuration 203****F****fault diagnostics 27**

features 22

- DeviceLogix 28
- gland plate entrance 28
- inputs 27
- motor cable 28
- outputs 28

functional safety 55**G****gateway address** 80**grounding**

- PE or ground 47
- safety grounds 47

group motor installations for USA and Canada markets 44**I****inspecting** 33**installation** 33**IP address** 79**K****keypad disable with DeviceLogix** 354**L****linear network**

- troubleshoot 234

linear network introduction 73**M****maintenance** 53

- safety version 65

manual brake control 337**media counter error or collisions** 234**mode of operation**

- full-voltage and reversing start 21
- sensorless vector control 21

motion disable 354**motor cable considerations** 48**motor operation** 20**mount orientation** 40**multiple-motor branch circuit**

- ArmorStart application 271
- ArmorStart product family 274
- background 271
- combined load conductors 286
- explanatory example 279
- input and output conductors for mechanical controllers 285
- input and output conductors for variable frequency drives 285
- introduction 271
- motor controllers Listed for group installation 275

O**overload protection** 22**P****partial fault condition** 233**power connections**

- safety 24
- switched 23
- unswitched 24

precautions

- Bulletin 284E applications 35
- general 34

probability of dangerous failure per hour and MTTFd for uncontrolled stop 65**product**

- description 18
- overview 17

product commissioning 79**protection faults** 27**R****rapid ring fault** 233**receiving** 33**replacement parts** 331

- Bulletin 281E 331
- Bulletin 281E safety version 332
- Bulletin 284E 332
- Bulletin 284E safety version 333
- fuses 334
- miscellaneous 334

reporting examples 352**requested packet interval** 77**S****safety**

- configuration 63
- function definition 62
- I/O module and TÜV requirements 60
- PLC program 64
- wiring 60

safety-related part limitations 62**shield and grounding of motors and motor cables** 48**specifications** 245

- altitude derating 259
- Bulletin 281E 245
- Bulletin 284E 253
- motor overload trip curves, Bulletin 281E 249
- motor overload trip curves, Bulletin 284E 257

storing 33

Studio 5000 software

- adding ArmorStart 97
- configuring ArmorStart with Add-On-Profile (AOP) 100
- offline connection 102
- setup 97

subnet mask 80**system design considerations 45****system design considerations when using a line reactor 335****T****terminology 69****troubleshoot 234**

- partial fault condition 233

troubleshooting 219

- actions to take before correcting specific network faults 231
- Bulletin 281E 220
- Bulletin 284E 221
- Bulletin 284E fault definitions 221
- DB1 faults 222
- fuse replacement 242
- hardware fault - Fan RPM warning 226
- internal drive faults 227
- IP67 dynamic brake diagnostic (DB1) 222
- linear or DLR networks 231
- media counter errors or collisions 234
- rapid ring fault 233
- safety 66
- supervisor reports a ring fault 232

U**ungrounded and high resistive distribution systems 44****unpacking 33****unshielded cable 48****V****VFD preset speed example, Bulletin 284E 340****W****wiring**

- Bulletin 281E ArmorStart 37
- Bulletin 281E safety version 56
- Bulletin 284E ArmorStart 39
- Bulletin 284E safety version 58

wiring guidelines 44

Notes:

Rockwell Automation Support

Use the following resources to access support information.

Technical Support Center	Knowledgebase Articles, How-to Videos, FAQs, Chat, User Forums, and Product Notification Updates.	https://rockwellautomation.custhelp.com/
Local Technical Support Phone Numbers	Locate the phone number for your country.	http://www.rockwellautomation.com/global/support/get-support-now.page
Direct Dial Codes	Find the Direct Dial Code for your product. Use the code to route your call directly to a technical support engineer.	http://www.rockwellautomation.com/global/support/direct-dial.page
Literature Library	Installation Instructions, Manuals, Brochures, and Technical Data.	http://www.rockwellautomation.com/global/literature-library/overview.page
Product Compatibility and Download Center (PCDC)	Get help determining how products interact, check features and capabilities, and find associated firmware.	http://www.rockwellautomation.com/global/support/pcdc.page

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete the How Are We Doing? form at http://literature.rockwellautomation.com/idc/groups/literature/documents/du/ra-du002_-en-e.pdf.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Allen-Bradley, ArmorBlock, ArmorBlock Guard I/O, ArmorConnect, ArmorStart, ControlLogix, DeviceLogix, Guard I/O, LISTEN. THINK. SOLVE., On-Machine, PowerFlex, Rockwell Software, RSLinx, RSLogix 5000, RSNetWorx, StepLogic, and Studio 5000 are trademarks of Rockwell Automation, Inc.
DeviceNet, EtherNet/IP, CIP, CIP Motion, CIP Safety, and CIP Sync are trademarks of ODVA, Inc. National Electrical Code, NEC, and NFPA are trademarks of the National Fire Protection Association.
Other trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 280ES-UM001B-EN-P - June 2017

Supersedes Publication 280ES-UM001A-EN-P - November 2016

Copyright © 2017 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.